

INTRODUCTION

How to Use This Manual

This supplement contains information for the 1990 CIVIC.
Refer to following shop manuals for service procedures.

Description	Code No.
CIVIC CHASSIS	62SH300
Maintenance and Repair	
CIVIC SHUTTLE/WAGON	62SH520
Supplement	
'89 CIVIC Supplement	62SH320
D12B/D13B/D14A/D15B/D16A ENGINE	62PM100
Maintenance and Repair	
L3 MANUAL TRANSMISSION	62PL300
Maintenance and Repair	
L3 (4WD) MANUAL TRANSMISSION	62PH800
Maintenance and Repair	
L4 AUTOMATIC TRANSMISSION	62PL400
Maintenance and Repair	
S5 AUTOMATIC TRANSMISSION	62PS500
Maintenance and Repair	

The first page of each section is marked with a black tab that lines up with one of the thumb index tabs on this page. You can quickly find the first page of each section without looking through a full table of contents. The symbols printed at the top corner of each page can also be used as a quick reference system.

Special information

▲WARNING Indicates a strong possibility of severe personal injury or loss of life if instructions are not followed.

CAUTION: Indicates a possibility of personal injury or equipment damage if instructions are not followed.

NOTE: Gives helpful information.

CAUTION: Detailed descriptions of *standard* workshops procedures, safety principles and service operations are not included. Please note that this manual does contain warnings and cautions against some specific service methods which could cause **PERSONAL INJURY**, or could damage a vehicle or make it unsafe. Please understand that these warnings cannot cover all conceivable ways in which service, whether or not recommended by Honda Motor, might be done, or of the possible hazardous consequences of each conceivable way, nor could Honda Motor investigate all such ways. Anyone using service procedures or tools, whether or not recommended by Honda Motor, *must satisfy himself thoroughly* that neither personal safety nor vehicle safety will be jeopardized.

All information contained in this manual is based on the latest product information available at the time of printing. We reserve the right to make changes at any time without notice. No part of this publication may be reproduced, stored in retrieval system, or transmitted, in any form by any means, electronic, mechanical, photocopying, recording, or otherwise, without the prior written permission of the publisher. This includes text, figures and tables.

*(Asterisk) marked sections are not included in this manual.

HONDA MOTOR CO., LTD.
Service Publication Office

First Edition 10/89 550 pages
All Rights Reserved

General Info



Special Tools



Specifications



Maintenance



Engine



Fuel and Emissions



Transaxle



Steering*



Suspension*



Brakes



Body



Heater and Air Conditioner



Electrical



Outline of Model Changes

ITEM	DESCRIPTION	89 MODEL	90 MODEL	REFERENCE SECTION
Engine	Modified • Oil filter • Crankshaft pulley bolt • Engine mounting bolts • Exhaustpipe	○		—
	D13B engine (1.3ℓ SOHC PGM-CARB) adopted for KG, KS models		○	5
	Oil filter modified		○	5
Carburetion	Vacuum connections modified	○		—
	D13B engine (1.3ℓ SOHC PGM-CARB) adopted for KG, KS models		○	6
PGM-FI	Fast idle control solenoid valve adopted Throttle body modified	○		—
	Adopted • Fuel sub pump • Fuel cut-off relay		○	6
Manual Transmission	Modified • Spring pin added • Mainshaft thrust shim • Countershaft ball bearing	○		—
Automatic Transmission	Modified • Servo valve body • Parking brake stoppers	○		—
	4WD automatic transmission adopted		○	8
Rear Suspension	Modified	○		—
Brake System	3-channel ALB with 4WD for some types		○	13
Instrument Panel	Modified		○	14
Air Conditioner	Pipe routing modified	○		—
	SANDEN Compressor adopted for some types		○	15
	Compressor pressure plate modified		○	15
Lighting System	Modified	○		—
High Mount Brake Light	Adopted for some types	○		—
Lighting System	Modified		○	—
Gauge Assembly	Modified		○	16
Shift Lever Position Indicator	Modified		○	16



General Information

Chassis and Engine Numbers	1 – 2
Identification Number Locations	1 – 3
Label Locations	1 – 4
Lift and Support Points	1 – 5
Towing	1 – 8
Preparation of Work	1 – 9
Symbol Marks	1 – 15
Abbreviation	1 – 15

Chassis and Engine Numbers

Vehicle Identification Number (2-door Hatchback)

JHM EC7 3200S200001

Manufacturer, Make and Type of vehicle

JHM:HONDA MOTOR CO., LTD.,
JAPAN
HONDA, Passenger car

Line/Body and Engine type

EC7: CIVIC 1200 Hatchback
EC8: CIVIC 1300 Hatchback
EC9: CIVIC 1400 Hatchback
ED6: CIVIC 1500 Hatchback
ED7: CIVIC 1600 Hatchback

Transmission and Body type

3: 5-speed manual/2-door
Hatchback
4: 4-speed automatic/2-door
Hatchback

Vehicle Grade

2: DX (EC7, EC8, ED6: KQ)
GL (EC9, ED6: KY)
3: GL (ED6: KQ)
4: DX (ED6: KX, KS, KW)
5: GL (ED6: KX, KS, KW)
6: 1.6i (ED7: SOHC)
7: 1.6i-16 (ED7: DOHC)

Fixed Code

Auxiliary Number

Factory

S: Suzuka Factory

Model Year

2: 1990

Serial Number

Vehicle Identification Number (4-door Sedan)

JHM ED1 5200S200001

Manufacturer, Make and Type of vehicle

JHM:HONDA MOTOR CO., LTD.,
JAPAN
HONDA, Passenger car

Line/Body and Engine type

ED1: CIVIC 1200 Sedan
ED2: CIVIC 1400 Sedan
ED3: CIVIC 1500 Sedan
ED4: CIVIC 1600 Sedan
ED5: CIVIC 1300 Sedan
EE5: CIVIC 1600 4WD Sedan

Transmission and Body type

5: 5-speed manual/4-door Sedan
5-speed+SL* manual/4-door Sedan
6: 4-speed automatic/4-door Sedan

Vehicle Grade

1: DX (ED3: KY)
2: DX (ED1, ED5, ED3: KQ)
GL (ED2, ED3: KP, KT, KY)
3: EX (ED3: KY)
GL (ED3: KQ)
4: DX (ED3: KS, KW)
5: GL (ED3: KX, KS, KW)
6: 1.6i (ED4)
1.6i 4WD (EE5)

Fixed Code

Auxiliary Number

Factory

S: Suzuka Factory

Model Year

2: 1990

Serial Number

SL*: Super Low Gear



Vehicle Identification Number (4-door Hatchback)

JHM EE1 7200S200001

Manufacturer, Make and Type of vehicle

JHM:HONDA MOTOR CO., LTD.,
JAPAN

HONDA, Passenger car

Line/Body and Engine type

EE1: CIVIC 1400 4-door Hatchback

EE2: CIVIC 1500 4-door Hatchback

EE3: CIVIC 1500 4WD 4-door
Hatchback

EE4: CIVIC 1600 4WD 4-door
Hatchback

Transmission and Body type

7: 5-speed manual/4-door Hatchback
5-speed+SL* manual/
4-door Hatchback

8: 4-speed automatic/4-door
Hatchback

Vehicle Grade

2: GL (except KX, KS)

RTX

5: GL (KX, KS)

6: 1.6i-4WD

Fixed Code

Auxiliary Number

Factory

S: Suzuka Factory

Model Year

2: 1990

Serial Number

SL*: Super Low Gear

Engine Serial Number (except KQ model)

D12B1-14 00001

Engine Type

D12B1: 1.2 l SOHC 1-Carbureted Engine

D13B1: 1.3 l SOHC 1-Carbureted Engine

D13B2: 1.3 l SOHC 1-Carbureted Engine
with catalytic converter

D14A1: 1.4 l SOHC 2-Carbureted Engine

D15B1: 1.5 l SOHC PGM-FI Engine for
DX models of KS, KW

D15B2: 1.5 l SOHC PGM-FI Engine for
GL models of KG, KS, KX, KW

D15B3: 1.5 l SOHC 1-Carbureted Engine

D16Z2: 1.6 l SOHC PGM-FI Engine with
catalytic converter

D16A7: 1.6 l SOHC PGM-FI Engine with-
out catalytic converter

D16A9: 1.6 l DOHC PGM-FI Engine

Emission Group

10: D13B2 Engine with catalytic converter

14: without catalytic converter
except D16A7 Engine

30: D16A7 Engine without catalytic
converter

37: with catalytic converter DX models of KS,
KW and GL models of KS,

38: with catalytic converter GL models of KG, KW

Serial Number

Engine Serial Number (KQ model)

D15B4-1400001

Engine Type

D15B4: 1.5 l SOHC 2-Carbureted Engine
with catalytic converter

Serial Number

Transmission Number

L3-2000001

Transmission Type

L3: 5-speed Manual Transmission
and 5-speed+SL* Manual Transmission for
4 WD

L4: Automatic Transmission

S5: Automatic Transmission for 4 WD

Serial Number

L3: 2000001~


L3(4 WD): 9100001~

L4: 5000001~


S5: 2000001~

SL*: Super Low Gear

Identification Number Locations



Label Locations




Lift and Support Points

Hoist

1. Place the lift blocks as shown.
2. Raise the hoist a few inches and rock the car to be sure it is firmly supported.
3. Raise the hoist to full height and inspect lift points for solid support.

⚠ WARNING When heavy rear components such as suspension, fuel tank, spare tire and trunk lid/hatch are to be removed, place additional weight in the trunk before hoisting. When substantial weight is removed from the rear of the car, the center of gravity may change and can cause the car to tip forward on the hoist.

NOTE: Since each tire/wheel assembly weighs approximately 14 kg (30 lbs), placing the front wheels in the trunk will assist with the weight distribution.






Floor Jack

1. Set the parking brake and block the wheels that are not being lifted.
2. When lifting the rear of the car, put the gearshift lever in reverse (Automatic in PARK).
3. Raise the car high enough to insert the safety stands.
4. Adjust and place the safety stands as shown on page 1-7 so the car will be approximately level, then lower the car onto the stands.


▲WARNING

- Always use safety stands when working on or under any vehicle that is supported by only a jack.
- Never attempt to use a bumper jack for lifting or supporting the car.

Front




Rear



(cont'd)

Lift and Support Points (cont'd)

Safety Stands



Service Precautions



Towing

For 4WD see also "4WD Disengagement,"

If possible, always tow the car with the front wheels off the ground. The tow truck driver should position wood spacer blocks between the car's frame and the chains and lift straps, to avoid damaging the bumper and the body.

Do not use the bumpers to lift the car or to support the car's weight while towing. Check local regulations for towing. A rope may be attached to the hook shown in the illustration. Do not attach a tow bar to either bumper.

▲WARNING

- Do not or tow a car to start it. The forward surge when the engine starts could cause a collision. (On some types) Also, under some conditions, the catalytic converter could be damaged. A car equipped with an automatic transmission cannot be started by pushing or towing.

- (4WD) Before towing the car with either the front or rear wheels raised off the ground, place the transmission in neutral and manually disengage the 4WD system to prevent the raised wheels from turning.

If the car to be towed with the front wheels on the ground observe the following precautions :

Manual Transmission


Shift the transmission to Neutral and turn the ignition key to the "I" position.

Automatic Transmission

First, check the automatic transmission fluid level (see Section 9). Start the engine and shift to D4, then to N. Return the ignition key to the 9 position.

CAUTION :

- Do not tow with front wheels on the ground when the automatic transmission fluid level is low or the transmission cannot be shifted with the engine running.
- Do not exceed 55 km/h (35 mph) or tow for distances of more than 80 km (50 miles).



TOWING HOOKS


4 WD Disengagement

The 4WD System shifts instantaneously and automatically from front wheel drive to four wheel drive when greater traction is needed.

⚠ WARNING The 4WD system must be manually disengaged before performing service that requires only the front wheels or only the rear wheels to be turning. Disengaging the system will prevent sudden movement of the car, which may result in personal injury.

TOWING:

CAUTION: Before towing the car with either the front or rear wheels raised off the ground, place the transmission in neutral and manually disengage the 4WD system to prevent the raised wheels from turning.



If possible, always tow the car with the front wheels off the ground, and 4WD disengaged. Do not use the bumpers to lift the car or to support the car's weight while towing. Check local regulations for towing with a chain or frame-mounted tow bar. A chain may be attached to the hooks shown in the illustration. Do not attach a tow bar to either bumper.

If the car is to be towed with front wheels on the ground, observe the following precautions:

Manual Transmission


Shift the transmission to Neutral and turn the ignition key to the "I" position.

Automatic Transmission

First, check the automatic transmission fluid level (see section 9). Start the engine and shift to D4, then to N. Return the ignition key to the "I" position.

CAUTION

- Do not tow with front wheels on the ground when the automatic transmission fluid level is low or the transmission cannot be shifted with the engine running.
- Do not exceed 55 km/h (35 mph) or tow for distances of more than 80 km (50 miles).




TOWING HOOKS

4WD Disengagement

(For cars not equipped ALB)

Manual Transmission :

1. Locate the orange disengagement lever at the rear of the engine compartment.



2. Loosen the lock at the slotted end of the lever.

NOTE : For better accessibility, use a socket and a long extension bar.


CAUTION : Do not loosen the lock bolt more than 5 — 7 turns.

Replacement is extremely difficult.

Unlocked Position
(4WD off)

MIDDLE BOLT

Locked Position
(4WD on)




3. Move the lever by turning the middle bolt counter-clockwise.
4. Tighten the lock bolt.

NOTE : After service or towing is completed return the lever to the normal (4WD on) position and tighten the lock bolt.



Automatic transmission :


1. Locate the disengagement plate at the rear of the transmission case behind the right front wheel.



2. Loosen the lock bolt in the notch on the plate.

NOTE : For better accessibility, use a socket and a long extension bar.

CAUTION : Do not loosen the middle bolt more than 5 – 7 turns. Replacement is extremely difficult.




3. Turn the middle bolt counterclockwise until the plate rotates about 150° and is stopped by the lock bolt.
4. Tighten the lock bolt.

NOTE : After service or towing is completed, return the plate to the normal (4WD on) position and tighten the lock bolt.

4WD Disengagement (For cars equipped with ALB)


1. Locate the orange disengagement bolt at the front of the rear differential behind the left rear wheel.



2. Loosen the middle bolt fixing the lock plate.

NOTE : For better accessibility, use a socket and a long extension bar.

CAUTION : Do not loosen the middle bolt more than 5 – 7 turns. Replacement is extremely difficult.



3. Turn the disengagement bolt counterclockwise until the disengagement bolt rotates about 180° and is stopped by the lock plate.
4. Tighten the middle bolt.


NOTE : After service or towing is completed, return the plate to the normal (4WD on) position and tighten the middle bolt.

Preparation of Work

Special Caution Items for This Car


1. ALB piping system servicing

- Dissassemble the ALB piping after relieve the high-pressured brake fluid.
- Otherwise, the high-pressured brake fluid will burst out and it is very dangerous.
- See section 13 how to relieve the high-pressured brake fluid.




2. Fuel Line Servicing

- Relieve fuel pressure by loosening the service bolt provided on the top of the fuel filter before disconnecting a fuel hose or a fuel pipe.




- Be sure to replace washers, O-rings, and rubber seals with new ones when servicing fuel line parts.
- Always apply oil to the surfaces of O-rings and seal rings before installation. Never use brake fluid, radiator fluid, vegetable oils or alcohol-based oils.





- When assembling the flare joint of the high-pressure fuel line, clean the joint and coat with new engine oil.
- When installing an injector, check the angle of the connector. The center line of the coupler should align with the setting mark on the injector holder.



3. Inspection for fuel leakage

- After assembling fuel line parts, turn ON the ignition switch (do not operate the starter) so that the fuel pump is operated for approximately two seconds and the fuel is pressurized. Repeat this operation two or three times and check whether any fuel leakage has occurred in any of the various points in the fuel line.

4. Installation of an amateur radio for cars equipped with PGM-FI and ALB.

Care has been taken for the control units of the Fuel-Injection, Carburetor, and its wiring to prevent erroneous operation from external interference, but erroneous operation of the control unit may be caused by extremely strong radio waves. Attention must be paid to the following items to prevent erroneous operation of the control units.

- The antenna and the body of the radio must be PGM-FI at least 200 mm (7.9 in.) away from the control units.

The control unit locations:

- Fuel-Injection, Carburetor: Passenger's side front floor panel.
- ALB : Right side panel of luggage area.
- Do not lead the antenna feeder and the coaxial cable over a long distance parallel to the car's wiring. When crossing with the wiring is required, execute crossing at a right angle.
- Do not install a radio with a large output (max. 10 W).


5. Apply liquid gasket to the transmission, oil pump cover, right side cover and water outlet. Use Honda genuine liquid gasket, Part NO. 0Y740-99986.

- Check that the mating surfaces are clean and dry before applying liquid gasket. Degrease the mating surfaces if necessary.
- Apply liquid gasket evenly, being careful to cover all the mating surface.
- To prevent leakage of oil, apply liquid gasket to the inner threads of the bolt holes.
- Do not install the parts if 20 minutes or more have elapsed since applying liquid gasket. Instead reapply liquid gasket after removing the old residue.
- After assembly, wait at least 30 minutes before filling the appropriate liquid (engine oil, coolant and other similar fluid).


Preparation of Work

CAUTION: Observe all safety precautions and notes while working.

1. Protect all painted surfaces and seats against dirt and scratches with a clean cloth or vinyl cover.




2. Work safely and give your work your undivided attention. When either the front or rear wheels are to be raised, block the remaining wheels securely. Communicate as frequently as possible when a work involves two or more workers. Do not run the engine unless the shop or working area is well ventilated.




3. Prior to removing or disassembling parts, they must be inspected carefully to isolate the cause for which service is necessary. Observe all safety notes and precautions and follow the proper procedures as described in this manual.



4. Mark or place all removed parts in order in a parts rack so they can be reassembled in their original places.




5. Use the special tools when use of such a tool is specified.




6. Parts must be assembled with the proper torque according to the maintenance standards established.


7. When tightening a series bolts or nuts, begin with the center or larger diameter bolts and tighten them in crisscross pattern in two or more steps.



8. Use new packings, gaskets, O-rings and cotter pins whenever reassembling.




9. Use genuine HONDA parts and lubricants or those equivalent. When parts are to be reused, they must be inspected carefully to make sure they are not damaged or deteriorated and are in good usable condition.





10. Coat or fill parts with specified grease as specified (Page 4-2). Clean all removed parts with solvent upon disassembly.




11. Brake fluid and hydraulic components

- When replenishing the system, use extreme care prevent dust and dirt from entering the system.
- Do not mix different brands of fluid as they may not be compatible.
- Do not reuse drained brake fluid.
- Brake fluid can cause damage to painted surfaces. Wipe up spilled fluid at once.
- After disconnecting brake hoses or pipes, be sure to plug the openings to prevent loss of brake fluid.
- Clean all disassembled parts only in clean BRAKE FLUID. Blow open all holes and passages with compressed air.




- Keep disassembled parts from air-borne dust and abrasives.
 - Check that parts are clean before assembly.
12. Avoid oil or grease getting on rubber parts and tubes, unless, specified.
13. Upon assembling, check every part for proper installation and operation.




Electrical


- Before making any repairs on electric wires or parts, disconnect the battery cables from the battery starting with the negative (–) terminal.




- After making repairs, check each wire or part for proper routing and installation. Also check to see that they are connected properly.
- Always connect the battery positive (+) cable first, then connect the negative (–) cable.



- Coat the terminals with clean grease after connecting the battery cables.
- Don't forget to install the terminal cover over the positive battery terminal after connecting.
- Before installing a new fuse, isolate the cause and take corrective measures, particularly when frequent fuse failure occurs.



- Be sure to install the terminal cover over the connections after a wire or wire harness has been connected.




(cont'd)

Preparation of Work


Electrical (cont'd)

- When removing locking couplers, be sure to disengage the lock before disconnecting.
- Couplers may be of two types, those in which the lock is pressed to remove, and those in which the lock is pulled up to remove. Be sure to ascertain the type of locking device before beginning work. The following is a depiction of the means of disconnecting various typical couplers.


Press to disengage:




Pull up to disengage:




- When disconnecting locks, first press in the coupler tightly (to provide clearance to the locking device), then operate the tab fully and remove the coupler in the designated manner.




- All plastic plugs have locking tabs that must be released before disconnecting, and must be aligned when reconnecting.




- When disconnecting a coupler, pull it off from the mating coupler by holding on both couplers.
- Never try to disconnect couplers by pulling on their wires.




- Before connecting couplers, check to see that the terminals are in place and are not bent or distorted.



- Insert couplers fully until they will no longer go.
- Some couplers have locking tabs that must be aligned and engaged securely.
- Don't use wire harnesses with a loose wire or coupler.




- Place the plastic cover over the mating coupler after reconnecting. Also check that the cover is not distorted.







- Before connecting, check each connector cover for damage. Also make sure that the female connector is tight and not loosened from the previous use.




- Insert male connectors into the female connectors fully until they will no longer go.
- Be sure that plastic cover is placed over the connection.
- Position the wires so that the open end of the cover is not facing upward.



- Secure wires and wire harnesses to the frame with their respective wire bands at the designated locations. Position the wiring in the bands so that only the insulated surfaces contact the wires or wire harnesses.




- A loose wire harness or cable can be a hazard to safety. After clamping, check each wire for security in its clamp.




- Do not squeeze wires against the weld when a weld-on clamp is used.




- After clamping, check each harness to be certain that it is not interfering with any moving or sliding parts of the vehicle.
- Keep wire harnesses away from the exhaust pipes and other hot parts.




- Always keep a safe distance between wire harnesses and any heated parts.



- Do not bring wire harnesses in direct contact with sharp edges or corners.
- Also avoid contact with the projected ends of bolts, screws and other fasteners.



- Route harnesses so they are not pulled taut or slackened excessively.




(cont'd)


Preparation of Work

Electrical (cont'd)


- Protect wires and harnesses with a tape or a tube if they are in contact with a sharp edge or corner.




- Clean the attaching surface thoroughly if an adhesive is used. First, wipe with solvent or alcohol in necessary.




- Seat grommets in their grooves properly.




- Do not damage the insulation when connecting a wire.
- Do not use wires or harnesses with a broken insulation. Repair by wrapping with a protective tape or replace with new ones if necessary.




- After installing parts, make sure that wire harnesses are not pinched.




- After routing, check that the wire harnesses are not twisted or kinked.



- Wire harnesses should be routed so that they are not pulled taut, slackened excessively, pinched, or interfering with adjacent or surrounding parts in all steering positions.



- When using the Service Tester, follow the manufacturer's instructions and those described in the Shop Manual.



- Do not drop parts.



- Rust is the enemy of all finished surfaces. Before connecting connectors and couplers, check the terminals and remove, if any, rust using a fine sand paper or emery cloth.



Symbol Marks

The following symbols stand for:



:Apply engine oil.



:Apply brake fluid.



:Apply grease.



:Apply Automatic Transmission Fluid



: Apply Power Steering Fluid.



:Apply or check vacuum.

①, ②, ③, :

①, ②, ③, :

Sequence for removal or installation.

Abbreviation



2D H/B	2-door Hatchback
4D	4-door Sedan
4D H/B	4-door Hatchback
A/C	Air Conditioner
A/T	Automatic Transmission
ATF	Automatic Transmission Fluid
Bor BAT	Battery
CATA	Catalytic Converter
EACV	Electronic Air Control Valve
ECU	PGM-FI Electronic Control Unit
EGR	Exhaust Gas Recirculation
EX	Exhaust
GND	Ground
IG	Ignition
IN	Intake
INT	Intermittent
L.	Left
LHD	Left Hand Drive
M/T	Manual Transmission
PCV	Positive Crankcase Ventilation
PGM-CARB	Programmed Carburetor
PGM-FI	Programmed Fuel-Injection
P/S	Power Steering
R.	Right
RHD	Right Hand Drive
SW	Switch
SOL. V	Solenoid Valve
TDC	Top Dead Center
P	Parking
R	Reverse
N	Neutral
D₄	Drive Position (1st~4th)
D₃	Drive Position (1st~3rd)
2	2nd Position



Special Tools

Engine	2 — 2
Fuel and Emissions	2 — 2
Clutch	2 — 2
Manual Transmission	2 — 3
Automatic Transmission	2 — 4
Driveshafts	2 — 5
Rear Differential (4WD).....	2 — 5
Manual Steering	2 — 5
Power Steering	2 — 6
Suspension	2 — 6
Brakes	2 — 7
Body	2 — 7
Heater and Air Conditioner	2 — 7
Electrical	2 — 7

Special Tools

5. Engine

Number	Tool Number	Description	Q'ty	Remarks
①	07GAD-PH70200	Valve Guide Seal Installer	1	For DOHC engine
②	07HAD-PJ70100	Oil Seal Driver	1	Crankshaft (Clutch side)
③	07HAD-PJ70200	Valve Guide Seal Installer	1	
④	07HAH-PJ70100	Valve Guide Reamer, 5.5mm	1	
⑤	07JAB-0010000	Crank Pulley Holder Set	1	
⑤-1	07JAA-0010100	Socket Wrench 17mm	(1)	} Component tools
⑤-2	07JAB-0010100	Pulley Holder Attachment	(1)	
⑤-3	07JAB-0010200	Handle	(1)	
⑥	07JAZ-SH20100	PRM Connecting Adaptor	1	
⑦	07JGG-0010100	Belt Tension Gauge	1	
⑧	07KAK-SJ40100	Engine Tilt Hanger Set	1	
⑨	07406-0030000	Oil Pressure Gauge Adaptor	1	For pressure measurement
⑩	07742-0010100	Valve Guide Driver, 5.5mm	1	
⑪	07742-0010200	Valve Guide Driver, 6.6mm	1	For DOHC engine
⑫	07743-0020000	Adjustable Valve Guide Driver	1	
⑬	07744-0010400	Pin Driver, 5mm	2	Used to set the camshaft at TDC (DOHC engine)
⑭	07749-0010000	Driver	1	07949-6110000 may also be used
⑮	07757-0010001	Valve Spring Compressor	1	07957-3290001 may also be used
⑯	07912-6110001	Oil Filter Socket	1	Used for Japan-made oil filter
⑰	—	Oil Filter Wrench (Apply from LABINAL S.A.)	1	Used for France-made oil filter
⑱	07924-PD20003	Ring Gear Holder	1	07924-PD20002 may also be used
⑲	07944-6110200	Pin Driver, 8mm	2	
⑳	07947-SB00100	Oil Seal Driver	1	
㉑	07948-SB00101	Driver Attachment	1	except 1.6/ crankshaft oil seal (Clutch side)
㉒	07948-SB00800	Driver Attachment	1	1.6/ crankshaft oil seal (Clutch side)
㉓	07973-PE00200	Pilot Collar	1	
㉔	07973-PE00310	Piston Pin Driver Shaft	1	07973-PE00301 may also be used
㉕	07973-PE00320	Piston Pin Driver Head	1	
㉖	07973-PE00400	Piston Pin Base Insert	1	
㉗	07973-SB00100	Piston Base Head	1	
㉘	07973-6570002	Piston Pin Dis/Assembly Tool Set	1	
㉘-1	07973-6570500	Piston Base	(1)	} Component tools
㉘-2	07973-6570600	Piston Base Spring	(1)	
㉙	07984-6570101	Valve Guide Reamer, 6.6mm	1	For DOHC engine

6. Fuel and Emissions

Number	Tool Number	Description	Q'ty	Remarks
①	07GMJ-ML80100	Test Harness	1	
②	07HAZ-PJ70000	ECU Test Harness A	1	
③	07HAZ-PJ70100	ECU Test Harness B	1	
④	07JAZ-SH20100	RPM Connecting adaptor	1	
⑤	07401-0010000	Float Level Gauge	1	
⑥	07406-0040001	Fuel Pressure Gauge Set	1	
⑥-1	07406-0040100	Pressure Gauge	(1)	} Component tools
⑥-2	07406-0040201	Hose Assy	(1)	
⑦	07411-0020000	Digital Circuit Tester	1	
⑧	07614-0050100	Fuel Line Clip	1	
⑨	07999-PD6000A	PGM-FI Test Harness	1	

7. Clutch

Number	Tool Number	Description	Q'ty	Remarks
①	07JAF-PM70100	Clutch Disc Alignment Tool	1	
②	07746-0010100	Attachment, 32×35mm	1	
③	07749-0010000	Driver	1	
④	07924-PD20003	Ping Gear Holder	1	07924-PD20002 may also be used



8. Manual Transmission (2WD)

Number	Tool Number	Description	Q'ty	Remarks
①	07GAJ-PG20102	Mainshaft Clearance Inspection Tool Set	1	
①-1	07GAJ-PG20110	Mainshaft Holder	1	
①-2	07GAJ-PG20120	Collar	1	
①-3	07GAJ-PG20130	Mainshaft Base	1	
②	07744-0010200	Pin Driver 3.0mm	1	
③	07744-0010400	Pin Driver, 5mm	1	07944-6110100 may also be used
④	07746-0010300	Attachment, 42 × 47mm	1	07974-6110100 may also be used
⑤	07746-0010400	Attachment, 52 × 55mm	1	07947-6340200 may also be used
⑥	07746-0030100	Driver	1	
⑦	07746-0030400	Driver, 35mm	1	
⑧	07749-0010000	Driver	1	07949-6110000 may also be used
⑨	07936-6340000	Bearing Remover Tet	1	
⑩	07944-SA00000	Pin Driver 4.0mm	1	
⑪	07947-6110500	Oil Seal Driver	1	
⑫	07947-6340500	Oil Seal Driver Attachment E	1	
⑬	07948-SC20200	Oil Seal Driver	1	
⑭	07979-PJ40000	Magnet Stand Base	1	

8. Manual Transmission (4WD)

Number	Tool Number	Description	Q'ty	Remarks
①	07GAJ-PG20101	Mainshaft Clearance Inspection Tool	1	
②	07JAC-PH80000	Adjustable Bearing Remover Set	1	
②-1	07JAC-PH80100	Bearing Remover Attachment	(1)	} Component tools
②-2	07JAC-PH80200	Remover Handle Assy	(1)	
②-3	07741-0010201	Remover Weight	(1)	
③	07JAD-PH80100	Oil Seal Driver Attachment	1	
④	07JAJ-PH80100	Drive Gear Gauge	1	
⑤	07JAJ-PH80200	Driven Gear Dummy Shaft	1	
⑥	07746-0010200	Attachment, 37 × 40mm	1	
⑦	07746-0010300	Attachment, 42 × 47mm	1	
⑧	07746-0010400	Attachment, 52 × 55mm	1	
⑨	07746-0010500	Attachment, 62 × 68mm	1	
⑩	07746-0010600	Attachment, 72 × 75mm	1	
⑪	07746-0030100	Driver C	1	
⑫	07746-0030400	Driver, 35mm	1	
⑬	07749-0010000	Driver	1	07949-6110000 may also be used
⑭	07907-6010300	Socket Wrench Handle	1	
⑮	07926-SD90000	Companion Flange Holder	1	
⑯	07936-8890101	Bearing Remover Set	1	
⑰	07944-SA00000	Pin Driver, 4.0mm	1	
⑱	07946-MB00000	Bearing Driver	1	
⑲	07947-SD90100	Oil Seal Driver Attachment	1	
⑳	07947-6110500	Oil Seal Driver Attachment	1	
㉑	07947-6340500	Driver Attachment E	1	
㉒	07948-SC20200	Oil Seal Driver	1	
㉓	07960-1870100	Spring Compressor Attachment	1	
㉔	07965-SB00200	Dis/Assembly Tool B	1	
㉕	07966-SD90000	Differential Carrier Stand	1	
㉖	07973-SD90100	Pinion Dummy Shaft	1	
㉗	07973-SD90200	Pinion Height Block	1	
㉘	07973-SD90300	Differential Pinion Center Pin	1	
㉙	07979-PJ40000	Base Stand	1	

Special Tools

9. Automatic Transmission (2WD)

Number	Tool Number	Description	Q'ty	Remarks
①	07GAC-PF40210	Bearing Remover Attachment	1	Use in place of 07936-634000 attachments
②	07GAE-PG40001	Clutch Spring Compressor Set	1	
②-1	07GAE-PG40200	Compressor Bolt Assembly	(1)	} Component tools
②-2	07HAE-PG40200	Compressor Attachment	(1)	
②-3	07960-6120100	Compressor Attachment	(1)	
③	07HAC-PK40100	Transmission Housing Puller	1	
④	07406-0020003	Oil Pressure Gauge Set	1	
④-1	07406-0010201	Oil Pressure Gauge Hose Attachment	(1)	Component tool
⑤	07406-0070000	Low Pressure Gauge	1	
⑥	07746-0010500	Attachment, 62×68mm	1	07947-6340400 may also be used
⑦	07746-0030100	Inner Handle C	1	
⑧	07749-0010000	Driver	1	07949-6110000 may also be used
⑨	07923-6890202	Mainshaft Holder	1	
⑩	07936-6340000	Bearing Remover Set	1	
⑪	07944-SA00000	Pin Driver, 4.0mm	1	
⑫	07947-6110500	Driver Attachment E	1	
⑬	07947-6340201	Oil Seal Driver	1	
⑭	07947-6340500	Driver Attachment E	1	
⑮	07948-SC20200	Oil Seal Driver	1	

9. Automatic Transmission (4WD)

Number	Tool Number	Description	Q'ty	Remarks
①	07GAE-PG40002	Clutch Spring Compressor Set	1	
①-1	07HAE-PL50100	Clutch Spring Compressor Attachment	1	
①-2	07GAE-PG40200	Clutch Spring Compressor Bolt Assembly	1	
①-3	07960-6120101	Clutch Spring Compressor Attachment	1	
②	07HAC-PK40100	Housing puller	1	
③	07KAJ-PS50100	Driven Gear Dummy Shaft	1	
④	07JAC-PH80000	Adjustable Bearing Remover Set	1	
④-1	07JAC-PH80100	Bearing Remver Attachment	1	
④-2	07JAC-PH80200	Remover Handle Assembly	1	
④-3	07741-0010201	Remover Weight	1	
⑤	07JAJ-PH80100	Drive Gear Gauge	1	
⑥	07406-0020003	Gauge Set	1	
⑥-1	07406-0020201	Gauge Hose	1	
⑦	07746-0010200	Attachment, 37×40mm	1	
⑧	07746-0010400	Attachment, 52×55mm	1	
⑨	07746-0010500	Attachment, 62×68mm	1	
⑩	07746-0010600	Attachment, 72×75mm	1	
⑪	07746-0030100	Driver 40mm I.D.	1	
⑫	07746-0030400	Attachment 35mm I.D.	1	
⑬	07749-0010000	Driver	1	
⑭	07923-6890202	Mainshaft Holder	1	
⑮	07926-SD90000	Flange Holder	1	
⑯	07943-SG20200	Oil Seal Driver	1	
⑰	07944-SA00000	Pin Drlren 4.0mm	1	
⑱	07947-SD90100	Oil Seal Driver	1	
⑲	07947-6110500	Driver Attachment E	1	
⑳	07947-6340201	Oil Seal Driver	1	
㉑	07947-6340500	Attachment E	1	
㉒	07948-SC20200	Oil Seal Driver	1	
㉓	07960-1870100	Spring Compressor Attachment	1	



10. Driveshafts

Number	Tool Number	Description	Q'ty	Remarks
①	07GAD-SE00100	Oil Seal Driver Attachment	1	
②	07HAB-SD90101	Companion Flange Holder	1	
③	07JAD-SH30100	Oil Seal Driver Attachment	1	
④	07JAF-SH20400	Support Base Attachment	1	
⑤	07746-0010300	Attachment, 42×47mm	1	
⑥	07746-0010400	Attachment, 52×55mm	1	
⑦	07746-0010500	Attachment, 62×68mm	1	
⑧	07746-0030100	Inner Handle C	1	
⑨	07746-0040800	35mm Pilot	1	
⑩	07746-0040900	40mm Pilot	1	
⑪	07749-0010000	Driver	1	
⑫	07926-SE90000	Companion Flange Holder	1	
⑬	07947-6340201	Driver Attachment	1	
⑭	07947-SD90100	Oil Seal Driver Attachment	1	
⑮	07947-SD90200	Oil Seal Driver Attachment	1	
⑯	07965-SD90100	Support Base	1	
⑰	07965-SD90200	Support Collar	1	

10. Rear Differential(4WD)

Number	Tool Number	Description	Q'ty	Remarks
①	07JAD-PH80100	Oil Seal Driver Attachment	1	07949-6110000 may also be used.
②	07746-0010600	Attachment, 72×75mm	1	
③	07746-0030100	Inner Handle C	1	
④	07749-0010000	Driver	1	
⑤	07907-6010300	Socket Wrench Handle	1	
⑥	07926-SD90000	Companion Flange Holder	1	
⑦	07944-SA00000	Pin Driver, 4mm	1	
⑧	07946-MB00000	Driver	1	
⑨	07947-SD90100	Oil Seal Driver Attachment	1	
⑩	07947-6110500	Driver Attachment E	1	
⑪	07947-6340500	Bearing Driver Attachment E	1	
⑫	07948-SC20200	Oil Seal Driver	1	
⑬	07965-SB00200	Dis/Assembly Tool B	1	
⑭	07973-SD90100	Dummy Pinion Shaft	1	
⑮	07973-SD90200	Pinion Height Block	1	
⑯	07973-SD90300	Pinion Center Pin	1	

11. Manual Steering

Number	Tool Number	Description	Q'ty	Remarks
①	07916-SA50001	Steering Gearbox Lock Nut Wrench	1	07916-6920100 may also be used.
②	07941-6920003	Ball Joint Remover	1	
③	07974-SA50800	Ball Joint Boot Clip Guide B	1	

Special Tools

11. Power Steering

Number	Tool Number	Description	Q'ty	Remarks
①	07GAG-SD40000	P/S Tool Kit	1	} Component tools
①-1	07GAG-SD40100	Piston Seal Ring Guide	(1)	
①-2	07GAG-SD40200	Piston Seal Ring Sizing Tool	(1)	
①-3	07GAG-SD40300	Cylinder End Seal Slider	(1)	
①-4	97GAG-SD40400	Sylinder End Seal Guide	(1)	
①-5	07GAG-SD40600	Tool Box	(1)	} Component tools
②	07GAK-SE00100	P/S Pressure Adaptor Set	1	
②-1*	07GAK-SE00110	P/S Joint Adaptor(Pump)	(1)	
②-2*	07GAK-SE00120	P/S Joint Adaptor(Hose)	(1)	
③	07406-0010200	P/S Pressure Gauge Set	1	
③-1	07406-0010300	Pressure Control Valve	(1)	} Component tools
③-2	07406-0010400	Pressure Gauge	(1)	
④	07725-0030000	Universal Holder	1	
⑤	07746-0010300	Attachment, 42×47mm	1	
⑥	07749-0010000	Driver	1	
⑦	07916-SA50001	Steering Gearbox Lock Nut Wrench	1	07949-6110000may also be used.
⑧	07941-6920003	Ball Joint Remover	1	
⑨	07947-6340300	Driver Attachment	1	
⑩	07974-SA50600	Pinion Seal Guide	1	

②-1* and ②-2* : Component tools

12. Suspension

Number	Tool Number	Description	Q'ty	Remarks
①	07GAE-SE00101	Shock Absorber Spring Compressor	1	07GAE-SE00100may also be used.
②	07GAF-SE00200	Hub Assembly Driver Attachment	1	
③	07GAF-SE00401	Front Hub Driver Base	1	
④	07HGK-0010100	Wheel Alignment Gauge Attachment	1	
⑤	07JAF-SH20110	Hub Dis/Assembly Pilot, 38mm	1	
⑥	07JAF-SH20120	Hub Dis/Assembly Shaft 22.4×25.4mm	1	
⑦	07JAF-SH20200	Ball Joint Remover Base	1	
⑧	07746-0010400	Attachment, 52×55mm	1	
⑨	07746-0010600	Attachment, 72×75mm	1	
⑩	07749-0010000	Driver	1	
⑪	07941-6920003	Ball Joint Remover	1	
⑫	07947-6340000	Driver	1	
⑬	07965-SA70100	Hub Dis/Assembly Tool A	1	
⑭	07965-SB00100	Ball Joint Remover/Installer	1	
⑮	07965-SB00200	Ball Joint Installer Base	1	
⑯	07965-6340301	Hub Dis/Assembly Base	1	
⑰	07965-6920201	Hub Dis/Assembly Base	1	
⑱	07965-6920500	Dis/Assembly Tool E	1	
⑲	07974-SA50700	Ball Joint Boot Clip Guide A	1	
⑳	07974-SA50800	Ball Joint Boot Clip Guide B	1	



13. Brakes

Number	Tool Number	Description	Q'ty	Remarks
①	07GAG-SE00100	Pushrod Adjustment Gauge	1	07949-6110000 may also be used.
②	07HAA-SG00100	ALB T wrench	1	
③	07HAE-SG00100	Brake Spring Compressor	1	
④	07HAJ-SG00601	ALB Checker	1	
	or			
	07508-SB00000		1	
	—07HAJ-SG00400	Adaptor	1	
⑤	07404-5790300	Vacuum Gauge	1	
⑥	07406-5790200	Oil Pressure Gauge	2	
⑦	07410-5790100	Pressure Gauge Attachment C	2	
⑧	07410-5790500	Tube Joint Adaptor	1	
⑨	07510-6340101	Pressure Gauge Joint Pipe	2	
⑩	07510-6340300	Vacuum Joint Tube A	1	
⑪	07747-6890300	Driver Attachment C	1	
⑫	07749-0010000	Driver	1	
⑬	07914-SA50000	Snap Ring Pliers	1	
⑭	07921-0010001	Flare Nut Wrench	1	

14. Body

Number	Tool Number	Description	Q'ty	Remarks
①	07GAZ-SE30100	Torsion Rod Assmby Tool	1	

15. Heater and Air Conditioner

Number	Tool Number	Description	Q'ty	Remarks
①	07HAF-SF10300	Seal Seat Remover	1	Cover plate removal
②	07HAF-SF10400	Seal Remover/Installer	1	Shaft seal removal/installation
③	07JAC-SH20100	A/C Pulley Puller	1	Pulley installation
④	07JAC-SH20300	Shaft Ring Remover	1	
⑤	07746-0030100	Inner Handle C	1	
⑥	07925-6920001	A/C Clutch Holder	1	
⑦	07935-8050003	Fly Wheel Puller	1	
⑧	07947-6340500	Driver Attachment	1	
⑨	07965-6340100	Bearing Driver	1	

16. Electrical

Number	Tool Number	Description	Q'ty	Remarks
①	07920-SB20000	Fuel Sender Wrench	1	

Specifications

Standards and Service Limits	3 — 2
Design Specifications	3 — 23
Body Specifications	3 — 35
Frame Repair Chart	3 — 39

specs

Standards and Service Limits

Unit: mm (in.)

5. Engine/Cylinder Head, Valve Train (SOHC Engine)

[illegible]

5. Engine/Cylinder Head, Valve Train (DOHC Engine)

	MEASUREMENT		STANDARD (NEW)	SERVICE LIMIT
Compression	250 min ⁻¹ (rpm) and wide-open throttle		Nominal Minimum Maximum variation	1,324 kPa (13.5 kg/cm ² , 192 psi) 932 kPa (9.5 kg/cm ² , 135 psi) 196 kPa (2 kg/cm ² , 28 psi)
Cylinder head	Warpage Height		131.95–132.05 (5.1949–5.1988)	0.05 (0.002)
Camshaft	End play		0.05–0.15 (0.002–0.006)	0.5 (0.02)
	Oil clearance		0.050–0.089 (0.002–0.004)	0.15 (0.006)
	Runout		0–0.03 (0–0.001) max.	0.06 (0.002)
	Cam lobe height	IN EX	33.021 (1.3000) 32.382 (1.2749)	— —
Valve	Valve clearance	IN EX	0.12–0.17 (0.005–0.007) 0.14–0.19 (0.006–0.008)	— —
	Valve stem O.D.	IN EX	6.58–6.59 (0.2591–0.2595) 6.55–6.56 (0.2579–0.2583)	6.55 (0.2579) 6.52 (0.2567)
	Stem-to-guide clearance	IN EX	0.02–0.05 (0.001–0.002) 0.05–0.08 (0.002–0.003)	0.08 (0.003) 0.11 (0.005)
	Stem installed height	IN EX	45.545–46.015 (1.7931–1.8116) 44.735–45.205 (1.7612–1.7797)	46.265 (1.8215) 45.455 (1.7896)
	Valve seat	Width	1.25–1.55 (0.049–0.061)	2.0 (0.08)
	Valve spring	Free length Squarness	47.49 (1.8697) 46.89 (1.8461)	46.46 (1.8291) 45.93 (1.8083)
Valve guide	I.D.	IN and EX	6.61–6.63 (0.2602–0.2610)	6.55 (0.2579)

5. Engine/Engine Block

	MEASUREMENT		STANDARD (NEW)	SERVICE LIMIT
Cylinder block	Warpage of deck surface Bore diameter Bore taper Reboring limit		— 75.00–75.02 (2.9528–2.9535) — —	0.10 (0.004) 75.07 (2.9555) 0.05 (0.002) 0.5 (0.02)
Piston	Skirt O.D. At 16 mm (0.63 in) from bottom of skirt Clearance in cylinder Piston-to-ring clearance	Top 2nd	74.98–74.99 (2.9520–2.9524) 0.01–0.04 (0.0004–0.0016) 0.03–0.06 (0.0012–0.0024) 0.030–0.055 (0.0012–0.0022)	74.97 (2.9516) 0.05 (0.002) 0.13 (0.005) 0.13 (0.005)
Piston ring	Ring end gap	Top 2nd Oil	0.15–0.30 (0.006–0.012) 0.30–0.45 (0.012–0.018) 0.20–0.80 (0.008–0.031)	0.6 (0.02) 0.6 (0.02) 0.9 (0.04)
Connecting rod	Pin-to-rod interference Large end bore diameter 1.2ℓ, 1.3ℓ, 1.4ℓ 1.5ℓ 1.6ℓ End play installed on crankshaft		0.014–0.040 (0.0006–0.0016) Nominal 43.0 (1.69) Nominal 45.0 (1.77) Nominal 48.0 (1.89) 0.15–0.30 (0.006–0.012)	— — — — 0.40 (0.016)
Crankshaft	Main journal diameter 1.6ℓ except 1.6ℓ Taper/out-of-round, main journal Rod journal diameter 1.2ℓ, 1.3ℓ, 1.4ℓ 1.5ℓ 1.6ℓ Taper/out-of-round, rod journal End play Runout		54.976–55.000 (2.1644–2.1654) 44.976–45.000 (1.7707–1.7716) 0.0025 (0.0001) max. 39.976–40.000 (1.5739–1.5748) 41.976–42.000 (1.6526–1.6535) 44.976–45.000 (1.7707–1.7765) 0.0025 (0.0001) max. 0.10–0.35 (0.004–0.014) 0.015 (0.0006) max.	— — 0.010 (0.004) — — — 0.010 (0.004) 0.45 (0.018) 0.03 (0.002)
Bearings	Main bearing-to-journal oil clearance except 1.6ℓ (No. 1, 5 journals) (No. 2, 3, 4 journals) 1.6ℓ (No. 1, 5 journals) (No. 2, 4 journals) (No. 3 journal) Rod bearing-to-journal oil clearance		0.018–0.036 (0.0007–0.0014) 0.024–0.042 (0.0010–0.0017) 0.018–0.036 (0.0007–0.0014) 0.024–0.042 (0.0010–0.0017) 0.030–0.048 (0.0012–0.0019) 0.020–0.038 (0.0008–0.0015)	0.05 (0.002) 0.05 (0.002) 0.05 (0.002) 0.05 (0.002) 0.05 (0.002) 0.05 (0.002)

Standards and Service Limits

Unit: mm (in.)

5. Engine/Engine Lubrication

	MEASUREMENT		STANDARD (NEW)	SERVICE LIMIT
Engine oil	Capacity ℓ (US qt, Imp qt)	SOHC	4.0 (4.2, 3.5) for engine disassembly 3.5 (3.7, 3.1) for oil change	
		DOHC	4.3 (4.5, 3.8) for engine disassembly 3.8 (4.0, 3.3) for oil change	
Oil pump	Displacement	SOHC	44 ℓ (11.6 U.S. gal., 9.7 Imp. gal.)	6,250 min ⁻¹ (rpm)
		DOHC	62 ℓ (16.3 U.S. gal., 13.6 Imp. gal.)	6,750 min ⁻¹ (rpm)
Relief valve	Pressure setting 80°C (176°F)	Idle	69 kPa (0.7 kg/cm ² , 10 psi) min.	
		3,000 min ⁻¹ (rpm)	343 kPa (3.5 kg/cm ² , 50 psi) min.	
Oil pump	Inner-to-outer rotor radial clearance Pump body-to-rotor radial clearance Pump body-to-rotor side clearance		0.14 (0.006) 0.10—0.175 (0.004—0.007) 0.03—0.08 (0.001—0.003)	0.2 (0.008) 0.2 (0.008) 0.15 (0.006)

5. Engine/Cooling

5. Engine / Cooling				
	MEASUREMENT		STANDARD (NEW)	
Radiator	Capacity (incl.heater) ℓ (U.S.qt.,Imp.qt.) (Includes reservoir tank 0.4 (0.42, 0.35))	M/T	1.2 ℓ , 1.3 ℓ , 1.4 ℓ 1.5 ℓ 1-carb, 1.5 ℓ PGM-F I (70ps) 1.6 ℓ SOHC	5.4 (5.7, 4.8)
			1.5 ℓ 2-carb, 1.5 ℓ PGM-F I (90PS) 1.6 ℓ DOHC	5.5(5.8, 4.8)
			1.3 ℓ , 1.4 ℓ	5.3 (5.6, 4.7)
		A/T	1.5 ℓ	5.4 (5.7, 4.8)
			1.6 ℓ	5.9 (6.2, 5.2)
Radiator cap	Pressure cap opening pressure	74—103 kPa (0.75—1.05 kg/cm², 11—15 psi)		
Thermostat	Starts to open Full open Valve lift at full open	76—80°C (169—176°F) 90°C (194°F) 8 (0.31) min.		
Water pump	Pulley ratio (crankshaft)	SOHC DOHC	1 : 1	
	Capacity: ℓ per min/at min ⁻¹ (rpm)		85 (22.4 U.S. gal., 18.7 Imp. gal.) 4,000 min ⁻¹ (rpm) 76 (20.0 U.S. gal., 16.7 Imp. gal.) 4,000 min ⁻¹ (rpm)	
Cooling fan	Fan-to-core clearance Thermoswitch "ON" temperature Thermoswitch "OFF" temperature	28.0 (1.10) 88.5—91.5°C (191—197°F) Subtract 5±1.5°C (9±2.7°F) from actual "ON" temperature.		

6. Fuel and Emission (PGM-FI)

6. Fuel and Emission (PGM-FI)				
	MEASUREMENT		STANDARD (NEW)	
Fuel pump	Delivery pressure Displacement Relief valve opening pressure		250 kPa (2.55 kg/cm ² , 36psi) 236 cc /minutes in 10 seconds min. 441—588 kPa (4.5—6.0 kg/cm ² , 64—85 psi)	
Pressure regulator	Pressure		245—255 kPa (2.5—2.6 kg/cm ² , 36—37 psi)	
Fuel Tank	Capacity		45 ℓ (11.9 U.S. gal., 9.9 Imp. U.S.gal.)	
Fast idle			M/T 1,000—2,000 min ⁻¹ (rpm) A/T 1,000—2,000 min ⁻¹ (rpm)	
Idle speed	with headlights and cooling fan off	1.5ℓ 1.6ℓ, with CATA 1.6 SOHC without CATA 1.6ℓ DOHC	800 ± 50 min ⁻¹ (rpm) 800 ± 50 min ⁻¹ (rpm) 780 ± 50 min ⁻¹ (rpm) 800 ± 50 min ⁻¹ (rpm)	
Idle CO		With CATA Without CATA	0.1% Max. 1.0 ± 1.0%	

6. Fuel and Emissions (Carbureted Engine)

	MEASUREMENT	STANDARD (NEW)
Fuel pump	Delivery pressure Displacement	6.8—22.6 kPa (0.07—0.23 kg/cm ² , 1.0—3.2 psi) 833.3 cc/minutes in 10 seconds min.
Fuel Tank	Capacity	45 ℓ (11.9 U.S. gal., 9.9 Imp. U.S. gal.)
Fast idle	1.3ℓ PGM-1 Carb (KS,KG only) KQ/except KQ.	2,700—3,700 min ⁻¹ (rpm). 1,350—2,000 min ⁻¹ (rpm)/1,500—2,500 min ⁻¹ (rpm)
Idle speed	with headlights and cooling fan off	M/T 800 ± 50 min ⁻¹ (rpm) : 1.3ℓ PGM-1 Carb (KS,KG only) M/T 750 ± 50 min ⁻¹ (rpm) A/T (except "N" or "P") 700 ± 50 min ⁻¹ (rpm)
Idle CO	KQ/except KQ	0.5% max./1.0% max.

7. Clutch

	MEASUREMENT	STANDARD (NEW)	SERVICE LIMIT
Clutch pedal	Pedal height	213 (8.39) to floor	—
	2D H/B, 4D LHD	208 (8.19) to floor	—
	RHD	210 (8.27) to floor	—
	4D H/B	205 (8.07) to floor	—
	LHD	140—150 (5.5—5.9)	—
	RHD	135—145 (5.3—5.7)	—
Stroke	LHD	15—20 (0.59—0.79)	—
	RHD	70 (2.76) min. to floor	—
	2D H/B, 4D LHD	62 (2.44) min. to floor	—
	RHD	61 (2.40) min. to floor	—
Pedal play	LHD	52 (2.05) min. to floor	—
	RHD	—	—
Disengagement height	2D H/B, 4D LHD	70 (2.76) min. to floor	—
	RHD	62 (2.44) min. to floor	—
4D H/B	LHD	61 (2.40) min. to floor	—
	RHD	52 (2.05) min. to floor	—
Clutch release arm	Free play at arm	3.0—4.0 (0.12—0.16)	—
Flywheel	Clutch surface runout	0.05 (0.002) max.	0.15 (0.006)
Clutch disc	Rivet head depth	1.3 (0.05) min.	0.2 (0.008)
	Surface runout	0.8 (0.03) max.	1.0 (0.04)
	Radial play in spline at circumference (200φ)	0.1—0.5 (0.004—0.020)	3.4 (0.134)
	Thickness	8.1—8.8 (0.32—0.35)	5.7 (0.224)
Clutch release bearing holder	I.D.	31.00—31.15 (1.220—1.226)	31.2 (1.228)
	2WD	35.040—35.079 (1.3795—1.3811)	35.11 (1.382)
	4WD	0.050—0.239 (0.002—0.009)	0.28 (0.011)
	Holder-to-guide sleeve clearance	0.090—0.168 (0.0035—0.0066)	0.24 (0.009)
Clutch cover	2WD	0.050—0.239 (0.002—0.009)	0.28 (0.011)
	4WD	0.090—0.168 (0.0035—0.0066)	0.24 (0.009)
Clutch cover	Unevenness of diaphragm spring	0.8 (0.03) max.	1.0 (0.04)

8. Manual Transmission (2WD)

	MEASUREMENT	STANDARD (NEW)	SERVICE LIMIT
Transmission oil	Capacity ℓ (US.qt., Imp.qt.)	1.8 (1.9, 1.6) at oil change 1.9 (2.0, 1.7) at assembly	
Mainshaft	End play	0.11—0.18 (0.004—0.007)	Adjust with a shim
	Diameter of ball bearing contact area	25.977—25.990 (1.0227—1.0232)	25.92 (1.020)
	Diameter of third gear contact area	33.984—34.000 (1.3380—1.3386)	33.93 (1.336)
	Diameter of 4th, 5th gear contact area	26.980—26.993 (1.0622—1.0627)	26.93 (1.060)
	Diameter of ball bearing contact area	21.987—22.000 (0.8656—0.8661)	21.93 (0.863)
	Runout	0.02 (0.0008) max.	0.05 (0.002)
Mainshaft third and fourth gears	I.D.	39.009—39.025 (1.5358—1.5364)	39.07 (1.538)
	End play	0.06—0.21 (0.0024—0.0083)	0.33 (0.013)
	3rd	0.06—0.19 (0.0024—0.0075)	0.31 (0.012)
	4th	30.22—30.27 (1.1898—1.1917)	30.15 (1.187)
Mainshaft fifth gear	I.D.	30.12—30.17 (1.1858—1.1878)	30.05 (1.183)
	Thickness	37.009—37.025 (1.4570—1.4577)	37.07 (1.459)
Countershaft	I.D.	0.06—0.19 (0.0024—0.0075)	0.31 (0.012)
	Thickness	28.42—28.47 (1.1189—1.1209)	28.35 (1.116)
Countershaft low gear	End play	0.17—0.38 (0.0067—0.0150)	0.53 (0.021)
	Diameter of needle bearing contact area	30.000—30.015 (1.1811—1.1817)	29.95 (1.179)
	Diameter of ball bearing contact area	24.980—24.993 (0.9835—0.9840)	24.93 (0.981)
	Diameter of low gear contact area	35.984—36.000 (1.4167—1.4173)	35.93 (1.415)
	Runout	0.02 (0.0008) max.	0.05 (0.002)
	Thickness	41.009—41.025 (1.6145—1.6152)	41.07 (1.617)
Countershaft low gear	I.D.	0.03—0.10 (0.0012—0.0039)	0.22 (0.009)
	Thickness	29.41—29.44 (1.1579—1.1591)	29.36 (1.156)

(cont'd)

Standard and Service Limits

8. Manual Transmission (2WD) (cont'd)

	MEASUREMENT	STANDARD (NEW)	SERVICE LIMIT
Countershaft second gear	I.D. End play Thickness	44.009–44.025 (1.7326–1.7333) 0.03–0.11 (0.0012–0.0043) 29.92–29.97 (1.1780–1.1799)	44.07 (1.735) 0.23 (0.009) 29.85 (1.175)
Spacer collar (Countershaft second gear)	I.D. O.D. Length	32.975–32.985 (1.2982–1.2986) 38.989–39.000 (1.5350–1.5354) 30.03–30.06 (1.1823–1.1835)	33.03 (1.300) 38.93 (1.533) 30.01 (1.181)
Spacer collar (Mainshaft fourth and fifth gears)	I.D. O.D. Length	27.002–27.012 (1.0631–1.0635) 33.989–34.000 (1.3381–1.3386) 31.989–32.000 (1.2594–1.2598) 27.43–27.46 (1.0799–1.0811) 23.53–23.56 (0.9264–0.9276)	27.06 (1.065) 33.93 (1.336) 31.93 (1.257) 27.41 (1.079) 23.51 (0.926)
Reverse idler gear	I.D. Gear-to-reverse gear shaft clearance	15.016–15.043 (0.5911–0.5922) 0.032–0.077 (0.0013–0.0030)	15.08 (0.594) 0.14 (0.006)
Synchro ring	Ring-to-gear clearance (ring pushed against gear)	0.73–1.18 (0.029–0.046)	0.4 (0.016)
Shift fork	Shift fork finger thickness Fork-to-synchro sleeve clearance	6.4–6.5 (0.252–0.255) 0.25–0.45 (0.0098–0.0177)	— 0.8 (0.03)
Reverse shift fork	Shift fork paul groove width Fork-to-reverse idler gear clearance Groove width Fork-to-fifth/reverse shift piece pin clearance	12.7–13.0 (0.500–0.512) 0.5–1.1 (0.020–0.043) 7.05–7.25 (0.278–0.285) 0.05–0.35 (0.002–0.014)	— 1.8 (0.071) — 0.5 (0.02)
Shift arm A	Diameter of shift rod contact area Shift arm A-to-shift rod clearance	13.005–13.130 (0.5120–0.5169) 0.005–0.230 (0.0002–0.0091)	— 0.35 (0.0138)
Shift arm B	Diameter of shift arm shaft contact area Shift arm B-to-shift arm shaft clearance Shift arm B-to-shift piece clearance Shift piece diameter of shift fork shaft contact area	13.973–14.000 (0.5501–0.5512) 0.013–0.070 (0.0005–0.0028) 0.2–0.5 (0.0079–0.0197) 12.9–13.0 (0.5079–0.5118)	— 0.16 (0.0063) 0.62 (0.0244) 12.78 (0.5031)
Ring gear	Backlash	0.070–0.130 (0.0028–0.0051)	0.18 (0.007)
Differential carrier	Pinionshaft bore diameter Carrier-to-pinionshaft clearance Driveshaft bore diameter Carrier-to-driveshaft clearance Carrier-to-intermediate shaft clearance Side clearance	18.000–18.018 (0.7087–0.7094) 0.017–0.047 (0.0007–0.0019) 26.025–26.045 (1.0246–1.0254) 0.045–0.086 (0.0017–0.0034) 0.075–0.111 (0.0030–0.0044) 0.15 max.	— 0.095 (0.004) — 0.14 (0.006) 0.16 (0.006)
Differential pinion gear	Backlash Pinion gear bore diameter Pinion gear-to-pinionshaft clearance	0.05–0.15 (0.002–0.006) 18.042–18.066 (0.7103–0.7113) 0.059–0.095 (0.0023–0.0037)	Adjust with a washer — 0.15 (0.006)

8. Manual Transmission (4WD)

	MEASUREMENT	STANDARD (NEW)	SERVICE LIMIT
Transmission oil	Capacity ℓ (US. qt., Imp. qt.)	2.4 (2.5, 2.1) at assembly 2.3 (2.4, 2.0) at oil change	
Mainshaft	End play Diameter of needle bearing contact area Diameter of 3rd gear contact area Diameter of 63/28C ball bearing contact area Diameter of 6306/25 ball bearing contact area Runout	0.08–0.15 (0.0031–0.0059) 27.987–28.000 (1.1018–1.1024) 34.984–35.000 (1.3773–1.3780) 27.977–27.990 (1.100–1.102) 24.987–25.000 (0.9837–0.9843) 0.02 (0.0008) max.	Adjust with a shim 27.93 (1.100) 34.93 (1.375) 27.92 (1.099) 24.93 (0.981) 0.05 (0.002)
Main 3rd gear	I.D. End play Thickness	40.009–40.025 (1.5752–1.5758) 0.06–0.21 (0.002–0.008) 32.42–32.47 (1.276–1.278)	40.07 (1.578) 0.3 (0.01) 32.3 (1.27)
Main 4th gear	I.D. End play Thickness	40.009–40.025 (1.5752–1.5758) 0.06–0.21 (0.002–0.008) 30.92–30.97 (1.217–1.219)	40.07 (1.578) 0.3 (0.01) 30.8 (1.21)
Main 5th gear	I.D. End play Thickness	40.009–40.025 (1.5752–1.5758) 0.06–0.21 (0.002–0.008) 30.42–30.47 (1.198–1.200)	40.07 (1.578) 0.3 (0.01) 30.3 (1.19)
Countershaft	End play Diameter of needle bearing contact area Diameter of ball bearing contact area Diameter of SL3 gear contact area Runout	0.05–0.30 (0.002–0.012) 29.000–29.015 (1.1417–1.1423) 24.987–25.000 (0.9837–0.9843) 30.464–30.480 (1.1994–1.2000) 0.02 (0.0008) max.	0.5 (0.02) 28.94 (1.139) 24.93 (0.981) 30.41 (1.197) 0.05 (0.002)
Counter 1st gear	I.D. End play Thickness	50.009–50.025 (1.9689–1.9695) 0.03–0.08 (0.001–0.003) 32.95–33.00 (1.297–1.299)	50.07 (1.971) 0.18 (0.007) 32.83 (1.293)

8. Manual Transmission (4WD)

	MEASUREMENT	STANDARD (NEW)	SERVICE LIMIT
Counter 2nd gear	I.D. End play Thickness	50.009–50.025 (1.9689–1.9695) 0.03–0.08 (0.001–0.003) 32.92–32.97 (1.296–1.298)	50.07 (1.971) 0.18 (0.007) 32.8 (1.29)
Main 4th gear & 5th gear distance collar	I.D. O.D. Width	28.002–28.012 (1.1024–1.1028) 34.989–35.000 (1.3775–1.3780) 26.03–26.08 (1.025–1.027)	28.06 (1.105) 34.93 (1.375) 26.01 (1.024)
Countershaft 2nd gear distance collar	I.D. O.D. Width	36.48–36.49 (1.436–1.437) 43.989–44.000 (1.7318–1.7323) 28.98–29.05 (1.140–1.144)	36.54 (1.439) 43.93 (1.730) Adjust with a collar
Reverse idle gear	I.D. Gear-to-shaft clearance	20.016–20.043 (0.7880–0.7890) 0.036–0.084 (0.0014–0.0033)	20.08 (0.791) 0.14 (0.006)
SL 1 shaft	Clearance of needle bearing contact area	23.984–23.993 (0.9443–0.9446)	23.93 (0.942)
SL 1 gear	I.D. Thickness	30.000–30.013 (1.1811–1.1816) 62.95–63.00 (2.478–2.480)	29.94 (1.179) 62.83 (2.474)
SL2 shaft	End play Diameter of needle bearing contact area Diameter of ball bearing contact area 62/28 (Clutch housing side) 6204U (Transmission housing side) Runout	0.07–0.20 (0.0028–0.0079) 22.987–23.000 (0.9050–0.9055) 27.987–28.000 (1.1018–1.1024) 19.987–20.000 (0.7869–0.7874) 0.02 (0.0008) max.	Adjust with a shim 22.93 (0.903) 27.93 (1.100) 19.93 (0.785) 0.05 (0.002)
SL2 gear	I.D. End play Thickness	37.009–37.025 (1.4570–1.4577) 0.03–0.16 (0.001–0.006) 34.42–34.47 (1.355–1.357)	37.07 (1.459) 0.24 (0.009) 34.3 (1.35)
SL3 gear	Diameter of needle bearing contact area Width of needle bearing contact area	43.984–44.000 (1.7318–1.7323) 31.03–31.08 (1.222–1.224)	43.93 (1.730) 31.01 (1.221)
SL2 gear distance collar	I.D. O.D. Width	23.000–23.013 (0.9055–0.9060) 31.989–32.000 (1.2594–1.2598) 31.00–31.03 (1.220–1.222)	23.060 (0.9079) 31.93 (1.257) 30.98 (1.220)
Transfer shaft	Diameter of needle bearing contact area Diameter of taper bearing contact area Width of transfer driven gear contact area Width of transfer drive bevel gear contact area Runout	27.987–28.000 (1.1018–1.1024) 16.989–17.000 (0.6689–0.6693) 45.01–45.05 (1.772–1.774) 35.002–35.018 (1.3780–1.3787) 0.02 (0.0008) max.	27.93 (1.100) 16.93 (0.6665) 45.17 (1.778) 34.95 (1.376) 0.05 (0.002)
Transfer driven gear	I.D. Diameter of needle bearing contact area End play Thickness	34.009–34.025 (1.3389–1.3396) 54.000–54.015 (2.1260–2.1266) 0.04–0.13 (0.002–0.005) 44.92–44.97 (1.769–1.770)	34.07 (1.341) 53.94 (2.124) 0.21 (0.008) 44.8 (1.76)
Transfer drive bevel gear	I.D. Diameter of taper bearing contact area	25.000–25.021 (0.9843–0.9851) 35.002–35.018 (1.3780–1.3787)	25.06 (0.987) 34.95 (1.376)
Transfer driven bevel gear	Backlash Diameter of taper bearing contact area Inner driven gear bearing race Outer driven gear bearing race	0.10–0.15 (0.004–0.006) 35.002–35.018 (1.3780–1.3787) 27.987–28.000 (1.1018–1.1024)	Adjust with a shim 34.95 (1.376) 27.93 (1.100)
Blocking ring	Ring-to-gear clearance	0.85–1.1 (0.033–0.043)	0.4 (0.02)
1–2 shift fork & 3–4 shift fork	Synchro sleeve groove width Shift fork-to-synchro sleeve clearance Thrust Radial Forkshaft-to-shift fork clearance	7.95–8.05 (0.313–0.317) 0.45–0.65 (0.018–0.026) 0.05–0.45 (0.002–0.018) 0.040–0.138 (0.0016–0.0054)	— 1.0 (0.04) 0.8 (0.03) —
5th shift fork	Synchro sleeve groove width Shift fork-to-synchro sleeve clearance Thrust Radial Fork shaft-to-shift fork clearance 5–R shift fork shaft 1–2 shift fork shaft	5.75–5.85 (0.226–0.230) 0.25–0.45 (0.010–0.018) 0.05–0.45 (0.002–0.018) 0.005–0.070 (0.0002–0.0028) 0.440–0.670 (0.0173–0.0264)	— 0.8 (0.03) 0.8 (0.03) — —
Reverse shift fork	Nail width Shift fork-to-reverse idle gear clearance L-groove width Shift fork-to-5-R shift piece clearance	13.0–13.3 (0.51–0.52) 0.5–1.1 (0.02–0.04) 7.05–7.25 (0.278–0.285) 0.05–0.35 (0.002–0.014)	— 1.8 (0.07) — 0.5 (0.02)

(cont'd)

Standard and Service Limits

8. Manual Transmission (4WD) (cont'd)

	MEASUREMENT	STANDARD (NEW)	SERVICE LIMIT
Shift arm A	Diameter of shift piece contact area Shift arm-to-shift piece clearance Shift arm-to-interlock clearance I.D. Shift arm-to-shaft clearance	12.9—13.0 (0.508—0.512) 0.2—0.5 (0.01—0.02) 16.000—16.068 (0.6299—0.6326) 0.011—0.092 (0.0004—0.0036)	— 0.7 (0.03) — —
Shift arm	Diameter of shift arm A contact area Shift arm-to-shift arm A clearance	11.9—12.0 (0.469—0.472) 0.05—0.25 (0.002—0.010)	— 0.5 (0.02)
Select arm	Diameter of shift arm A contact area Select arm-to-shift arm A clearance	7.95—8.00 (0.313—0.315) 0.10—0.25 (0.004—0.010)	— 0.5 (0.02)
SL shift fork	Synchro sleeve groove width Shift fork-to-synchro sleeve clearance Thrust Radial	5.75—5.85 (0.226—0.230) 0.25—0.45 (0.010—0.018) 0.05—0.45 (0.002—0.018)	— 0.8 (0.03) 0.8 (0.03)
SL shift piece A	Shift piece-to-fork shaft clearance Diameter of SL shift lever contact area Shift piece-to-SL shift lever clearance	0.040—0.138 (0.0016—0.0054) 10.1—10.2 (0.398—0.402) 0.1—0.3 (0.004—0.012)	— — —
SL shift piece B	Diameter of SL shift lever contact area Shift piece-to-SL shift lever clearance	7.9—8.0 (0.311—0.315) 0.05—0.25 (0.002—0.010)	— 0.5 (0.02)
Selector fork	Sleeve groove width Fork-to-sleeve clearance Thrust Radial	8.45—8.55 (0.333—0.337) 0.45—0.65 (0.018—0.026) 0.2—1.1 (0.01—0.04)	— 1.0 (0.04) 1.5 (0.06)
Ring gear	Backlash	0.071—0.129 (0.0028—0.0051)	—
Differential carrier	Pinion shaft bore diameter Carrier-to-pinion shaft clearance Driveshaft bore diameter Carrier-to-driveshaft clearance Ball bearing bore diameter	18.000—18.018 (0.7087—0.7094) 0.016—0.052 (0.0006—0.0020) 28.005—28.025 (1.1026—1.1033) 0.025—0.066 (0.0010—0.0026) 40.002—40.018 (1.5749—1.5755)	— 0.12 (0.005) — 0.12 (0.005) —
Differential pinion gear	Backlash Pinion gear bore diameter Pinion gear-to-pinion shaft clearance	0.05—0.15 (0.002—0.006) 18.042—18.066 (0.710—0.713) 0.057—0.095 (0.0022—0.0037)	Adjust with a washer — 0.15 (0.006)

9. Automatic Transmission (2 WD)

	MEASUREMENT		STANDARD (NEW)	SERVICE LIMIT
Transmission oil	Capacity ℓ (U.S. qt., Imp. qt.)		2.4 (2.5, 2.1) at oil change 5.4 (5.7, 4.8) at assembly	
Hydraulic pressure	Line pressure at 2,000 min ⁻¹ (rpm)	1.2 ℓ	735—785 kPa (7.5—8.0 kg/cm ² , 107—114 psi)	686 kPa (7.0 kg/cm ² , 100 psi)
		others	785—834 kPa (8.0—8.5 kg/cm ² , 114—121 psi)	736 kPa (7.5 kg/cm ² , 107 psi)
	2nd, 3rd, 4th clutch pressure at 2,000 rpm in ② and ③		412 kPa (4.2 kg/cm ² , 60 psi) Throttle control lever full closed 785—834 kPa (8.0—8.5 kg/cm ² , 114—121 psi) Throttle control lever opened 2/8 or more	363 kPa (3.7 kg/cm ² , 53 psi) (closed) 736 kPa (7.5 kg/cm ² , 107 psi) (2/8 opened)
	2nd clutch pressure at 2,000 min ⁻¹ (rpm) in ②	1.2 ℓ	735—785 kPa (7.5—8.0 kg/cm ² , 107—114 psi)	686 kPa (7.0 kg/cm ² , 100 psi)
	1st clutch pressure at 2,000 min ⁻¹ (rpm)	others	785—834 kPa (8.0—8.5 kg/cm ² , 114—121 psi)	736 kPa (7.5 kg/cm ² , 107 psi)
	Governor pressure at 60 km/h (37.5 mph)	1.5 ℓ PGM-FI except KG	206—216 kPa (2.10—2.20 kg/cm ² , 30—31 psi)	201 kPa (2.05 kg/cm ² , 29 psi)
		1.5 ℓ PGM-FI KG	223—232 Kpa (2.27—237 kg/cm ² , 32—34 psi)	218 Kpa (2.22 kg/cm ² , 32 psi)
		others	151—162 kPa (1.54—1.64 kg/cm ² , 22—23 psi)	146 kPa (1.49 kg/cm ² , 21 psi)
Throttle pressure B	Full closed		0	—
	Full opened 1.2 ℓ		735—785 kPa (7.5—8.0 kg/cm ² , 107—114 psi) 785—834 kPa (8.0—8.5 kg/cm ² , 114—121 psi)	686 kPa (7.0 kg/cm ² , 100 psi) 736 kPa (7.5 kg/cm ² , 107 psi)
Throttle pressure A	Full closed		0—4.9 kPa (0—0.05 kg/cm ² , 0—0.7 psi)	—
	Full opened 1.5 ℓ KG (4 D, 4 D H/B) others		456—471 (4.65—4.8 kg/cm ² , 66—68 psi) 505—520 kPa (5.15—5.30 kg/cm ² , 73—75 psi)	451 kPa (4.6 kg/cm ² , 65 psi) 500 kPa (5.1 kg/cm ² , 73 psi)

(cont'd)

Standard and Service Limits

9. Automatic Transmission (2 WD)(cont'd)

	MEASUREMENT	STANDARD (NEW)	SERVICE LIMIT
Stall speed		2,300–2,900 min ⁻¹ (rpm)	—
Clutch	Clutch initial clearance	1st 0.65–0.85 (0.026–0.033) 2nd 0.65–0.85 (0.026–0.033) 3rd, 4th 0.40–0.60 (0.016–0.024)	— — —
	Clutch return spring free length	1st 31.0 (1.22) Except 1st 30.5 (1.20)	29.0 (1.14) 28.5 (1.12)
	Clutch disc thickness	1.88–2.00 (0.074–0.079)	Until grooves worn out
	Clutch plate thickness	1st 1.55–1.65 (0.061–0.065)	Discoloration
	Clutch plate thickness	Except 1st 1.95–2.05 (0.077–0.079)	
	Clutch end plate thickness	Mark 1 2.3–2.4 (0.091–0.094)	
	(1.6ℓ, 1.5ℓ PGM-FI and	Mark 2 2.4–2.5 (0.094–0.098)	
	1.5ℓ 2-Carbureted engine)	Mark 3 2.5–2.6 (0.098–0.102)	
		Mark 4 2.6–2.7 (0.102–0.106)	
		Mark 5 2.7–2.8 (0.106–0.110)	
		Mark 6 2.8–2.9 (0.110–0.114)	
		Mark 7 2.9–3.0 (0.114–0.118)	
		Mark 8 3.0–3.1 (0.118–0.122)	
		Mark 9 3.1–3.2 (0.122–0.126)	
		Mark 10 3.2–3.3 (0.126–0.130)	
	Clutch end plate thickness	Mark 1 2.2–2.3 (0.087–0.091)	
	(1.2ℓ, 1.3ℓ, 1.4ℓ	Mark 2 2.5–2.6 (0.098–0.102)	
	and 1.5ℓ 1-Carbureted	Mark 3 2.8–2.9 (0.110–0.114)	
	engine)	Mark 4 3.1–3.2 (0.122–0.126)	
		Mark 5 3.4–3.5 (0.134–0.138)	
Transmission		Mark 11 2.05–2.15 (0.081–0.085)	
		Mark 12 2.35–2.45 (0.093–0.096)	
		Mark 13 2.65–2.75 (0.104–0.108)	
		Mark 14 2.95–3.05 (0.116–0.120)	
		Mark 15 3.25–3.35 (0.128–0.132)	Discoloration
	Diameter of needle bearing contact area on main and stator shaft	19.980–19.993 (0.7866–0.7871)	Wear or damage
	Diameter of needle bearing contact area on mainshaft 2nd gear	35.975–35.991 (1.4163–1.4169)	
	Diameter of needle bearing contact area on mainshaft 4th gear collar	31.975–31.991 (1.2588–1.2594)	
	Diameter of needle bearing contact area on mainshaft 1st gear collar	27.975–27.995 (1.1014–1.1022)	
	Diameter of needle bearing contact area on countershaft (L side)	36.004–36.017 (1.4175–1.4180)	
	Diameter of needle bearing contact area on countershaft 3rd gear	31.975–31.991 (1.2589–1.2595)	
	Diameter of needle bearing contact area on countershaft 4th gear	27.980–27.993 (1.1016–1.1021)	
	Diameter of needle bearing contact area on countershaft reverse gear collar	29.980–29.993 (1.1803–1.1808)	
	Diameter of needle bearing contact area on countershaft 1st gear collar	29.980–29.993 (1.1803–1.1808)	
	Diameter of needle bearing contact area on reverse idle gear	13.990–14.000 (0.5508–0.5512)	
	Mainshaft 2nd gear I.D.	41.000–41.016 (1.6142–1.6148)	
	Mainshaft 1st gear I.D.	33.000–33.016 (1.2992–1.2998)	
	Mainshaft 4th gear I.D.	38.000–38.016 (1.4961–1.4967)	
	Countershaft 4th gear I.D.	33.000–33.016 (1.2992–1.2998)	
	Countershaft 3rd gear I.D.	38.000–38.016 (1.4961–1.4967)	
	Countershaft 1st gear I.D.	35.000–35.016 (1.3780–1.3786)	
	Countershaft reverse gear I.D.	36.000–36.016 (1.4173–1.4179)	
	Reverse idle gear I.D.	18.007–18.020 (0.7089–0.7094)	
	Reverse idler shaft holder I.D.	14.416–14.434 (0.5676–0.5683)	Wear or damage
	Mainshaft 4th gear end play	0.10–0.22 (0.0039–0.0087)	—
	Mainshaft 2nd gear end play	0.07–0.15 (0.0028–0.0059)	—
	Mainshaft 1st gear end play	0.08–0.24 (0.0031–0.0094)	—
	Countershaft 4th gear end play	0.07–0.15 (0.0028–0.0059)	—
	Countershaft 3rd gear end play	0.07–0.15 (0.0028–0.0059)	—
	Countershaft 1st gear end play	0.10–0.45 (0.0039–0.0177)	—
	Reverse idler gear end play	0.05–0.18 (0.0020–0.0071)	—
	Countershaft reverse gear play	0.10–0.45 (0.0039–0.0177)	—
	Selector hub O.D.	51.87–51.90 (2.0421–2.0433)	Wear or damage

9. Automatic Transmission (2 WD)

	MEASUREMENT	STANDARD (NEW)	SERVICE LIMIT
Transmission (cont'd)	Thrust washer thickness		
	Mainshaft 2nd gear A	3.47—3.50 (0.1366—0.1378)	Wear or damage
	B	3.52—3.55 (0.1386—0.1398)	
	C	3.57—3.60 (0.1406—0.1417)	
	D	3.62—3.65 (0.1425—0.1437)	
	E	3.67—3.70 (0.1445—0.1457)	
	F	3.72—3.75 (0.1465—0.1476)	
	G	3.77—3.80 (0.1484—0.1496)	
	H	3.82—3.85 (0.1504—0.1516)	
	I	3.87—3.90 (0.1524—0.1535)	
	Mainshaft L side bearing	2.95—3.05 (0.1161—0.1201)	
	Mainshaft 4th gear	4.45—4.55 (0.1752—0.1791)	Wear or damage
	Mainshaft R side 1st gear	2.43—2.50 (0.0957—0.0984)	
	Mainshaft L side 1st gear	1.45—1.50 (0.0571—0.0591)	
	Countershaft 3rd gear A	2.97—3.00 (0.1169—0.1181)	
	B	3.02—3.05 (0.1189—0.1201)	
	C	3.07—3.10 (0.1209—0.1220)	
	D	3.12—3.15 (0.1228—0.1240)	
	E	3.17—3.20 (0.1248—0.1260)	
	F	3.22—3.25 (0.1268—0.1280)	
	G	3.27—3.30 (0.1287—0.1299)	
	H	3.32—3.35 (0.1307—0.1319)	
	I	3.37—3.40 (0.1327—0.1339)	
	Countershaft distance collar length	38.97—39.00 (1.5342—1.5354)	Wear or damage
		39.02—39.05 (1.5362—1.5374)	
		39.07—39.10 (1.5382—1.5394)	
		39.12—39.15 (1.5402—1.5413)	
		39.17—39.20 (1.5421—1.5433)	
		39.22—39.25 (1.5441—1.5453)	
		39.27—39.30 (1.5461—1.5472)	
		40.00—40.05 (1.5748—1.5768)	
		25.00—25.15 (0.9843—0.9902)	
		2.5—2.6 (0.098—0.102)	
	Mainshaft 4th gear collar length	14.50—14.55 (0.5709—0.5728)	Wear or damage
	Mainshaft 1st gear collar length	2.45—2.55 (0.0965—0.1004)	
	Mainshaft 1st gear collar flange thickness	14.50—14.55 (0.5709—0.5728)	Wear or damage
	Countershaft reverse gear collar flange thickness	2.45—2.55 (0.0965—0.1004)	
	Countershaft 1st gear collar length	14.50—14.55 (0.5709—0.5728)	Wear or damage
	Countershaft 1st gear collar flange thickness	2.45—2.55 (0.0965—0.1004)	
	Diameter of countershaft one-way clutch contact area	74.414—74.440 (2.9297—2.9307)	Wear or damage
	Diameter of parking gear one-way clutch contact area	57.755—57.768 (2.2738—2.2743)	
	Mainshaft feed pipe A O.D. (at 15 mm from end)	8.97—8.98 (0.353—0.354)	Wear or damage
	Mainshaft feed pipe B O.D. (at 12 mm from end)	5.97—5.98 (0.2351—0.2354)	
	Countershaft feed pipe O.D. (at 20 mm from end)	7.97—7.98 (0.3138—0.3142)	7.95 (0.3130)
	Mainshaft sealing ring 32 mm thickness	1.980—1.995 (0.0780—0.0785)	
	Mainshaft bushing I.D.	6.018—6.030 (0.2369—0.2374)	1.800 (0.0709)
	Mainshaft bushing I.D.	9.000—9.015 (0.3543—0.3549)	6.045 (0.2380)
	Countershaft bushing I.D.	8.000—8.015 (0.3150—0.3156)	9.030 (0.3555)
	Mainshaft sealing ring groove width	2.025—2.060 (0.0797—0.0811)	8.030 (0.3161)
	Statorshaft distance collar 20 mm I.D.	26.000—26.013 (1.0236—1.0241)	2.080 (0.0819)
			26.030 (1.0248)
Regulator valve body	Sealing ring contact area diameter	32.000—32.025 (1.2598—1.2608)	32.050 (1.2618)
Shifting device and parking brake control	Reverse shift fork thickness	5.90—6.00 (0.2323—0.2362)	5.40 (0.2126)
	Parking brake ratchet pawl	—	Wear or other defect
	Throttle cam stopper	18.5—18.6 (0.728—0.732)	Wear or other defect
Servo body	Shift fork shaft bore I.D. A	14.000—14.005 (0.5512—0.5514)	—
	B	14.006—14.010 (0.5514—0.5516)	—
	C	14.011—14.015 (0.5516—0.5518)	—
	Shift fork shaft valve bore I.D.	37.000—37.039 (1.4567—1.4582)	37.045 (1.4585)
Valve body	Oil pump gear side clearance	0.03—0.05 (0.0012—0.0020)	0.07 (0.0028)
	Oil pump gear-to-body clearance	Drive: 0.240—0.266 (0.0094—0.0105)	—
		Driven: 0.063—0.088 (0.0025—0.0035)	—
	Stator camshaft needle bearing bore I.D. (R side)	26.000—26.013 (1.0236—1.0241)	Wear or damage
	Stator camshaft needle bearing contact and I.D. (Stator side)	24.000—24.021 (0.9449—0.9457)	Wear or damage
	Oil pump driven gear I.D.	14.016—14.034 (0.5518—0.5525)	Wear or damage
	Oil pump shaft O.D.	13.980—13.990 (0.5504—0.5508)	Wear or damage

(cont'd)

Standards and Service Limits

9. Automatic Transmission (2 WD)(cont'd)

Springs	MEASUREMENT		STANDARD (NEW)			
			Wire Diameter	O.D.	Free Length	No. of Coils
Regulator valve spring A	1.2 ℓ		1.8 (0.07)	14.7 (0.58)	83.8 (3.30)	17
	others		1.58 x 2.00 (0.06 x 0.08)	14.7 (0.58)	86.5 (3.41)	20.9
Regulator valve spring B	1.2 ℓ		1.8 (0.07)	9.6 (0.38)	44 (1.73)	9
	others		1.8 (0.07)	9.6 (0.38)	44 (1.73)	7.5
Stator reaction spring			6 (0.24)	38.4 (1.51)	30.3 (1.20)	2
Throttle modulator spring	*1		1.2 (0.05)	9.4 (0.37)	{ 27.2 (1.07) 26.3 (1.04) }	8
	*2		1.2 (0.05)	9.4 (0.37)	{ 26.3 (1.04) 26.4 (1.04) }	8
Torque converter check valve spring			1.1 (0.04)	8.4 (0.33)	36.4 (1.43)	12
Cooler releaf valve spring			1.1 (0.04)	8.4 (0.33)	36.4 (1.43)	12
Releaf valve spring			1.0 (0.04)	8.4 (0.33)	52 (2.05)	23
Governor spring A	*3		1.0 (0.04)	18.8 (0.74)	38.1 (1.50)	4
	*4		1.0 (0.04)	18.8 (0.74)	20.4 (0.80)	4
Governor spring B	*3		0.9 (0.04)	11.8 (0.46)	27.8 (1.09)	6
	*4		0.9 (0.04)	11.8 (0.46)	26.7 (1.05)	6
2nd orifice control spring			0.8 (0.03)	6.6 (0.26)	43.8 (1.72)	27.6
Servo orifice control spring			0.9 (0.04)	6.1 (0.24)	35.9 (1.41)	20
Throttle spring A			1.0 (0.04)	8.5 (0.33)	22.2 (0.87)	6
					22.1 (0.87)	5.5
Throttle adjust spring A (throttle B pressure)			0.8 (0.03)	6.2 (0.24)	30 (1.18)	8
Throttle adjust spring A			0.8 (0.03)	6.2 (0.24)	27 (1.06)	8.5
Throttle spring B			1.6 (0.06)	8.5 (0.33)	41.3 (1.63)	13.9
			1.4 (0.06)	8.5 (0.33)	41.4 (1.63)	8.4
1—2 shift spring	*3		0.5 (0.02)	4.4 (0.17)	47.2 (1.86)	38
	*2		0.5 (0.02)	4.5 (0.18)	42.5 (1.67)	21.1
	*5		0.5 (0.02)	4.5 (0.18)	44.5 (1.75)	35.1
1—2 shift ball spring	Main *3		0.45 (0.02)	4.5 (0.18)	12.7 (0.50)	11
	*2		0.4 (0.02)	4.5 (0.18)	14.4 (0.57)	8.2
	*5		0.4 (0.02)	4.5 (0.18)	11.3 (0.44)	8
2—3 shift spring	2nd *3		0.45 (0.02)	4.5 (0.18)	12.7 (0.50)	11
	*3		0.9 (0.04)	7.6 (0.23)	44.6 (1.76)	20.7
	*2		0.7 (0.03)	7.6 (0.23)	48 (1.89)	12.7
2—3 shift ball spring	*5		0.7 (0.03)	7.6 (0.23)	43 (1.69)	12.7
	*3		0.4 (0.02)	4.5 (0.18)	14.4 (0.57)	8.2
	*5		0.4 (0.02)	4.5 (0.18)	14.7 (0.58)	7.3
3—4 shift spring	*2		0.45 (0.02)	4.5 (0.18)	17.1 (0.67)	11.1
	*3		0.9 (0.04)	9.6 (0.38)	32.5 (1.28)	10
	*2		0.9 (0.04)	9.6 (0.38)	27 (1.06)	10
3—4 shift ball spring	*5		0.7 (0.03)	9.6 (0.38)	32.9 (1.30)	6.4
	*3		0.5 (0.02)	4.5 (0.18)	11.3 (0.44)	7
	*2		0.5 (0.02)	4.5 (0.18)	10.8 (0.43)	7.4
	*5		0.45 (0.02)	4.5 (0.18)	12.0 (0.47)	6.7
Low accumulator spring A			2.34 x 2.9 (0.09 x 0.1)	21.5 (0.85)	66.7 (2.63)	10.2
Low accumulator spring B			2.8 (0.11)	13.1 (0.52)	40 (1.57)	8.8
Top accumulator spring			3.2 (0.13)	18.6 (0.73)	78.3 (3.08)	10
2nd accumulator spring			3.5 (0.14)	20.2 (0.80)	76.7 (3.02)	9.6
3rd accumulator spring			2.7 (0.10)	15.5 (0.61)	80.0 (3.15)	14.8
L/C shift spring	*6		1.1 (0.04)	8.1 (0.32)	51.8 (2.04)	22.3
L/C shift spring	*4		0.7 (0.03)	8.1 (0.32)	39.0 (1.54)	15.4
	*8		0.9 (0.04)	8.1 (0.32)	44.5 (1.75)	18.3
L/C timing spring B	*3		1.0 (0.04)	6.6 (0.26)	55.6 (2.19)	30
	*4		1.0 (0.04)	6.6 (0.26)	52.3 (2.06)	30.1
L/C control valve spring	*6		0.7 (0.03)	6.6 (0.26)	35.3 (1.39)	15.8
	*7		0.7 (0.03)	6.6 (0.26)	32.5 (1.28)	14
CPC valve spring			1.4 (0.06)	9.4 (0.37)	31.6 (1.24)	10.9

*1 : except KG 1.5 ℓ (4 D, 4 D H/B) *2 : KG 1.5 ℓ (4 D, 4 D H/B)

*3 : KX, KS, KZ, KQ, KG (1.5 ℓ) *4 : except KX, KS, KZ, KQ, KG (1.5 ℓ) *5 : except KX, KS, KZ, KG 1.5 ℓ (4 D, 4 D H/B)

*6 : KX, KS, KZ, KG (1.5 ℓ) *7 : except KX, KS, KZ, KG (1.5 ℓ) *8 : KQ

9. Automatic Transmission (2 WD)(cont'd)

	MEASUREMENT	STANDARD (NEW)		SERVICE LIMIT	
		Wire Diameter	O.D.	Free Length	No. of Coils
Springs	Shift timing valve spring	0.9 (0.04)	8.6 (0.34)	42.9 (1.69)	21.4
	Kick down valve spring	0.9 (0.04)	10.1 (0.40)	40.8 (1.61)	14.5
	Reverse control spring	0.7 (0.03)	7.6 (0.30)	37.2 (1.46)	15.3
	L/C cut spring	0.7 (0.03)	7.6 (0.30)	29 (1.14)	18
	3-2 timing valve spring	1.2 (0.05)	7.7 (0.30)	45.1 (1.78)	19.8
	Low oneway ball spring	0.29 (0.01)	4.0 (0.16)	14 (0.55)	13
	4th exhaust spring	0.9 (0.04)	6.1 (0.24)	43.7 (1.72)	20.3
	Servo control valve spring	1.1 (0.04)	6.6 (0.26)	44 (1.73)	20
	Reverse timing spring	0.7 (0.03)	5.6 (0.22)	43.8 (1.72)	21.7
Ring gear	Backlash	0.086-0.143 (0.0034-0.0056)		0.25 (0.01)	
Differential carrier	Pinionshaft bore diameter	18.000-18.018 (0.7087-0.7094)		—	
	Carrier-to-pinionshaft clearance	0.017-0.047 (0.0007-0.0019)		0.095 (0.004)	
	Driveshaft bore diameter	26.005-26.025 (1.0238-1.0246)		—	
	Carrier-to-driveshaft clearance	0.045-0.086 (0.0017-0.0034)		0.14 (0.006)	
	Carrier-to-intermediate shaft clearance	0.075-0.111 (0.0030-0.0044)		0.16 (0.006)	
	Side clearance	0.15 max.			
Differential pinion gear	Backlash	0.05-0.15 (0.002-0.006)		Adjust with a washer	
	Pinion gear bore diameter	18.042-18.066 (0.7103-0.7113)		—	
	Pinion gear to pinionshaft clearance	0.059-0.095 (0.0023-0.0037)		0.15 (0.006)	

Standards and Service Limits

9. Automatic Transmission (4 WD)

	MEASUREMENT	STANDARD (NEW)	SERVICE LIMIT
Transmission oil	Capacity ℓ (US qt, Imp qt)	2.7 (2.9 , 2.4) at oil change 5.8 (6.1 , 5.1) at assembly	
Hydraulic pressure	Line pressure at 2,000 rpm	800—850 kPa (8.0—8.5 kg/cm ² , 114—121 psi)	750 kPa (7.5 kg/cm ² , 107 psi)
	2nd, 3rd, 4th clutch pressure at 2,000 rpm in [S] or [D]	500 kPa (5.0 kg/cm ² , 71 psi) Throttle control lever full closed 850 kPa (8.5 kg/cm ² , 121 psi) Throttle control lever opened 3/8 or more	450 kPa (4.5 kg/cm ² , 64 psi) (closed) 750 kPa (7.5 kg/cm ² , 107 psi) (2/8 opened)
	Low hold clutch pressure at 2,000 rpm in [2]	800—850 kPa (8.0—8.5 kg/cm ² , 114—121 psi)	750 kPa (7.5 kg/cm ² , 107 psi)
	1st clutch pressure at 2,000 rpm in [S] or [D]		

Unit: mm (in)

9. Automatic Transmission (4 WD)

	MEASUREMENT		STANDARD (NEW)	SERVICE LIMIT
Hydraulic pressure	Throttle pressure B	Full closed Full opened	0 800—850 kPa (8.0—8.5 kg/cm ² , 114—121 psi)	— 750 kPa (7.5 kg/cm ² , 107 psi)
Stall speed			2,300—2,900 rpm	2,750 rpm
Clutch	Clutch initial clearance	1st	0.65—0.85 (0.026—0.033)	—
		2nd	0.65—0.80 (0.026—0.031)	—
		3rd, 4th	0.40—0.60 (0.016—0.024)	—
	Clutch return spring free length	1st	31.0 (1.22)	29.0 (1.14)
		Except 1st	30.5 (1.20)	28.5 (1.12)
	Clutch disc thickness		1.88—2.0 (0.074—0.08)	Until grooves worn out
	Clutch plate thickness	1st	1.55—1.65 (0.061—0.065)	Discoloration
		Except 1st	1.95—2.05 (0.077—0.081)	
	Clutch end plate thickness Except lowhold clutch	Mark 1	2.3—2.4 (0.09—0.09)	Discoloration
		Mark 2	2.4—2.5 (0.09—0.10)	
		Mark 3	2.5—2.6 (0.10—0.10)	
		Mark 4	2.6—2.7 (0.10—0.11)	
		Mark 5	2.7—2.8 (0.11—0.11)	
		Mark 6	2.8—2.9 (0.11—0.11)	
		Mark 7	2.9—3.0 (0.11—0.12)	
		Mark 8	3.0—3.1 (0.12—0.12)	
		Mark 9	3.1—3.2 (0.12—0.13)	
		Mark 10	3.2—3.3 (0.13—0.13)	
		Mark 11	2.0—2.1 (0.08—0.08)	
		Mark 12	2.1—2.2 (0.08—0.09)	
		Mark 13	2.2—2.3 (0.09—0.09)	
	Low hold clutch	Mark 1	2.05—2.10 (0.081—0.083)	
		Mark 2	2.15—2.20 (0.085—0.087)	
		Mark 3	2.25—2.30 (0.089—0.091)	
		Mark 4	2.35—2.40 (0.093—0.094)	
		Non mark	2.45—2.50 (0.096—0.098)	
		Mark 6	2.55—2.60 (0.100—0.102)	
		Mark 7	2.65—2.70 (0.104—0.106)	
Transmission	Diameter of needle bearing contact area on main shaft and statorshaft		19.980—19.993 (0.7866—0.7871)	Wear or damage
	Diameter of needle bearing contact area on mainshaft 2nd gear		35.975—35.991 (1.4163—1.4170)	
	Diameter of needle bearing contact area on mainshaft 4th gear collar		31.975—31.991 (1.2589—1.2595)	
	Diameter of needle bearing contact area on mainshaft 1st gear collar		30.975—30.995 (1.2195—1.2203)	
	Diameter of needle bearing contact area on countershaft (L side)		36.004—36.017 (1.4175—1.4180)	
	Diameter of needle bearing contact area on countershaft 3rd gear		31.975—31.991 (1.2589—1.2595)	
	Diameter of needle bearing contact area on countershaft 4th gear		27.980—27.993 (1.1016—1.1021)	
	Diameter of needle bearing contact area on countershaft reverse gear collar		29.980—29.993 (1.1803—1.1808)	
	Diameter of needle bearing contact area on countershaft 1st gear collar		31.975—31.991 (1.2589—1.2595)	

(cont'd)

Standards and Service Limits

9. Automatic Transmission (4 WD)(cont'd)

	MEASUREMENT	STANDARD (NEW)	SERVICE LIMIT
Transmission (cont'd)	Diameter of needle bearing contact area on subshaft (L. side)	27.991—28.000 (1.1020—1.1024)	Wear or damage ↑
	Diameter of needle bearing contact area on subshaft S-4 gear collar	29.980—29.993 (1.1803—1.1808)	
	Diameter of needle bearing contact area on reverse idle gear	13.990—14.000 (0.5508—0.5512)	
	Mainshaft 2nd gear I.D.	41.000—41.016 (1.6142—1.6148)	
	Mainshaft 1st gear I.D.	36.000—36.016 (1.4173—1.4179)	
	Mainshaft 4th gear I.D.	38.000—38.016 (1.4961—1.4967)	
	Countershaft 4th gear I.D.	33.000—33.016 (1.2992—1.2998)	
	Countershaft 3rd gear I.D.	38.000—38.016 (1.4961—1.4967)	
	Countershaft 1st gear I.D.	35.000—35.016 (1.3780—1.3786)	
	Countershaft reverse gear I.D.	36.000—36.016 (1.4173—1.4179)	
	Subshaft S-4 gear I.D.	35.000—35.016 (1.3780—1.3786)	Wear or damage ↓
	Reverse idle gear I.D.	18.007—18.020 (0.7089—0.7094)	
	Reverse idler shaft holder I.D.	14.416—14.434 (0.5676—0.5683)	
	Mainshaft 4th gear end play	0—0.08 (0.003)	
	Mainshaft 2nd gear end play	0.07—0.15 (0.003—0.006)	
	Mainshaft 1st gear end play	0.08—0.24 (0.003—0.009)	
	Countershaft 4th gear end play	0.07—0.15 (0.003—0.006)	
	Countershaft 3rd gear end play	0.07—0.15 (0.003—0.006)	
	Countershaft 1st gear end play	0.10—0.45 (0.004—0.018)	
	Reverse idler gear end play	0.05—0.18 (0.002—0.007)	
	Countershaft reverse gear play	0.10—0.45 (0.004—0.018)	Wear or damage ↑
	Selector hub O.D.	51.87—51.90 (2.042—2.043)	
	Thrust washer thickness		
	Mainshaft 2nd gear A	3.47—3.50 (0.137—0.138)	
	B	3.52—3.55 (0.139—0.140)	
	C	3.57—3.60 (0.141—0.142)	
	D	3.62—3.65 (0.143—0.144)	
	E	3.67—3.70 (0.144—0.146)	
	F	3.72—3.75 (0.146—0.148)	
	G	3.77—3.80 (0.148—0.150)	
	H	3.82—3.85 (0.150—0.152)	Wear or damage ↓
	I	3.87—3.90 (0.152—0.154)	
	Mainshaft L side bearing	2.95—3.05 (0.116—0.120)	
	Mainshaft 4th gear	4.45—4.55 (0.175—0.179)	
	Mainshaft R side 1st gear	2.43—2.50 (0.096—0.098)	
	Mainshaft L side 1st gear	1.45—1.50 (0.057—0.059)	
	Countershaft 3rd gear A	2.97—3.00 (0.117—0.118)	
	B	3.02—3.05 (0.119—0.120)	
	C	3.07—3.10 (0.121—0.122)	
	D	3.12—3.15 (0.123—0.124)	
	E	3.17—3.20 (0.125—0.126)	Wear or damage ↑
	F	3.22—3.25 (0.127—0.128)	
	G	3.27—3.30 (0.129—0.130)	
	H	3.32—3.35 (0.131—0.132)	
	I	3.37—3.40 (0.133—0.134)	
	Countershaft distance collar length	38.97—39.00 (1.534—1.535)	
		39.02—39.05 (1.536—1.537)	
		39.07—39.10 (1.538—1.539)	
		39.12—39.15 (1.540—1.541)	
		39.17—39.20 (1.542—1.543)	
		39.22—39.25 (1.544—1.545)	
		39.27—39.30 (1.546—1.547)	
	Mainshaft 4th gear collar length	46.50—46.53 (1.831—1.832)	
	Mainshaft 1st gear collar length	24.50—24.55 (0.965—0.967)	
	Mainshaft 1st gear collar flange thickness	2.5—2.6 (0.10—0.10)	Wear or damage

Unit: mm (in)

Automatic Transmission (4WD) — Section 14

	MEASUREMENT	STANDARD (NEW)	SERVICE LIMIT
Transmission (cont'd)	Countershaft reverse gear collar length	14.50—14.55 (0.571—0.573)	—
	Countershaft reverse gear collar flange thickness	2.45—2.55 (0.096—0.100)	Wear or damage
	Countershaft 1st gear collar length	14.50—14.55 (0.571—0.573)	—
	Countershaft 1st gear collar flange thickness	2.45—2.55 (0.096—0.100)	Wear or damage
	Subshaft S-4 gear collar length	24.000—24.100 (0.9449—0.9488)	Wear or damage
	Length of needle bearing contact area on subshaft S-4 gear collar	21.000—21.100 (0.8268—0.8307)	Wear or damage
	Diameter of countershaft one-way clutch contact area	83.339—83.365 (3.2811—3.2821)	Wear or damage
	Diameter of parking gear one-way clutch contact area	66.685—66.698 (2.6254—2.6259)	Wear or damage
	Mainshaft feed pipe A O.D. (at 15 mm from end)	8.970—8.980 (0.3531—0.3535)	8.950 (0.3524)
	Mainshaft feed pipe B O.D. (at 12 mm from end)	5.970—5.980 (0.2350—0.2354)	5.950 (0.2343)
	Countershaft feed pipe O.D. (at 20 mm from end)	7.970—7.980 (0.3138—0.3142)	7.950 (0.3130)
	Subshaft feed pipe O.D.	7.970—7.980 (0.3138—0.3142)	7.950 (0.3130)
	Mainshaft sealing ring 32 mm thickness	1.980—1.995 (0.0780—0.0785)	1.800 (0.0709)
	Mainshaft bushing I.D.	6.018—6.030 (0.2369—0.2374)	6.045 (0.2380)
	Mainshaft bushing I.D.	9.000—9.015 (0.3543—0.3549)	9.030 (0.3555)
	Countershaft bushing I.D.	8.000—8.015 (0.3150—0.3156)	8.030 (0.3161)
	Subshaft bushing I.D.	8.000—8.015 (0.3150—0.3156)	8.030 (0.3161)
	Mainshaft sealing ring groove width	2.025—2.060 (0.0797—0.0811)	2.080 (0.0819)
	Statorshaft distance collar 20 mm I.D.	26.000—26.013 (1.0236—1.0241)	26.030 (1.0248)
Regulator valve body	Sealing ring contact area diameter	32.000—32.025 (1.2598—1.2608)	32.050 (1.2618)
Shifting device and parking brake control	Reverse shift fork thickness	5.90—6.00 (0.232—0.236)	5.40 (0.213)
	Parking brake ratchet pawl	—	Wear or other defect
	Parking gear Throttle cam stopper height	27.0—27.1 (1.06—1.07)	Wear or other defect
Servo body	Shift fork shaft bore I.D.	A 14.000—14.005 (0.5512—0.5514)	—
		B 14.006—14.010 (0.5514—0.5516)	—
		C 14.011—14.015 (0.5516—0.5518)	—
	Shift fork shaft valve bore I.D.	37.000—37.039 (1.4567—1.4582)	37.045 (1.4585)
Valve body	Oil pump gear side clearance	0.03—0.05 (0.001—0.002)	0.07 (0.003)
	Oil pump gear-to-body clearance	0.240—0.266 (0.0094—0.0105)	—
		0.063—0.088 (0.0025—0.0035)	—
	Stator camshaft needle bearing bore I.D. (R side)	26.000—26.013 (1.0236—1.0241)	Wear or damage
	Stator camshaft needle bearing contact and I.D. (Stator side)	24.000—24.021 (0.9449—0.9457)	Wear or damage
	Oil pump driven gear I.D.	14.016—14.034 (0.5518—0.5525)	Wear or damage
	Oil pump shaft O.D.	13.980—13.990 (0.5504—0.5508)	Wear or damage

(cont'd)

Standards and Service Limits

9. Automatic Transmission (4 WD)(cont'd)

	MEASUREMENT	Wire Dia.	O.D.	Free Length	No. of Coils
Springs	Regulator valve spring A	1.8 (0.07)	14.7 (0.58)	86.5 (3.41)	16.5
	Regulator valve spring B	1.8 (0.07)	9.6 (0.38)	44.0 (1.73)	7.5
	Stator reaction spring	6.0 (0.24)	38.4 (1.51)	30.3 (1.19)	2
	Torque converter check valve spring	1.1 (0.04)	8.4 (0.33)	36.4 (1.43)	12
	Relief valve spring	1.0 (0.04)	8.4 (0.33)	52.0 (2.05)	23
	2nd orifice control valve spring	0.8 (0.03)	6.6 (0.26)	38.5 (1.52)	28
	Servo orifice control valve spring	0.9 (0.04)	6.1 (0.24)	35.9 (1.41)	20
	Throttle control valve B spring	1.6 (0.06)	8.5 (0.33)	41.3 (1.63)	13.9
	Throttle control valve B adjuster spring	0.8 (0.03)	6.2 (0.24)	30.0 (1.18)	8
	1—2 shift spring	0.9 (0.04)	8.6 (0.34)	40.4 (1.59)	14.5
	2—3 shift spring	0.8 (0.03)	8.6 (0.34)	35.8 (1.41)	10.6
	3—4 shift spring	0.8 (0.03)	7.6 (0.30)	59.7 (2.35)	22.7
	Low accumulator A spring	2.0 (0.08)	13.7 (0.54)	71.3 (2.81)	11.0 and 8.0
	Low accumulator B spring	3.2 (0.13)	24.3 (0.96)	59.5 (2.34)	5.8
	4th accumulator spring	3.2 (0.13)	18.6 (0.73)	78.3 (3.08)	10
	2nd accumulator spring	2.7 (0.11)	16.1 (0.63)	88.4 (3.48)	16.0
	3rd accumulator spring	2.7 (0.11)	15.5 (0.61)	78.3 (3.08)	15.6
	L/C control springs	0.6 (0.02)	6.6 (0.26)	42.0 (1.65)	31.6
	L/C timing valve B spring	0.9 (0.04)	5.6 (0.22)	40.7 (1.60)	30
	CPC valve spring	1.4 (0.06)	9.4 (0.37)	31.6 (1.24)	10.9
	Servo return springs A and B	2.6 (0.10)	29.8 (1.17)	40.3 (1.59)	3.3
	L/C shift valve spring	1.1 (0.04)	8.6 (0.34)	51.0 (2.01)	18.6
	4—2 kick down valve spring	0.9 (0.04)	6.4 (0.25)	42.7 (1.68)	20.8
	Cooler relief valve spring	1.1 (0.04)	8.4 (0.33)	36.4 (1.43)	12
	Modulator valve springs A and B	1.4 (0.06)	9.4 (0.37)	33.0 (1.30)	10.5
	Servo control valve spring	1.1 (0.04)	8.1 (0.32)	47.8 (1.88)	18.8
	4th exhaust valve spring	0.9 (0.04)	6.6 (0.26)	37.0 (1.46)	18.7
	4—3 kick down valve spring	0.9 (0.04)	6.4 (0.25)	42.7 (1.68)	20.8

10. Driveshaft

	MEASUREMENT	STANDARD (NEW)	SERVICE LIMIT
Driveshaft	Right: boot as installed with intermediate shaft	485—490 (19.09—19.29)	—
	without intermediate shaft	481.5—486.5 (18.96—19.15)	—
	Left: boot as installed with intermediate shaft*	485—490 (19.09—19.29)	—
	without intermediate shaft	774.5—779.5 (30.49—30.69)	—
Rear driveshaft	Right boot as installed	595.6—600.6 (23.45—23.65)	—
	Left boot as installed	641.6—646.6 (25.26—25.46)	—
Propeller shafts	Runout No. 1, No. 3	—	1.5 (0.06)

* includes 4WD

10. Rear Differential (4 WD without ALB)

	MEASUREMENT	STANDARD (NEW)	SERVICE LIMIT
Differential carrier assembly	Oil capacity	0.65 ℓ (0.69US. qt., 0.57Imp. qt)	—
	Replace Disassemble	0.70 ℓ (0.74US. qt., 0.62Imp. qt)	—
Differential carrier	Diameter of taper bearing contact area		
	Front drive pinion bearing	57.979—58.009 (2.2826—2.2838)	58.06 (2.286)
	Rear drive pinion bearing	71.979—72.009 (2.8338—2.8350)	72.06 (2.837)
	Side bearing	68.000—68.030 (2.6772—2.6783)	68.08 (2.680)
Differential case	Diameter of diff. pinion shaft contact area	18.000—18.018 (0.7087—0.7094)	—
	Case-to-diff. pinion shaft	0.016—0.052 (0.0006—0.0020)	0.1 (0.004)
	Diameter of drive shaft contact area	26.005—26.025 (1.0236—1.0246)	—
	Case-to-drive shaft clearance	0.025—0.066 (0.0010—0.0026)	0.12 (0.005)
	Diameter of taper bearing contact area	40.002—40.018 (1.5749—1.5755)	39.95 (1.573)
Differential pinion gear	Backlash I.D.	0.05—0.15 (0.002—0.006)	Adjust with a washer
	Gear-to-pinion shaft clearance	18.042—18.066 (0.7103—0.7113)	—
		0.059—0.095 (0.0022—0.0037)	0.15 (0.006)
Hypoid drive pinion gear	Backlash	0.11—0.16 (0.004—0.006)	Adjust with a shim
	Diameter of taper bearing contact area		
	Front pinion bearing	27.987—28.000 (1.1018—1.1024)	27.93 (1.100)
	Rear pinion bearing	30.002—30.018 (1.1812—1.1818)	29.95 (1.179)

10. Rear Differential (4 WD with ALB)

	MEASUREMENT	STANDARD (NEW)	SERVICE LIMIT
Clutch housing	Fluide Capacity Disassembly	0.31 ℓ (0.33 US. gt., 0.27 Imp. gt)	
Differential carrier assembly	Oil capacity	0.93 ℓ (0.98 US. gt., 0.82 Imp. gt)	—
	Replace Disassembly	1.00 ℓ (1.06 US. gt., 0.88 Imp. gt)	—
Hypoid drive pinion gear	Backlash	0.10—0.15 (0.004—0.006)	Adjust with a shim
2-4 shift fork	Fork projection width for 2-4 sleeve groove	6.8—6.9 (0.268—0.272)	—
Clearance of clutch hub to clutch peace		0.05—0.25 (0.002—0.100) max	—
Preroid of hypoid drive pinion N·m (kg-cm, lb)		98—160 (10.0—16.3, 22—36)	—
Total preroid of hyoid drive pinion and biscous coupling unit N·m (kg-cm, lb)		109—175 (11.1—17.8, 25—39)	—

Standards and Service Limits

11. Steering

	MEASUREMENT	STANDARD (NEW)	SERVICE LIMIT
Steering wheel	Play	10 (0.39) max.	—
Gear box	Pinion starting torque N·m (kg-m, lb-ft)	○ 0.49—1.67 (0.05—0.17, 0.36—1.27) ● 0.39—1.37 (0.04—0.14, 0.29—1.01)	—
	Angle of rack-guide-screw loosened from locked position with P/S	0.98 (0.1, 0.72) max. ○ 40°—60° ● 10°—20° 20°—25°	— — — —
Pump	Pump pressure with valve closed (Oil temp./speed: 40°C (104°F) min/idle. Do not run for more than 5 seconds) kPa (kg/cm ² , psi)	7,845—8,826 (80—90, 1,138—1,280)	
Power steering fluid	Fluid capacity	Reservoir0.4 ℓ (0.42 U.S. qt., 0.35 Imp. qt.) At changeapprox. 1.2 ℓ (1.3 U.S. qt., 1.1 Imp. qt.)	
Power steering belt	Deflection when 98 N (10 kg, 22 lb) between the pulleys Belt tension between the pulleys N (kg, lb) (Measured with the belt tension gauge)	9—12 (0.35—0.47) for used belt 7—10 (0.28—0.39) after replacement of belt 343-490 (35-50, 77-110) 441 - 686 (45 - 70, 99 - 154)	
Rack end	Pivoting resistance N·m (kg-m, lb-ft)	0.49—1.96 (0.05—0.2, 0.36—1.45)	—

○ : Normal ratio, ● : Variable ratio (Si)

12. Suspension

	MEASUREMENT	STANDARD (NEW)	SERVICE LIMIT
Wheel alignment	Toe-in	Front 0±2 (0±0.08) Rear 2± ² / ₃ (0.08 ^{+0.08} / _{-0.04})	— —
	Camber	2D H/B, 4D 0'00'±1'	—
		4D 4WD, 4WD H/B 0'19'±1'	—
		4D H/B 4WD 0'35'±1'	—
	Caster	2D H/B 2'59'±1'	—
		4D H/B 2'58'±1'	—
		4D H/B 4WD 2'56'±1'	—
	Side slip	0±3 (0±0.12)	—
	Turning angle (max.)		
	Inward wheel except 4D H/B 4WD	41'30'±2'	—
Wheel	4D H/B 4WD	42'00'±2'	—
	Outward wheel except 4D H/B 4WD	33'30'±2'	—
	4D H/B 4WD	33'50'±2'	—
Wheel	Rim runout	Steel 0—1.0 (0—0.039) Aluminum 0—0.7 (0—0.028)	2.0 (0.08) 1.5 (0.06)
Wheel bearing	End play	Front 0 Rear 0	0.05 0.05

13. Brake

	MEASUREMENT		STANDARD (NEW)	SERVICE LIMIT
Parking brake lever	Play in stroke 200N (20 kg, 44 lbs)		To be locked when pulled 6—10 notches	
Foot brake pedal	Pedal height	RHD	161 (6.3) from floor	—
	Free play	LHD	153 (6.0) from floor 1—5 (0.04—0.20)	5 (0.20)
Master cylinder	Piston-to-push rod clearance		0—0.4 (0—0.016)	—
Disc brake	Disc thickness	Front	*1 12.0 (0.47) *2 17.0 (0.67) *3 19.0 (0.75) *8 21.0 (0.83)	10.0 (0.39) 15.0 (0.59) 17.0 (0.67) 19.0 (0.75)
		Rear	10.0 (0.39)	8.0 (0.32)
		Front/Rear	—	0.1 (0.004)/0.15 (0.006)
		Disc runout	—	0.015 (0.006)
	Disc parallelism	Front	*4 9.5 (0.37) *5 9.5 (0.37) *6 10.5 (0.41) *7 9.0 (0.35) *8 10.0 (0.39)	3.0 (0.12) 1.6 (0.06) 1.6 (0.06) 3.0 (0.12)
		Rear	8.0 (0.32)	1.6 (0.06)
	Pad thickness	Front	*4 9.5 (0.37) *5 9.5 (0.37) *6 10.5 (0.41) *7 9.0 (0.35) *8 10.0 (0.39)	3.0 (0.12) 1.6 (0.06) 1.6 (0.06) 3.0 (0.12)
		Rear	8.0 (0.32)	1.6 (0.06)
	I.D. except 4D H/B 4D H/B		180 (7.09) 200 (7.87) 4.5 (0.18)	181 (7.13) 201 (7.91) 2.0 (0.08)
	Lining thickness			
Brake booster	Characteristics		Vacuum (mm Hg)	Pedal Pressure kg (lbs)
	7"	1.2 ℓ, 1.3 ℓ DX GL (KP, KT except 4D H/B)	0	20 (44)
			300	20 (44)
			500	20 (44)
	8"	GL (EC except KS, KQ, KY), 4D H/B General models	0	20 (44)
			300	20 (44)
			500	20 (44)
	Others		0	20 (44)
			300	20 (44)
			500	20 (44)

*1: 1.2 ℓ, 1.3 ℓ

*2: 2D H/B (1.4 ℓ), 4D (1.4 ℓ, 1.5 ℓ 1-carb. except KY), 4D H/B (KP, KT)

*3: 2D H/B (1.5 ℓ, 1.6 ℓ), 4D (KY, 1.5 ℓ 2-carb., 1.5 ℓ PGM-FI, 1.6 ℓ), 4D H/B (except KP, KT)

*4: 2D H/B, 4D EC model (1.2 ℓ DX, 1.3 ℓ DX and GL except KX, KS)

*5: 2D H/B, 4D General Model (except KQ, KY)

*6: 2D H/B, 4D GL-KX and 4D H/B EC model (except KG, KS)

*7: 2D H/B, 4D GL-KS, 1.6 ℓ, 4D H/B KG, KS model and 4WD model

*8: KQ, KY model

15. Air Conditioner

	MEASUREMENT	STANDARD (NEW)
Compressor		MATSUSHITA
	Cooling capacity	3.850 kcal/h
	Refrigerant quantity	0.9 ± 0.05 kg (1.98 ± 0.11lb.)
	Lubricant capacity	130 cc
	Clutch resistance	3.33 ± 0.17 ohm at 20 °C (68 °F)
Compressor belt	Clutch clearance	0.4-0.6
	Deflection when 98 N (10kg, 22 lb) between the pulleys	9-11 (0.35-0.43) with used belt 7-9 (0.28-0.35) with new belt
	Belt tension between the pulleys N (kg, lb) (Measure with belt tension gauge)	343-442 (35-45, 77-99) with used belt 442-686 (45-70, 99-154) with new belt

Standards and Service Limits

16. Electrical

16. Electrical											
MEASUREMENT				STANDARD (NEW)							
Ignition coil	Rated voltage			12 Volts							
	Primary winding resistance			0.3—0.5 ohms							
	Secondary winding resistance			9,440—14,160 ohms							
Ignition wire	Resistance			25,000 ohms max.							
Spark plug						Standard		Optional			
	Type			Unleaded gasoline	NGK	BCPR6E-11		BCPR6EY-N11 BCPR7E-11 BCPR7EY-N11			
					ND	Q20PR-U11		Q22PR-U11			
				Leaded gasoline	NGK	BCPR6E-11		BCPR7E-11			
					ND	20PR-U11 20PR-UL11 (*)		20PR-U11 (*) 22PR-U11 22PR-UL11 (*)			
(*) : 1.6 ℓ DOHC only											
Gap			1.0—1.1 (0.039—0.043)								
Ignition timing	At idling	PGM-FI	SOHC	18° ± 2° (Red) BTDC							
		DOHC	16° ± 2° (Red) BTDC								
1-Carbureted Engine			16° ± 2° (Red) BTDC								
KT (1.2 ℓ)			12° ± 2° (Red) BTDC								
KG (1.3 ℓ M/T), KY (1.5 ℓ A/T)			2° ± 2° (Red) BTDC								
KG (1.3 ℓ A/T)			20° ± 2° (Red) BTDC								
Others (1.2 ℓ)			18° ± 2° (Red) BTDC								
Others (1.3 ℓ, 1.5 ℓ)			20° ± 2° (Red) BTDC								
2-Carbureted Engine			2° ± 2° (Red) BTDC								
KQ			12° ± 2° (Red) BTDC								
KG (A/T)			18° ± 2° (Red) BTDC								
KG (M/T)											
Others											
Battery	Lighting capacity (20-hour rate)			47 (European), 45 (General) Ampere Hours							
	Starting capacity (Voltage after 5sec.)			8.6 V min. at 300 Ampere draw/-15°C							
Alternator belt	Deflection when 98 N (10 kg, 22 lb) between the pulleys			9-11 (0.35-0.43) with used belt							
				7-9 (0.28-0.35) with new belt							
Belt tension between the pulleys N (kg, lb)				294-392 (30-40, 66-88) with used belt							
(Measure with belt tension gauge)				392-588 (40-60, 88-132) with new belt							
Alternator				ND		MITSUBISHI					
	Output			13.5V / 60A							
	MEASUREMENT			STANDARD (NEW)		SERVICE LIMIT		STANDARD (NEW)		SERVICE LIMIT	
	Coil resistance (rotor)			2.8—3.0 ohm		±0.1 ohm		3.4—3.8 ohm		±0.2 ohm	
	Slip ring O.D.			32.5 (1.28)		32.1 (1.26)		22.7 (0.89)		22.2 (0.87)	
	Brush length			13.5 (0.53)		4.5 (0.18)		22 (0.87)		8 (0.31)	
	Brush Spring tension			300—500g (10.6—17.6 oz)		—		300—450g (10.6—15.9 oz)		—	
Starting motor	HITACHI 0.8 kw			ND 0.8 kw		ND 1.0 kw, 1.2 kw		MITSUBA 1.0 kw, 1.4 kw			
	MEASUREMENT	STANDARD (NEW)	SERVICE LIMIT	STANDARD (NEW)	SERVICE LIMIT	STANDARD (NEW)	SERVICE LIMIT	STANDARD (NEW)	SERVICE LIMIT		
	Mica depth	0.5—0.8 (0.020 —0.031)	0.2 (0.008)	0.5—0.8 (0.020 —0.031)	0.2 (0.008)	0.5—0.8 (0.020 —0.031)	0.2 (0.008)	0.4—0.5 (0.016 —0.020)	0.15 (0.006)		
	Commutator	0—0.1 (0.004)	0.4 (0.016)	0.05 (0.002)	0.4 (0.016)	0—0.02 (0.0008)	0.05 (0.002)	0—0.02 (0.0008)	0.05 (0.002)		
	Commutator O.D.	40.0 (1.57)	39.0 (1.54)	28.0 (1.10)	27.0 (1.06)	29.9—30.0 (1.18)	29.0 (1.14)	28.0—28.1 (1.10—1.11)	27.5 (1.08)		
	Brush length	14.5—15.5 (0.57—0.61)	11.0 (0.43)	15.5—16.5 (0.61—0.65)	10.0 (0.39)	12.5—13.5 (0.49—0.53)	8.5 (0.33)	14.3—14.7 (0.56—0.58)	9.3 (0.37)		
	Spring Pressure (new)	15.7 N (1.6 kg, 3.5 lb)	—	15.7 N (1.6 kg, 3.5 lb)	—	18.1—23.9 N (1.85—2.4 kg, 4.1—5.4 lb)	—	20.1—26.5 N (2.05—2.7 kg, 4.5—6.0 lb)	—		

Design Specifications

2D H/B

specs

	ITEMS	METRIC	ENGLISH	NOTES
DIMENSIONS	Overall Length	3,995 mm 4,005 mm	157.3 in. 157.7 in.	with registration plate guard KQ, KY
	Overall Width	3,990 mm 1,680 mm	157.1 in. 66.1 in.	
	Overall Height	1,670 mm 1,330 mm	65.7 in. 52.4 in.	1.2 t, 1.3 t KY
	Wheelbase	1,360 mm 2,500 mm	53.5 in. 98.4 in.	
	Track, Front/Rear	1,450/1,455 mm 1,445/1,450 mm	57.1/57.3 in. 56.9/57.1 in.	KY
	Ground Clearance	160 mm 150 mm	6.3 in. 5.9 in.	
	Seating Capacity			cars with CATA
	Overhang, Front/Rear	795/700 mm 805/700 mm	31.3/27.6 in. 31.7/27.6 in.	
				with registration plate guard
WEIGHTS	Engine Weight (Wet)			
	1.2 t	93 kg	205 lb.	
	1.3 t	95 kg	209 lb.	
	1.4 t	98 kg	216 lb.	
	1.5 t 1-Carbureted	94 kg	207 lb.	
	1.5 t 2-Carbureted	101 kg	222 lb.	
	1.5 t PGM-FI	100 kg	220 lb.	
	1.6 t SOHC	107 kg	236 lb.	
	1.6 t DOHC	113 kg	249 lb.	
	Curb weight			
	1.2 t M/T	845 kg	1,862 lb.	KB
	1.3 t M/T	860 kg	1,896 lb.	KB, KF, KE, KW, KG
		865 kg	1,907 lb.	KW (SF)
		875 kg	1,929 lb.	KG
		880 kg	1,940 lb.	KS
	1.3 t A/T	880 kg	1,940 lb.	KB, KE, KF, KW
		885 kg	1,951 lb.	KW (SF)
	1.4 t M/T	875 kg	1,929 lb.	KB, KF, KW
		880 kg	1,940 lb.	KW (SF)
		890 kg	1,962 lb.	KE
	1.4 t A/T	895 kg	1,973 lb.	KB, KF, KW
		900 kg	1,984 lb.	KW (SF)
		910 kg	2,006 lb.	KE
	1.5 t M/T (DX)	900 kg	1,984 lb.	KW, KX
	1.5 t M/T (GL)	905 kg	1,995 lb.	KS
		915 kg	2,017 lb.	KX
		900 kg	1,984 lb.	KW
		910 kg	2,006 lb.	KG
	1.5 t A/T (DX)	920 kg	2,028 lb.	KX
	1.5 t A/T (GL)	925 kg	2,039 lb.	KS
		935 kg	2,061 lb.	KX
		920 kg	2,028 lb.	KW
	1.3 t M/T	874 kg	1,927 lb.	KT
	1.3 t A/T	894 kg	1,971 lb.	KT
	1.5 t M/T (DX)	901 kg	1,986 lb.	KQ
	1.5 t M/T (GL)	925 kg	2,039 lb.	KQ
		945 kg	2,083 lb.	KY
	1.5 t A/T (GL)	946 kg	2,086 lb.	KQ
		965 kg	2,127 lb.	KY

SF: Finland

(cont'd)

Design Specifications

2 D H/B (cont'd)

	ITEMS	METRIC	ENGLISH	NOTES	
WEIGHTS	weight Distribution (Front/Rear)				
	1.3 ℓ A/T	545/335 kg	1,202/739 lb.	KB, KE, KF, KW	
		550/335 kg	1,216/739 lb.	KW (SF)	
	1.4 ℓ M/T	535/340 kg	1,179/750 lb.	KB	
		540/340 kg	1,190/750 lb.	KW (SF)	
	1.4 ℓ A/T	550/340 kg	1,213/750 lb.	KE	
		555/340 kg	1,224/750 lb.	KB, KF, KW	
		560/340 kg	1,235/750 lb.	KW (SF)	
		570/340 kg	1,257/750 lb.	KE	
	1.5 ℓ M/T (DX)	550/350 kg	1,213/750 lb.	KW, KX	
	1.5 ℓ M/T (GL)	555/350 kg	1,224/772 lb.	KS	
		565/350 kg	1,246/772 lb.	KX	
		550/350 kg	1,213/772 lb.	KW	
		560/350 kg	1,235/772 lb.	KG	
	1.5 ℓ A/T (DX)	570/350 kg	1,257/772 lb.	KX	
	1.5 ℓ A/T (GL)	575/350 kg	1,268/772 lb.	KS	
		585/350 kg	1,290/772 lb.	KX	
		570/350 kg	1,257/772 lb.	KW	
		580/350 kg	1,279/772 lb.	KG	
	1.6 ℓ SOHC	570/365 kg	1,257/805 lb.	KG, KX, KW (A)	
		575/365 kg	1,268/805 lb.	KW, KS	
	1.6 ℓ DOHC	580/365 kg	1,257/805 lb.	KB, KF, KW	
		590/365 kg	1,301/805 lb.	KR (SF)	
		595/375 kg	1,312/827 lb.	KE	
		585/365 kg	1,290/805 lb.	KF, KR	
	1.3 ℓ M/T	536/338 kg	1,182/745 lb.	KT	
	1.3 ℓ A/T	556/338 kg	1,226/745 lb.	KT	
	1.5 ℓ M/T (DX)	554/347 kg	1,221/765 lb.	KQ	
	1.5 ℓ M/T (GL)	571/354 kg	1,259/780 lb.	KQ	
		586/359 kg	1,292/791 lb.	KY	
	1.5 ℓ A/T (GL)	595/351 kg	1,312/774 lb.	KQ	
		607/358 kg	1,338/789 lb.	KY	
		Max. Permissible weight (EC)			
		1.2 ℓ	1,310 kg	2,888 lb.	
		1.3 ℓ	1,310 kg	2,888 lb.	except "S"
			1,270 kg	2,800 lb.	"S" only
		1.4 ℓ	1,340 kg	2,954 lb.	
		1.5 ℓ	1,370 kg	3,020 lb.	except "S"
			1,300 kg	2,866 lb.	"S" M/T
			1,320 kg	2,910 lb.	"S" A/T
			1,380 kg	3,042 lb.	except "S"
		1.6 ℓ	1,320 kg	2,910 lb.	"S" only
		Maximum Loaded Vehicle Weight	1,390 kg	3,064 lb.	KY
ENGINE	Type	Water cooled 4-stroke S.O.H.C.			
		Water cooled 4-stroke D.O.H.C.			
	Cylinder arrangement	4-cylinder in-line, transverse			
	Bore and Stroke	1.2 ℓ	75×67.5 mm	2.95×2.66 in.	
		1.3 ℓ	75×76 mm	2.95×2.99 in.	
		1.4 ℓ	75×79 mm	2.95×3.11 in.	
		1.5 ℓ	75×84.5 mm	2.95×3.33 in.	
		1.6 ℓ	75×90 mm	2.95×3.54 in.	
	Displacement	1.2 ℓ	1,193 cm ³ (cc)	73 cu. in.	
		1.3 ℓ	1,343 cm ³ (cc)	82 cu. in.	
		1.4 ℓ	1,396 cm ³ (cc)	85 cu. in.	
		1.5 ℓ	1,493 cm ³ (cc)	91 cu. in.	
		1.6 ℓ	1,590 cm ³ (cc)	97 cu. in.	
	Compression Ratio				
		1.2 ℓ	8.6		
		1.3 ℓ	9.0		
		1.4 ℓ	9.3		
		1.5 ℓ	9.2		
		1.6 ℓ with CATA	9.1		
		1.6 ℓ without CATA	9.5		
	Valve Train	1.6 ℓ without CATA	4-valves per cylinder, double overhead camshafts		
		Others	4-valves per cylinder, single overhead camshaft		
	Lubrication System		Forced and wet sump		
	Fuel Required				
	Engine with CATA		Unleaded gasoline with 91 R.O.N or higher		
	Carbureted engines without CATA		* Gasoline with 91 R.O.N or higher		
	PGM-FI DOHC without CATA		Leaded gasoline with 97 R.O.N or higher		
	PGM-FI without CATA		eadedgasoline with 97 R.O.N. or higher or unleaded gasoline with 95 R.O.N. or higher		
				* Both leaded and unleaded gasoline can be used.	

SF : Finland

A : Austria

"S" : Sweden

	ITEMS		METRIC		ENGLISH		NOTES
STARTER	Type	0.8 kW 1.0 kW, 1.2 kW, 1.4kW	Direct Gear reduction 0.8 kW, 1.0 kW, 1.2 kW, 1.4 kW 12V 30 seconds Clockwise as viewed from gear end				
	Normal Output		4.4 kg		9.7 lb.		
	Normal Voltage		3.4 kg		7.5 lb.		
	Hour Rating		3.85 kg		8.5 lb.		
	Direction of Rotation		3.85 kg		8.5 lb.		
TRANSMISSION	Weight	0.8 kW HITACHI/ND 1.0 kW MITSUBA ND 1.2 kW ND 1.4 kW MITSUBA	4.4 kg		9.7 lb.		
			3.4 kg		7.5 lb.		
			3.85 kg		8.5 lb.		
			3.85 kg		8.5 lb.		
			3.7 kg		8.2 lb.		
	Clutch	M/T A/T	Single plate dry, diaphragm spring Torque converter				
	Transmission Type	M/T	5 speeds forward, synchromesh, 1 speed reverse, constant mesh				
	Primary Reduction	A/T	4 speeds forward, with lock-up clutch, 1 speed reverse 1.000				
	Gear Ratio		M/T	1.6 DOHC M/T	A/T		
		1st	3.250	3.250	2.705		
		2nd	1.894	1.944	1.560		
		3rd	1.259	1.346	1.027		
		4th	0.937	1.033	0.780		
		5th	0.771	0.878	—		
		Reverse	3.153		1.954		
	Final Reduction	M/T 1.2 ℓ 1.3 ℓ 1.4 ℓ 1.5 ℓ 1.6 ℓ SOHC 1.6 ℓ DOHC	Single helical gear, 4.058 Single helical gear, 4.250 Single helical gear, 4.058 Single helical gear, 4.250 Single helical gear, 4.058 Single helical gear, 4.214 (A/T) Single helical gear, 4.250 Single helical gear, 4.250 Single helical gear, 3.888 Single helical gear, 3.933				KB KP, KT, KU KX, KW, KS KG KQ
	Clutch Facing Area	A/T	160 cm ²		24.8 sq. in.		
AIR CONDIT- TIONER	Compressor		MASTUSHITA				
	Cooling Capacity		3,850 Kcal/h				
	— Conditions:		1,800 min ⁻¹ (rpm)				
	Compression min ⁻¹ (rpm)		27.0°C		81°F		
	Outside Air Temperature			50%			
	Outside Air Humidity		35°C		95°F		
	Condenser Air Temperature		4.5 m/sec.		14.8 ft/sec.		
	Condenser Air Velocity		440 m ³ /h		15,118 cu. ft/h		
	Blower Capacity						
	Compressor	Type Number of Vane Displacement Max. min ⁻¹ (rpm) Lubricant Capacity	Vane rotary type 3 130cc/rev. 7,500 min ⁻¹ (rpm) 130 cc			7.93 cu. in. /rev 7.93 cu. in.	
Receiver Dryer With Desiccant		Includes fusible safety plug.					
Condenser		Corrugated fin type					
Evaporator		Corrugated fin type					

(cont'd)

Design Specifications

2D H/B (cont'd)

	ITEMS		METRIC	ENGLISH	NOTES
AIR CONDI-TIONER	Blower	Type Motor Input Speed Control Max. Capacity	Sirocco fan 170 W (12 V) 4 speeds 390 m ³ /h		13,773 cu. ft/h
	Temp. Control Comp. Clutch	Type Power Consumption	Air-mix type Dry, single plate, V-belt 32 W max. 12 V		
	Refrigerant	Type Quantity	R-12 0.9±0.05 kg		1.98±0.11 lb
STEERING SYSTEM	Type		Rack and pinion		
	Overall Ratio	Manual Variable ratio Power	18.6: 1 19.8 (18-20.4): 1 17.7: 1		1.6 l only
	Turns, Lock-to-lock	Manual Variable ratio Power	3.8 4.1 3.6		1.6 l only
	Steering Wheel Diameter	Dx Others	377 mm 370 mm		14.8 in. 14.6 in.
SUSPENSION SYSTEM	Type Shock Absorber	Front/Rear Front Rear	Independent by double wishbones, coil springs Telescopic, nitrogen gas-filled Telescopic, nitrogen gas-filled		
WHEEL ALIGNMENT	Wheel Alignment		0°00'±1'		
	Camber	Front Rear	-0°30'±1'		
	Caster Toe-in	Front Front Rear	2°59'±1'		
	Kingpin Inclination		7°34'		
BRAKE SYSTEM	Type	Front 1.2 l, 1.3 l Rear 1.6 l Others	Power assisted self-adjusting disc Power assisted self-adjusting ventilated disc Power assisted self-adjusting disc drum		
	Pad Surface Area	Front 1.2 l, 1.3 l, 1.4 l, 1.5 l, 1.6 l Rear 1.2 l, 1.3 l, 1.4 l, 1.5 l, 1.6 l	36.8 mm ² 44.1 mm ² 50.2 mm ² 21.0 mm ²		5.70 sq. in. 6.84 sq. in. 7.78 sq. in. 3.25 sq. in.
	Effective Disc Diameter	Front 1.2 l, 1.3 l, 1.4 l Rear 1.5 l, 1.6 l	190 mm 194 mm 208 mm 180 mm		7.48 in. 7.64 in. 8.19 in. 7.09 in.
	Brake Drum I.D. Rear Parking Brake Kind and Type		Mechanically actuating, rear two wheel brakes		Carbureted engine PGM-FI Drum Disc (1.6 l) Carbureted engine PGM-FI
TIRES	Front/Rear	1.2 l, 1.3 l 1.4 l, 1.5 l	155SR13, 155R13 78S 155SR13, 165SR13 (rough road type only) 165/80R13 82S 165/70R13 79S 165/70R13 79S or 175/70R13 82H		KB, KG KF, KE, KW, KS KP, KT, KU KY KQ KB, KG, KX, KW, KS KF, KE, KW (1.4 l)
	Spare	1.6 l	185/60R14 82H T105/80D 13		Standard for some types.

	ITEMS	METRIC	ENGLISH	NOTES
ELECTRICAL	Battery	12V-47 AH (European), 12V-45AH (General)		20A*: Finland only
	Starter	12V-0.8 kW, 1.0 kW, 1.2 kW, 1.4 kW		
	Alternator	12V-60 amps		
	Fuses	10A, 15A, 20A*, 30A		
	In the dash fuse box	10A, 15A, 20A, 50A, 60A		
	In the main fuse box	12V-60/55W		
	Headlights High/Low	12V-21W		
	Front Turn Signal Lights	12V-21W		
	Rear Turn Signal Lights	12V-5W		
	Side Turn Signal Lights	12V-21/5W		
	Stop/Taillights	12V-5W		
	Side Marker Lights	12V-21W		
	Back-up Lights	12V-5W		
	License Plate Lights	12V-5W		
	Gauge Lights	12V-3.4W, 3.0W, 1.4W		
	Indicator Lights	12V-1.4W		
	Warning Lights	12V-5W		
	Dome Light	12V-3.4W		
	Trunk Light	12V-1.4W		
	Illumination and Pilot Lights	12V-1.4W		
	Heater Illumination Lights	0.91W, 0.84W, LED		
		12V-1.4W		

Design Specifications

4D

	ITEMS	METRIC	ENGLISH	NOTES
DIMENSIONS	Overall Length	4,295 mm	169.1 in.	KQ SF with door protector without door protector
	with registration plate guard	4,285 mm	168.7 in.	
		4,305 mm	169.5 in.	
		1,695 mm	66.7 in.	
	Overall Width	1,690 mm	66.5 in.	KY 4WD
	Overall Height	1,360 mm	53.5 in.	
		1,385 mm	54.5 in.	
		1,380 mm	54.3 in.	
	Wheelbase	2,500 mm	98.4 in.	KY
	Track, Front/Rear	1,450/1,455 mm	57.1/57.3 in.	
WEIGHTS	Ground Clearance	1,445/1,450 mm	56.9/57.1 in.	
		160 mm	6.3 in.	
		150 mm	5.9 in.	
	Seating Capacity			cars with CATA
	Overhang, Front/Rear	815/980 mm	32.1/38.6 in.	
	with registration plate guard	825/980 mm	32.5/38.6 in.	
	Engine Weight (Wet)			KB, KW KW (SF)
	1.2 l	93 kg	205 lb.	
	1.3 l	95 kg	209 lb.	
	1.4 l	98 kg	216 lb.	
WEIGHTS	1.5 l 1-Carbureted	94 kg	207 lb.	KB, KE, KW KW (SF)
	1.5 l 2-Carbureted	101 kg	222 lb.	
	1.5 l PGM-FI	100 kg	220 lb.	
	1.6 l SOHC	107 kg	236 lb.	
	Curb weight			KW (SF)
	1.2 l M/T	880 kg	1,940 lb.	
		885 kg	1,951 lb.	
	1.4 l M/T	915 kg	2,017 lb.	
		920 kg	2,028 lb.	
	1.4 l A/T	935 kg	2,061 lb.	KB, KE, KW KW (SF)
		940 kg	2,072 lb.	
	1.5 l M/T (DX)	920 kg	2,028 lb.	
		935 kg	2,061 lb.	
WEIGHTS	1.5 l M/T (GL)	930 kg	2,050 lb.	KS KW, KX
		950 kg	2,094 lb.	
	1.5 l A/T (GL)	935 kg	2,061 lb.	
		950 kg	2,094 lb.	
		970 kg	2,138 lb.	KG (NL, DK), KS KW, KX KG
	1.6 l	955 kg	2,105 lb.	
		975 kg	2,149 lb.	
		980 kg	2,161 lb.	
	1.6 l M/T 4WD	985 kg	2,171 lb.	KW (SF) KX KS
		1,070 kg	2,359 lb.	
		1,075 kg	2,370 lb.	
		1,065 kg	2,349 lb.	
WEIGHTS	1.6 l A/T 4WD	1,090 kg	2,403 lb.	KW (A) KX Singapore
	1.3 l M/T	895 kg	1,973 lb.	
	1.3 l A/T	915 kg	2,017 lb.	
	1.5 l M/T (DX)	946 kg	2,086 lb.	
	1.5 l M/T (GL)	977 kg	2,154 lb.	KQ KQ KY
		985 kg	2,171 lb.	
		935 kg	2,061 lb.	
	1.5 l M/T (EX)	1,005 kg	2,216 lb.	
	1.5 l A/T (GL)	997 kg	2,198 lb.	KY Singapore KQ KY
		1,005 kg	2,216 lb.	
		955 kg	2,105 lb.	
	1.5 l A/T (EX)	1,025 kg	2,260 lb.	
WEIGHTS	Weight Distribution (Front/Rear)			KB, KW KW (SF)
	1.2 l M/T	525/355 kg	1,157/783 lb.	
		530/355 kg	1,168/783 lb.	
	1.4 l M/T	545/370 kg	1,202/816 lb.	
		550/370 kg	1,213/816 lb.	KW (SF) KB, KE, KW KW (SF)
	1.4 l A/T	565/370 kg	1,246/816 lb.	
		570/370 kg	1,257/816 lb.	
	1.5 l M/T (DX)	550/370 kg	1,213/816 lb.	
		565/370 kg	1,246/816 lb.	KW KS KW, KX
	1.5 l M/T (GL)	560/370 kg	1,235/816 lb.	
		580/370 kg	1,279/816 lb.	
WEIGHTS		565/370 kg	1,246/816 lb.	
	1.5 l A/T (GL)	580/370 kg	1,279/816 lb.	KG (NL, DK), KS KW, KX KG
		600/370 kg	1,323/816 lb.	
		585/370 kg	1,290/816 lb.	
	1.6 l	585/390 kg	1,290/860 lb.	

SF : Finland NL: Netherlands DK: Denmark A : Austria

	ITEMS	METRIC	ENGLISH	NOTES	
WEIGHTS	1.6ℓ	590/390 kg	1,301/860 lb.	KW, KS	
	1.6 ℓ M/T 4WD	595/390 kg	1,312/860 lb.	KW (SF)	
		625/445 kg	1,379/981 lb.	KX	
		630/445 kg	1,389/981 lb.	KS	
	1.6 ℓ A/T 4WD	620/445 kg	1,367/981 lb.	KW (A)	
	1.3 ℓ M/T	645/445 kg	1,422/981 lb.	KX	
	1.3 ℓ A/T	527/368 kg	1,162/811 lb.	Singapore	
	1.5 ℓ M/T (DX)	547/368 kg	1,206/811 lb.	Singapore	
	1.5 ℓ M/T (GL)	567/379 kg	1,250/836 lb.	KQ	
		586/391 kg	1,292/862 lb.	KQ	
		591/394 kg	1,303/869 lb.	KY	
		571/364 kg	1,259/802 lb.	Singapore	
	1.5 ℓ M/T (EX)	603/402 kg	1,329/886 lb.	KY	
	1.5 ℓ A/T (GL)	607/390 kg	1,338/860 lb.	KQ	
		613/392 kg	1,351/864 lb.	KY	
		591/364 kg	1,303/802 lb.	Singapore	
	1.5 ℓ A/T (EX)	625/400 kg	1,378/882 lb.	KY	
	Max. Permissible Weight (EC)				
	1.2 ℓ	1,340 kg	2,954 lb.	KB, KW	
	1.4 ℓ	1,370 kg	3,020 lb.	KB, KF, KE, KW	
	1.5 ℓ	1,400 kg	3,086 lb.	KG, KS, KX, KW	
	1.6 ℓ	1,410 kg	3,108 lb.	KB, KG, KS, KX, KW	
	1.6 ℓ 4WD	1,540 kg	3,395 lb.	KX, KS, KW	
	Maximum Loaded Vehicle Weight	1,440 kg	3,175 lb.	KY	
ENGINE	Type	Water cooled 4-cycle S.O.H.C.			
	Cylinder arrangement	4-cylinder in-line, transverse			
	Bore and stroke	1.2 ℓ	75×67.5 mm	2.95×2.66 in.	
		1.3 ℓ	75×76 mm	2.95×2.99 in.	
		1.4 ℓ	75×79 mm	2.95×3.11 in.	
		1.5 ℓ	75×84.5 mm	2.95×3.33 in.	
		1.6 ℓ	75×90 mm	2.95×3.54 in.	
	Displacement	1.2 ℓ	1,193 cm³ (cc)	73 cu. in.	
		1.3 ℓ	1,343 cm³ (cc)	82 cu. in.	
		1.4 ℓ	1,396 cm³ (cc)	85 cu. in.	
		1.5 ℓ	1,493 cm³ (cc)	91 cu. in.	
		1.6 ℓ	1,590 cm³ (cc)	97 cu. in.	
	Compression Ratio				
		1.2 ℓ	8.6		
		1.3 ℓ	9.0		
		1.4 ℓ	9.3		
		1.5 ℓ	9.2		
		1.6 ℓ	9.1		
	Valve Train	4-valves per cylinder, single overhead camshaft			
	Lubrication System	Forced and wet sump			
	Fuel Required	Unleaded gasoline with 91 R.O.N or higher		* Both leaded and unleaded gasoline can be used.	
	Engines with cata.	*Gasoline with 91 R.O.N or higher			
	Carbureted engines without cata.	Leaded gasoline with 97 R.O.N or higher			
	PGM-FI without cata.	or unleaded gasoline with 95 R.O.N. or higher			
STARTER	Type	0.8 kW	Direct		
		1.0 kW, 1.2 kW, 1.4kW	Gear reduction		
	Normal Output		0.8 kW, 1.0 kW, 1.2 kW, 1.4 kW		
	Normal Voltage		12V		
	Hour Rating		30 seconds		
	Direction of Rotation		Clockwise as viewed from gear end		
	Weight	0.8 kW HITACHI/ND	4.4 kg	9.7 lb.	
		1.0 kW MITSUBA	3.4 kg	7.5 lb.	
		ND	3.85 kg	8.5 lb.	
		1.2 kW ND	3.85 kg	8.5 lb.	
		1.4 kW MITSUBA	3.7 kg	8.2 lb.	
	TRANSMISSION	Clutch	M/T	Single plate dry, diaphragm spring	
		A/T	Torque converter		
Transmission Type		M/T	5-speed forward, synchromesh, 1-speed reverse		
		M/T + Super Low Gear	6-speed forward, synchromesh, 1-speed reverse		
		A/T	4-speed forward, with lock-up clutch, 1 speed reverse		
Primary Reduction			1.000		
			5-M/T	4-A/T	4WD 5-M/T
					4WD 4-A/T
Gear Ratio		Super low	—	—	4.512
		I	3.250	2.705	3.384
		II	1.894	1.560	1.950
		III	1.259	1.027	1.275
		IV	0.937	0.780	0.941
		V	0.771	—	0.783
		Reverse	3.153	1.954	3.000
					1.954

(cont'd)

Design Specifications

4D (cont'd)

	ITEMS		METRIC	ENGLISH	NOTES
TRANSMISSION	Final Reduction	M/T 1.2 t	Single helical gear, 4.058		KB, KW KP, KT, KU KP, KT, KU KB, KF, KG, KE, KW KX, KS, KP, KT, KU, KY KG KQ, KW KB, KG, KW, KS, KX
		1.3 t	Single helical gear, 4.250		
		1.4 t	Single helical gear, 4.058		
		1.5 t	Single helical gear, 4.250		
			Single helical gear, 4.058		
		1.6 t	Single helical gear, 4.214 (A/T)		
		1.6 t 4WD	Single helical gear, 4.250		
		A/T	Single helical gear, 4.250		
			Single helical gear, 4.428		
			Single helical gear, 3.933		
	4WDA/T	Single helical gear, 4.333			
	Clutch Facing Area		160 cm ²	24.8 sq. in.	
AIR CONDI- TIONER	Compressor		MATSUSHITA		
	Cooling Capacity		3,850 Kcal/h		
	—Conditions:		1,800 min ⁻¹ (rpm)		
	Compression min ⁻¹ (rpm)		27.0°C	81°F	
	Outside Air Temperature				
	Outside Air Humidity		50%	95°F	
	Condenser Air Temperature		35°C		
	Condenser Air Velocity		4.5 m/sec.	14.8 ft/sec.	
	Blower Capacity		440 m ³ /h	15,118 cu. ft/h	
	Compressor	Type	Vane rotary type		
		Number of Vane	3		
		Displacement	130cc/rev.	7.93 cu. in. /rev	
		Max. min ⁻¹ (rpm)	7,500 min ⁻¹ (rpm)		
	Lubricant Capacity	130 cc	7.93 cu. in.		
	Receiver Dryer With Desiccant	Includes fusible safety plug.			
	Condenser	Corrugated fin type			
	Evaporator	Corrugated fin type			
	Blower	Type	Sirocco fan		
		Motor Input	170 W (12 V)		
		Speed Control	4 speeds		
		Max. Capacity	390 m ³ /h	13,773 cu. ft/h	
	Temp. Control	Air-mix type			
	Comp. Clutch	Type	Dry, single plate, V-belt		
		Power Consumption	32 W max. 12 V		
	Refrigerant	Type	R-12		
		Quantity	0.9±0.05 kg	1.98±0.11 lb	
STEERING SYSTEM	Type		Rack and pinion		
	Overall Ratio	Manual	18.6: 1		
		Power	17.7: 1		
	Turns, Lock-to-lock	Manual	3.8		
		Power	3.6		
	Steering Wheel Diameter	except 1.6 t	377 mm	14.8 in.	
		1.6 t	370 mm	14.6 in.	
SUSPENSION SYSTEM	Type		Independent by double wishbones, coil springs		
	Shock Absorber	Front/Rear	Telescopic, hydraulic		
		Front	Telescopic, nitrogen gas-filled		
		Rear			

	ITEMS	METRIC	ENGLISH	NOTES
WHEEL ALIGNMENT	Wheel Alignment Camber Front Rear Caster Front Toe-in Front Rear Kingpin Inclination	$0'00' \pm 1'$ $-0'30' \pm 1'$ $2'59' \pm 1'$ $0 \pm 2 \text{ mm}$ $2 \pm 1 \text{ mm}$	$0 \pm 0.08 \text{ in.}$ $0.08 \pm 0.008 \text{ in.}$ $7'34'$	
BRAKE SYSTEM	Type Front 1.2 <i>ℓ</i> , 1.3 <i>ℓ</i> 1.4 <i>ℓ</i> , 1.5 <i>ℓ</i> , 1.6 <i>ℓ</i> Rear 1.6 <i>ℓ</i> Others Lining Surface Area Front 1.2 <i>ℓ</i> , 1.3 <i>ℓ</i> , 1.4 <i>ℓ</i> 1.5 <i>ℓ</i> , 1.6 <i>ℓ</i> Rear Effective Disc Diameter Front 1.2 <i>ℓ</i> , 1.3 <i>ℓ</i> , 1.4 <i>ℓ</i> , 1.5 <i>ℓ</i> 1.5 <i>ℓ</i> , 1.6 <i>ℓ</i> Rear Brake Drum I.D. Rear Parking Brake Kind and Type	Power assisted self-adjusting disc Power assisted self-adjusting ventilated disc Power assisted self-adjusting disc drum 36.8 mm^2 44.1 mm^2 50.2 mm^2 21.0 mm^2 190 mm 194 mm 208 mm 180 mm Mechanically actuating, rear two wheel brakes	5.70 sq. in. 6.84 sq. in. 7.78 sq. in. 3.25 sq. in. 7.48 in. 7.64 in. 8.19 in. 7.09 in.	Drum Disc (1.6 <i>ℓ</i>) Carbureted engine PGM-FI
TIRES	Front/Rear 1.2 <i>ℓ</i> , 1.3 <i>ℓ</i> 1.4 <i>ℓ</i> , 1.5 <i>ℓ</i> Spare 1.6 <i>ℓ</i> except 4WD 4WD	155SR13, 155R13 78S 155SR13, 165SR13 (rough road type only) 165/80R13 82S 165/70R13 79S 165/70R13 79S or 175/70R13 82H 175/70R13 82H or 175/65R14 82H T105/80D 13 T135/70D15	KB, KW KP, KT, KU KY KQ KB, KG, KX, KW, KS KF, KE, KW (1.4 <i>ℓ</i>)] Standard for some types
ELECTRICAL	Battery Starter Alternator Fuses In the dash fuse box In the main fuse box Headlights High/Low Front Turn Signal Lights Rear Turn Signal Lights Side Turn Signal Lights Stop/Taillights Side Marker Lights Back-up Lights License Plate Lights Gauge Lights Indicator Lights Warning Lights Dome Light Trunk Light Illumination and Pilot Lights Heater Illumination Lights	12V -47 AH(European), 12V -45 AH (General) 12V-0.8 kW, 1.0 kW, 1.2 kW, 1.4 kW 12V-60 amps 10A, 15A, 20A, 30A 10A, 15A, 20A, 50A, 60A 12V-60/55W 12V-21W 12V-21W 12V-5W 12V-21/5W 12V-5W 12V-21W 12V-5W 12V-3.4W, 3.0W, 1.4W 12V-1.4W 12V-5W 12V-3.4W 12V-1.4W 12V-1.4W 0.91W, 0.84W, LED 12V-1.4W		

4D H/B

	ITEMS	METRIC	ENGLISH	NOTES
DIMENSIONS	Overall Length	4,105 mm	161.6 in.	
	Overall Width	1,690 mm	66.5 in.	
		1,695 mm	66.7 in.	KY
	Overall Height	1,470 mm	57.9 in.	2WD except KY
		1,490 mm	58.7 in.	2WD KY
		1,495 mm	58.9 in.	2WD with roof rail
		1,490 mm	58.6 in.	4WD
		1,515 mm	59.6 in.	4WD with roof rail
	Wheelbase	2,500 mm	98.4 in.	
	Track, Front/Rear	1,445/1,455 mm	56.9/57.3 in.	
		1,440/1,450 mm	56.7/57.1 in.	4WD, KY 2WD
	Ground Clearance	KX, KS	155 mm	1.5 ft PGM-FI
		KF, KW, KB, KE	165 mm	1.4 ft
		KG, KS, KW	175 mm	1.6 ft with CATA
		KF, KW, KB, KE	185 mm	1.6 ft without CATA
	KQ	190 mm		
	KX	160 mm		
Seating Capacity		5		
Overhang, Front/Rear	770/835 mm		30.3/32.9 in.	Includes bumper
WEIGHTS	Engine Weight (Wet)			
	1.4 l	98 kg	216 lb.	
	1.5 l 1-Carbureted	94 kg	207 lb.	
	1.5 l 2-Carbureted	101 kg	222 lb.	
	1.5 l PGM-FI	100 kg	220 lb.	
	1.6 l	107 kg	236 lb.	
	Curb Weight			
	1.4 l M/T	965 kg	2,127 lb	KB, KE, KF
	1.4 l A/T	985 kg	2,172 lb	KB, KE, KF
	1.5 l M/T	990 kg	2,183 lb	KS, KX
	1.5 l A/T	1,010 kg	2,227 lb	KS, KX
	1.6 l M/T	1,095 kg	2,414 lb	KG, KW, KB, KE, KF
		1,105 kg	2,436 lb	KX
		1,100 kg	2,425 lb	KS
	1.6 l A/T	1,125 kg	2,480 lb	KX
	1.5 l M/T	1,127 kg	2,486 lb	KQ
		1,015 kg	2,238 lb	KY
	1.5 l A/T	1,035 kg	2,281 lb	KY
	Weight Distribution (Front/Rear)			
	1.4 l M/T	555/410 kg	1,224/904 lb	KB, KE, KF
	1.4 l A/T	575/410 kg	1,268/904 lb	KB, KE, KF
	1.5 l M/T	575/415 kg	1,268/915 lb	KS, KX
	1.5 l A/T	595/415 kg	1,312/915 lb	KS, KX
	1.6 l M/T	620/475 kg	1,367/1,047 lb	KG, KW
		625/470 kg	1,379/1,036 lb	KB, KE, KF
		630/475 kg	1,389/1,047 lb	KX
		625/475 kg	1,379/1,047 lb	KS
	1.6 l A/T	650/475 kg	1,433/1,047 lb	KX
	1.5 l M/T	636/491 kg	1,402/1,082 lb	KQ
		592/423 kg	1,305/933 lb	KY
	1.5 l A/T	621/414 kg	1,369/913 lb	KY
	Max. Permissible Weight (EC)			
	1.4 l	1,440 kg	3,175 lb	
	1.5 l	1,440 kg	3,175 lb	except "S"
	1.5 l	1,440 kg	3,108 lb	"S" only
1.6 l	1,560 kg	3,439 lb	except "S"	
1.6 l	1,520 kg	3,351 lb	"S" only	
Max. Vehicle Weight	1,470 kg	3,241 lb.	KY	
Gross Vehicle Mass (ADR)	1,540 kg	3,395 lb.	KQ	
ENGINE	Type	Water cooled 4-cycle S.O.H.C.		
	Cylinder arrangement	4-cylinder in-line, transverse		
	Bore and Stroke	1.4 l	75 x 79 mm	2.95 x 3.11 in.
		1.5 l	75 x 84.5 mm	7.95 x 3.33 in.
		1.6 l	75 x 90 mm	2.95 x 3.54 in.
	Displacement	1.4 l	1,396 cm ³ (cc)	85 cu. in.
		1.5 l	1,493 cm ³ (cc)	91 cu. in.
		1.6 l	1,590 cm ³ (cc)	97 cu. in.
	Compression Ratio			
		1.4 l	9.3	
		1.5 l	9.2	
		1.6 l	9.1	
	Valve Train	4-valves per cylinder, single overhead camshaft		
	Lubrication System	Forced and wet sump		
	Fuel Required			
Engine with CATA	Unleaded gasoline with 91 R.O.N. or higher		* Both leaded and unleaded gasoline can be used.	
Carbureted engine without CATA	* Gasoline with 91 R.O.N. or higher			
PGM-FI without CATA	Leaded gasoline with R.O.N. or higher or unleaded gasoline 95 R.O.N. or higher			

	ITEMS	METRIC	ENGLISH	NOTES
STARTER	Type	0.8 kW 1.0 kW, 1.2 kW, 1.4kW	Direct Gear reduction 0.8 kW, 1.0 kW, 1.2 kW, 1.4 kW 12V 30 seconds Clockwise as viewed from gear end	
	Normal Output Normal Voltage Hour Rating Direction of Rotation Weight	0.8 kW HITACHI/ND 1.0 kW MITSUBA ND 1.2 kW ND 1.4 kW MITSUBA	4.4 kg 3.4 kg 3.85 kg 3.85 kg 3.7 kg	9.7 lb. 7.5 lb. 8.5 lb. 8.5 lb. 8.2 lb.
TRANSMISSION	Clutch	M/T A/T	Single plate dry, diaphragm spring Torque converter	
	Transmission Type	M/T M/T + Super Low Gear	5 speeds forward, synchromesh, 1 speed reverse, 6 speeds forward, synchromesh, 1 speed reverse	
	Primary Reduction	A/T	4 speeds forward, with lock-up clutch, 1 speed reverse 1.000	
			5-M/T	4-A/T
			4WD	4WD4-A/T
	Gear Ratio	Super low I II III IV V Reverse	3.250 1.894 1.259 0.937 0.771 3.153	2.705 1.560 1.027 0.780 1.954
			4.512 3.384 1.857*1 1.950*2 1.275 0.941 0.783 3.000	2.529 1.428 0.974 0.733 1.954
	Final Reduction	M/T 1.4 ℓ 1.5 ℓ 4WD M/T A/T 4WDA/T	Single helical gear, 4.250 Single helical gear, 4.058 Single helical gear, 4.214 Single helical gear, 4.428 Single helical gear, 3.933 Single helical gear, 4.333	KX, KS KE KG
	Clutch Facing Area		160 cm ²	24.8 sq. in.
AIR CONDITIONER	Compressor		MASTUSHITA	
	Cooling Capacity		3,850 Kcal/h	
	—Conditions:			
	Compression min ⁻¹ (rpm)		1,800 min ⁻¹ (rpm)	
	Outside Air Temperature	27.0°C	81°F	
	Outside Air Humidity		50%	
	Condenser Air Temperature	35°C	95°F	
	Condenser Air Velocity	4.5 m/sec.	14.8 ft/sec.	
	Blower Capacity	440 m ³ /h	15,118 cu. ft/h	
	Compressor	Type Number of Vane Displacement Max. min ⁻¹ (rpm) Lubricant Capacity	Vane rotary type 3 130cc/rev. 7,500 min ⁻¹ (rpm) 130 cc Includes fusible safety plug.	7.93 cu. in. /rev 7.93 cu. in.
	Receiver Dryer With Desiccant			
	Condenser		Corrugated fin type	
	Evaporator		Corrugated fin type	
	Blower	Type Motor input Speed control Max. capacity	Sirocco fan 170 W (12V) 4 speeds 390 m ³ /h	13,773 cu ft/h
	Temp. Control		Air-mix type	
	Comp. Clutch	Type Power consumption	Dry, single plate, V-belt 32 W max. 12V	
	Refrigerant	Type Quantity	R-12 0.90 ± 0.05 kg	1.98 ± 0.11 lbs
STEERING SYSTEM	Type		Rack and Pinion	
	Overall Ratio Turn, lock-to-lock Steering Wheel Dia Power Steering Oil Capacity Power Steering Oil	Manual/Variable/Power Manual/Variable/Power	18.6 : 1/19.8 (18—20.4): 1/17.7 : 1 3.8/4.1/3.6 377 mm 1.2 lit. HONDA Genuine Power Steering Fluid P/N 08208—99961	14.8 in 13 U.S. qt., 1.1 Imp. qt.
SUSPENSION SYSTEM	Type, Front/Rear Shock Absorber	Front and Rear	Independent by double wishbones coil springs Telescopic, Nitrogen gas-filled	

(cont'd)


Design Specifications

4D H/B (cont'd)

	ITEMS		METRIC	ENGLISH	NOTES
WHEEL ALIGNMENT	Wheel alignment				
	Camber	Front 2WD 4WD Rear 2WD 4WD		0° ± 1° 0°35' ± 1° -0°30' ± 1° 0° ± 1° 2°59' ± 1° 2°59' ± 1°	
	Caster	Front 2WD 4WD			
	Toe-in	Front 2WD Rear 4WD	0 ± 2 mm 2 ± 1 mm	0 ± 0.08 in. 0.08 ± 0.04 in.	
	Kingpin Inclination	2WD 4WD		7°34' 6°58'	
BRAKE SYSTEM	Type	Front Rear	Power assisted self-adjusting disc drum		
	Lining Surface Area				
	Front	1.4 l, 1.5 l, 1.6 l	44.1 mm²	6.84 sq. in.	
	Rear		50.2 mm²	7.78 sq. in.	
	Effective Disc Diameter	1.4 l, 1.5 l, 1.6 l	194 mm	7.64 in.	
	Brake Drum I.D.		200 mm	7.87 in.	
	Parking Brake Kind and Type		Mechanically actuating, rear two wheel brakes		
TIRES	Size	KY 4WD Others	165/80R13 82S 175/65R14 82H or 165SR13 165/70R13 79S or 175/70R13 82H T105/80 D13 T135/70 D15		
	Spare	2WD 4WD			Standard for some types
ELECTRICAL	Battery		12 V-47 AH (European), 12 V-45 AH (General)		
	Starter		12V-0.8 kW, 1.0 kW, 1.2 kW, 1.4 kW		
	Alternator		12V-60 amps		
	Fuses	In the dash fuse box In the main fuse box	10A, 15A, 20A, 30A 10A, 15A, 20A, 50A, 60A		
	Headlights High/Low		12V-60/55W		
	Front Turn Signal Lights		12V-21W		
	Rear Turn Signal Lights		12V-21W		
	Side Turn Signal Lights		12V-5W		
	Stop/Taillights		12V-21/5W		
	Side Marker Lights		12V-5W		
	Back-up Lights		12V-21W		
	License Plate Lights		12V-5W		
	Gauge Lights		12V-3.4W, 3.0W, 1.4W		
	Indicator Lights		12V-1.4W		
	Warning Lights		12V-3.4W		
	Dome Light		12V-3.4W		
	Luggage Area Light		12V-21W		
	Illumination and Pilot Lights		12V-1.4W		
	Heater Illumination Lights		0.91W, 0.84W, LED		
	Rear Fog Lights		12V-1.4W 12V-21W		

Body Specifications

2D H/B







*1: with registration plate guard *2: 1.2 *ℓ*, 1.3 *ℓ* *3: KY

(cont'd)

Body Specifications

4D, 4D 4WD





unit: mm (in)



*1: KQ *2: with registration plate guard *3: KY *4: 4WD

4D H/B

Unit: mm (in.)




*¹: KY *²: with roof rail *³: KX, KS *⁴: KF, KW, KB, KE

(cont'd)

Body Specifications

4D H/B 4WD

Unit: mm (in.)




*1: with CATA *2: without CATA *3: KQ *4: KX

Frame Repair Chart

2D H/B

specs

Unit: mm




(cont'd)

Frame Repair Chart

4D

Unit: mm




Technical drawing of a mechanical assembly, likely a vehicle chassis or engine mount, showing a top view and three cross-sections (AA, BB, CC). The drawing includes numerous dimensions, points of interest (A through V), and section lines. Key features include a central engine mount, various arms, dampers, and cross beams. The top view shows a symmetrical design with a central vertical line and a horizontal center line. Dimensions are given in inches and millimeters. Points of interest are labeled with letters and numbers, indicating specific locations on the assembly. Cross-sections AA, BB, and CC provide detailed views of the internal structure and components at specific points along the assembly.

(cont'd)

4D H/B

[illegible]

Unit: mm



Maintenance


Lubrication Points.....	4-2
Maintenance Schedule	4-4




Lubrication Points

No.	LUBRICATION POINTS	LUBRICANT
1	Engine	API Service Grade: SE, SF or SG SAE Viscosity: See chart below
2	Transmission Manual	API Service: SE or SF SAE Viscosity: See chart below
	Automatic	DEXRON® or DEXRON®II Automatic transmission fluid
3	Brake line (ALB line for ALB models)	Brake fluid DOT 3 or DOT 4
4	Power steering system	Honda power steering fluid P/N 08208—99961
5	Power steering gearbox	Honda steering grease P/N 08733—B070E
6	Shift lever pivot (Manual transmission)	Silicone grease with molybdenum disulfide
7	Tilt steering	Multi-purpose Grease
8	Steering ball joints	
9	Suspension ball joints	
10	Steering boots	
11	Steering gearbox (Manual steering)	
12	Steering column bushings	
13	Select lever (Automatic transmission)	
14	Pedal linkage	
15	Brake master cylinder push rod	
16	Tailgate hinges and Trunk hinges	
17	Door hinges upper and lower	
18	Door opening detents	
19	Fuel filler lid	
20	Engine hood hinges	
21	Engine hood latch	
22	Rear brake shoe linkage	
23	Caliper Piston seal Dust seal Caliper pin Piston	Silicone Grease
24	Rear Differential (4WD only)	Hypoid Gear oil (API GL4 or GL5) above 5°C (41°F) SAE90, below 5°C (41°F) SAE 80

Recommended Engine Oil
(SE, SF or SG Grade oil)




Recommended Manual Transmission Oil




CAUTION: Used engine oil may cause skin cancer if repeatedly left in contact with the skin for prolonged periods. Although this is unlikely unless you handle used oil on a daily basis, it is still advisable to thoroughly wash your hands with soap and water as soon as possible after handling used oil.

2WD:



4WD:



Maintenance Schedule

Service at the interval listed x 1,000 km (or miles) or after that number of months, whichever comes first.	R—Replace C—Clean	I—Inspect. After inspection, clean, adjust, repair or replace if necessary.				
ITEM	x 1,000 km x 1,000 miles months	20 12 12	40 24 24	60 36 36	80 48 48	100 60 60
Idle speed and idle CO*3		I	I	I	I	I
Idle speed and idle CO*4						I
Valve clearance		I	I	I	I	I
Alternator drive belt			I		I	
Timing belt						R
Water pump						I
■Engine oil and oil filter	Replace every 10,000 km (6,000 miles) or 6 months					
■Transmission oil			R		R	
■Radiator coolant					R*1	
Cooling system hoses and connections			I		I	
Air cleaner element (Viscous type for European and KQ models)			R		R	
Air cleaner element (Dry type except European and KQ models)	R	R	R	R	R	R
Fuel filter			R		R	
Tank, fuel line and connections			I		I	
Intake air temp. control system*5						I
Throttle control system*5			I		I	
Choke mechanism*5			I		I	
Choke mechanism*6				C*7		I
Evaporative emission control system (for cars using unleaded gasoline and KY model)						I
Ignition timing and control system*3			I		I	
Ignition timing and control system*4						I
Spark plugs (for cars using unleaded gasoline)			R*2		R*2	
Spark plugs (for cars using leaded gasoline)	R	R	R	R	R	R
Distributor cap and rotor*3			I		I	
Distributor cap and rotor*4						I
Ignition wiring*3			I		I	
Ignition wiring*4						I
Positive crankcase ventilation valve*3			I		I	
Positive crankcase ventilation valve*4						I
Blow-by filter*5			I		I	

■: These service intervals assume routine checking and replenishment has been done, as needed, by the customer.

*1 Thereafter, replace every 2 years or 40,000 km (24,000 miles), whichever comes first.

*2 For KS type, replace every 2 years or 40,000 km (24,000 miles) whichever comes first after 30,000 km (18,000 miles).

*3 Except KS, KX models

*4 KS, KX models

*5 Only for carbureted types (except KS model)

*6 Only for carbureted type (KS model)

*7 Recommended by manufacturer only



Service at the interval listed x 1,000 km (or miles) or after that number of months, whichever comes first.	R—Replace		I—Inspect. After inspection, clean, adjust, repair or replace if necessary.			
ITEM	x 1,000 km x 1,000 miles months	20 12 12	40 24 24	60 36 36	80 48 48	100 60 60
Brake hoses and lines (Including ALB hoses and pipes for ALB models)		I	I	I	I	I
Brake fluid (Including ALB fluid for ALB models)			R		R	
Front brake discs and calipers		I	I	I	I	I
Front brake pads		Inspect every 10,000 km (6,000 miles) or 6 months				
Rear brake discs, calipers and pads (for disc brake type)			I		I	
Rear brake drums, wheel cylinders and linings (for drum brake type)			I		I	
Parking brake		I	I		I	
Clutch release arm travel		I	I	I	I	I
Exhaust pipe and muffler		I	I	I	I	I
Suspension mounting bolts		I	I	I	I	I
Front wheel alignment		I	I	I	I	I
Steering operation, tie rod ends, steering gear box and boots		I	I		I	
ALB high pressure hose (for ALB models)					R	
ALB operation (for ALB models)		I	I		I	
Rear differential clutch operation (for ALB models)		I	I		I	
Power steering system (Standard for some types)		I	I	I	I	I
Power steering pump belt (Standard for some types)			I		I	
Catalytic converter heat shield (Standard for some types)					I	

CAUTION: The following items must be serviced more frequently on cars normally used under severe driving conditions. Refer to the chart below for the appropriate maintenance intervals.

Severe driving conditions include :

A : Repeated short distance driving

B : Driving in dusty conditions

C : Driving in severe cold weather

D : Driving in areas using road salt or other corrosive materials

E : Driving on rough and/or muddy roads

F : Towing a trailer

R—Replace.

I—Inspect. After inspection, clean, adjust, repair or replace if necessary.

Condition	Maintenance item	Maintenance operation	Interval
A B . . . F	Engine oil and oil filter	R	Every 5,000 km (3,000 miles) or 3 months
. F	Transmission oil	R	Every 20,000 km (12,000 miles) or 12 months
A B . D E F	Front brake discs and calipers	I	Every 10,000 km (6,000 miles) or 6 months
A B . D E F	Rear brake discs, calipers and pads	I	Every 20,000 km (12,000 miles) or 12 months
A B C . E F	Clutch release arm travel	I	Every 10,000 km (6,000 miles) or 6 months
. B C . E .	Power steering system	I	Every 10,000 km (6,000 miles) or 6 months

CAUTION: Used engine oil may cause skin cancer if repeatedly left in contact with the skin for prolonged periods. Although this is unlikely unless you handle used oil on a daily basis, it is still advisable to thoroughly wash your hands with soap and water as soon as possible after handling used oil.

Engine

This section contains only on-frame servicing and removal/installation. For detail, refer to the D12B/D13B/D14A/D15B/D16A Engine Maintenance and Repair (62 PM100).

Engine Tune-up	5 — 1
Timing Belt	5 — 15
Engine Removal/Installation	5 — 19
Oil Pan	5 — 23
Exhaust Pipe and Muffler	5 — 27
Radiator	5 — 29



Engine Tune-up

Special Tools	5 — 2
Coolant Level Inspection	5 — 3
Engine Oil Replacement	5 — 3
Oil Filter Replacement	5 — 4
Alternator Belt Adjustment	5 — 7
A/C Compressor Belt Adjustment	5 — 8
P/S Pump Belt Adjustment	5 — 9
Idle Speed Inspection/Adjustment....	5 — 10




Outline of Model Changes

- The coolant refill capacity has been changed.
- The grade of the recommended engine oil has been changed.
- The oil filter has been changed.
- The inspection of the belt tension has been added.
- The idle speed has been changed.


Special Tools

Special Tools


Ref. No.	Tool Number	Description	Q'ty	Remarks
①	07912-6110001	Oil Filter Socket	1	
②	07JAZ-SH20100	R.P.M. Connecting Adaptor	1	
③	07JGG-0010100	Belt Tension Gauge	1	



①



②



③


Engine Tune-up



Coolant Level Inspection

CAUTION: When supplying coolant, be sure to shut the relay box lid and not to let coolant spill on the electrical parts or the painted portion. If any coolant spills, rinse it off immediately.

1. Check whether the coolant level in the coolant reservoir tank is between "MAX" and "MIN".



2. Supply the coolant reservoir tank with coolant to "MAX", if the coolant level is lower than "MIN" or near to "MIN".

NOTE:

- Use only HONDA-RECOMMENDED anti-freeze/coolant.
- For best corrosion protection, the coolant concentration must be maintained year-round at 50% MINIMUM. Coolant concentrations less than 50% may not provide sufficient protection against corrosion or freezing.
- Coolant concentrations greater than 60% will impair cooling efficiency and are not recommended.

CAUTION:

- Do not mix different brand anti-freeze/coolants.
- Do not use a additional rust inhibitors or antirust products; they may not be compatible with the recommended coolant.

Radiator Coolant Refill Capacity:

	M/T	A/T
	ℓ (US qt, Imp qt)	
1.2 ℓ, 1.3 ℓ, 1.4 ℓ	4.4 (4.6, 3.9)	4.3 (4.5, 3.8)
1.5 ℓ (Cabureted)	4.5 (4.7, 4.0)	4.4 (4.6, 3.9)
1.5 ℓ (PGM-FI) 70 ps	4.4 (4.6, 3.9)	4.3 (4.5, 3.8)
1.5 ℓ (PGM-FI)	4.5 (4.7, 4.0)	4.4 (4.6, 3.9)
1.6 ℓ DOHC	4.5 (4.7, 4.0)	
1.6 ℓ SOHC (2WD)	4.4 (4.6, 3.9)	
1.6 ℓ SOHC (4WD)	4.4 (4.6, 3.9)	4.9 (5.2, 4.3)


(including the reservoir capacity : 0.4 ℓ (0.42 US qt, 0.35 Imp qt))

Engine Oil Replacement

1. Warm up the engine.
2. Drain the engine oil.

CAUTION: Used engine oil may cause skin cancer if repeatedly left in contact with the skin for prolonged periods. Although this is unlikely unless you handle used oil on a daily basis, it is still advisable to thoroughly wash your hands with soap and water as soon as possible after handling used oil.

NOTE: Remove the filler cap to speed draining.



OIL PAN DRAIN PLUG
45 N·m (4.5 kg-m, 33 lb-ft)

3. Reinstall the drain plug with a new washer, and refill with the recommended oil.


(cont'd)

Engine Tune-up

Engine Oil Replacement (cont'd)

Capacity	SOHC: 3.0 lit (3.2 US qt, 2.7 Imp. qt) DOHC: 3.3 lit (3.5 US qt, 2.9 Imp. qt) excluding oil filter SOHC: 3.5 lit (3.7 US qt, 3.1 Imp. qt) DOHC: 3.8 lit (4.0 US qt, 3.4 Imp. qt) at change, including filter SOHC: 4.0 lit (4.2 US qt, 3.5 Imp. qt) DOHC: 4.3 lit (4.6 US qt, 3.8 Imp. qt)
Change	Every 10,000 km (6,000 miles) or 6 months

Recommended Engine Oil SF or SG (also SE for DOHC)



Engine oil viscosity for ambient temperature ranges.

NOTE: Oil filter should be replaced at each oil change.


Oil Filter Replacement

▲WARNING After the engine has been run, the exhaust pipes will be hot; be careful when working around the exhaust manifold.

CAUTION: Used engine oil may cause skin cancer if repeatedly left in contact with the skin for prolonged periods. Although this is unlikely unless you handle used oil on a daily basis, it is still advisable to thoroughly wash your hands with soap and water as soon as possible after handling used oil.

1. Remove the oil filter with the special oil filter socket.
2. Inspect the threads and rubber seal on the new filter. Wipe off the filter seat on the engine block and apply a light coat of oil to the filter rubber seal.

NOTE: Use only filters with a built-in bypass system.






3. Install the oil filter by hand.
4. After the rubber seal is seated, tighten the oil filter clockwise with the special tool.

Tighten: 7/8 turn clockwise.

Tightening torque: 22 N·m (2.2 kg-m, 16 lb-ft)


CAUTION: Installation other than the above procedure could result in serious engine defects due to oil leakage.



Eight numbers (1 to 8) are printed on the surface of the filter.

The following explains the procedure for tightening filters using these numbers.

- 1) Make a mark on the cylinder block under the number that shows at the bottom of the filter when the rubber seal is seated.
- 2) Tighten the filter by turning it clockwise seven numbers from the marked point. For example, if a mark is made under the number 2 when the rubber seal is seated, the filter should be tightened until the number 1 aligns with the marked point.



Number when rubber seal is seated.

Number after tightening.

Number when rubber seal is seated	1	2	3	4	5	6	7	8
Number after tightening	8	1	2	3	4	5	6	7

5. After installation, fill the engine with oil up to the specified level, run the engine for more than 3 minutes, then check for oil leakage.

Engine Tune-up

Drive Belts Inspection


Drive Belts Deflection:

(When applying a force of 98 N (10 kg, 22 lb))

	Used Belt	New Belt
① Alternator Belt	9.0—11.0 mm (0.35—0.43 in.)	7.0—9.0 mm (0.28—0.35 in.)
② A/C Compressor Belt	9.0—11.0 mm (0.35—0.43 in.)	7.0—9.0 mm (0.28—0.35 in.)
③ P/S Pump Belt	9.0—12.0 mm (0.35—0.47 in.)	7.0—10.0 mm (0.28—0.39 in.)

Measure with the belt tension gauge:

	Used Belt	New Belt
Ⓐ Alternator Belt	294—392 N (30—40 kg) (66—88 lb)	392—588 N (40—60 kg) (88—132 lb)
Ⓑ A/C Compressor Belt	343—441 N (35—45 kg) (77—99 lb)	441—686 N (45—70 kg) (99—154 lb)
Ⓒ P/S Pump Belt	343—490 N (35—50 kg) (77—110 lb)	441—686 N (45—70 kg) (99—154 lb)






Alternator Belt Adjustment

1. Apply a force of 98 N (10 kg, 22 lb) and measure the deflection between the alternator and the crankshaft pulley.

Deflection : 9.0—11.0 mm (0.35—0.43 in.)

NOTE :

- On a brand-new belt, the deflection should be 7.0—9.0 mm (0.28—0.35 in.) when first measured.
- If there are cracks or any damage evident on the belt, replace it with a new one.




Measure with the belt tension gauge:

Attach the belt tension gauge to the belt and measure the tension of the belt.

Tension : 294—392 N (30—40 kg, 66—88 lb)

NOTE :

- On a brand-new belt, the tension should be 392—588 N (40—60 kg, 88—132 lb) when first measured.
- See the instruction for the belt tension gauge.
- If there are cracks or any damage evident on the belt, replace it with a new one.



2. Loosen the alternator adjusting bolt and alternator nut.
3. Move the alternator to obtain the proper belt tension, then retighten the adjusting bolt and alternator nut.
4. Recheck the deflection of the belt.
5. After adjusting, if necessary, adjust the A/C compressor belt (See page 5 — 8) and P/S pump belt (See page 5 — 9).

Engine Tune-up


A/C Compressor Belt Adjustment

NOTE: If there are cracks or any damage evident on the belt, replace it with a new one.

1. Apply a force of 98 N (10 kg, 22 lb) and measure the deflection, between the A/C compressor idler pulley and the crankshaft pulley.

Deflection : 9.0—11.0 mm (0.35—0.43 in.)

NOTE : On a brand-new belt, the deflection should be 7.0—9.0 mm (0.28—0.35 in.) when first measured.




Measure with the belt tension gauge:

Attach the belt tension gauge to the belt and measure the tension of the belt.

Tension : 343—441 IN (35—45 kg, 77—99 lb)

NOTE :

- On a brand-new belt, the tension should be 441—686 N (45—70 kg, 99—154 lb) when first measured.
- See the instruction for the belt tension gauge.



2. Loosen the idler pulley nut.
3. Turn the adjusting bolt to get the proper belt tension, then retighten the bolt.
4. Recheck the deflection of the belt.




P/S Pump Belt Adjustment

NOTE: If there are cracks or any damage evident on the belt, replace it with a new one.

1. Apply a force of 98 N (10 kg, 22 lb) and measure the deflection, between the P/S pump pulley and the crankshaft pulley.

Deflection: 9.0–12.0 mm (0.35–0.47 in.)

NOTE: On a brand-new belt, the deflection should be 7.0–10.0 mm (0.28–0.39 in.) when first measured.



Measure with the belt tension gauge:


Attach the belt tension gauge to the belt and measure the tension of the belt.

Tension: 343–490 N (35–50 kg, 77–110 lb)


NOTE:

- On a brand-new belt, the tension should be 441–686 N (45–70 kg, 99–154 lb) when first measured.
- See the instruction for the belt tension gauge.

BELT TENSION GAUGE
07JGG-0010100



2. Loosen the bolts and move the power steering pump to get proper tension, then retighten the special bolts.



24 N·m
(2.4 kg-m, 17 lb-ft)

3. Start the engine and turn the steering wheel from lock to lock several times, then recheck the belt tension.

Engine Tune-up

Idle speed Inspection/Adjustment

Carbureted Engine :

Inspection/Adjustment Propane Enrichment Method


⚠ WARNING Do not smoke during this procedure.
Keep any open flame away from your work area.

NOTE :


- This procedure requires a propane enrichment kit.
- Check that the warning light and self diagnosis indicator before making idle speed and mixture inspections.

1. Start the engine and warm up to normal operating temperature (the cooling fan comes on). Turn the ignition switch OFF. Start the engine with idle for two minutes and keep the engine speed $2,500-3,000 \text{ min}^{-1}$ (rpm) for a one minute.
2. Disconnect the #8 vacuum hose from the intake air control diaphragm and clamp the hose end.

AIR CONTROL DIAPHRAGM



3. Connect a tachometer.




4. Check idle speed with the headlights, heater blower, rear window defogger, cooling fan and air conditioner off.

Idle speed should be :


Manual : $800 \pm 50 \text{ min}^{-1}$ (rpm)

Adjust the idle speed, if necessary, by turning the throttle stop screw.

NOTE : If the idle speed is excessively high, check the throttle control (page 6-39).




5. Disconnect the 2P connector from the EACV and disconnect the hose from vacuum hose manifold, then cap the hose end.





6. Disconnect air cleaner intake tube from air intake duct.
7. Insert the hose of the propane enrichment kit into the intake tube about 4-inches.


NOTE : Check that propane bottle has adequate gas before beginning test.



PROPANE ENRICHMENT KIT

8. With engine idling, depress push button on top of propane device, then slowly open the propane control valve to obtain maximum engine speed. Engine speed should increase as percentage of propane injected goes up.

NOTE : Open the propane control valve slowly ; a sudden burst of propane may stall the engine.




RPM increase should be :

Manual : $40 \pm 20 \text{ min}^{-1} \text{ (rpm)}$

- If engine speed does not increase per specification, mixture is improperly adjusted. Go to step 9.
- If engine speed increase per specification, go to step 10.

9. Remove the mixture adjusting screw hole caps, and recheck maximum propane enriched rpm.



- If the propane enriched speed is too low, mixture is too rich :
turn both mixture screws $1/4$ turn clockwise and recheck.
- If the propane enriched speed is too high, mixture is too lean :
turn both mixture screws $1/4$ turn counterclockwise and recheck.

10. Reconnect the connector and hose. Close the propane control valve.
11. Remove the ECU fuse for 10 seconds to reset control unit and recheck idle speed. Turn the ignition switch OFF. Start the engine with idle for two minutes and keep the engine speed should be :

Manual : $800 \pm 50 \text{ min}^{-1} \text{ (rpm)}$

- If idle speed is as specified (Step 4), go to step 12.
- If idle speed is not as specified, adjust by turning throttle stop screws, then repeat step 9.


12. Remove propane enrichment kit and reconnect air cleaner intake tube on the air intake duct.

(cont'd)

Idle Speed Inspection/Adjustment (cont'd)


Carbureted Engine (cont'd) :

13. Reinstall the mixture adjusting screw hole cap.
14. Disconnect the # 20 vacuum hose from the idle boost throttle controller and connect a vacuum pump.




15. Apply vacuum, then check the idle speed with the headlight, heater blower, rear window defogger and cooling fan on.

Idle speed should be : $800 \pm 50 \text{ min}^{-1} \text{ (rpm)}$



Adjust the idle speed, if necessary, by turning the adjusting screw A.

16. Disconnect the vacuum pump and connect the # 20 vacuum hose, then check the idle speed with the headlight, heater blower, rear window defogger and cooling fan OFF.
17. If equipped with air conditioner, check the idle speed with the A/C on.
Idle speed should be : $800 \pm 50 \text{ min}^{-1} \text{ (rpm)}$



ADJUSTING SCREW B

Adjusting the idle speed, if necessary, by turning the adjusting screw B.

18. If the idle speed does not reach the specified idle speeds in steps 14 though 17, go to idle control system testing (page 6-12).

CO Meter Method

⚠ WARNING Do not smoke during this procedure.
Keep any open flame away from your work area.

1. Follows steps 1 through 5 of the propane enrichment method.
2. Warm up and calibrate the CO meter according to the meter manufacture instructions.
3. Turn the engine off, restart the engine and complete the idle CO check within three minutes of restarting, with the headlights, heater blower, window defogger, cooling fan and air conditioner off.

CO meter should indicate 0.1% maximum.


If the idle CO is not within the specification, check the engine tune-up condition.




1.5 l Fuel Injected Engine :

Inspection/Adjustment

1. Start the engine and warm it up to normal operating temperature (the cooling fan comes on).
2. Connect a tachometer.



3. Disconnect the 2P connector from the EACV.



4. Check idling in no-load conditions in which the headlights, blower fan, rear defogger, cooling fan, and air conditioner are not operating.


Idle speed should be:

Manual	$625 \pm 50 \text{ min}^{-1} \text{ (rpm)}$
Automatic	$625 \pm 50 \text{ min}^{-1} \text{ (rpm)}$ (in N or P)

Adjust the idle speed, if necessary, by turning the idle adjusting screw.

NOTE: If the idle speed is excessively high, check the throttle control system.

IDLE ADJUSTING SCREW



5. Turn the ignition switch OFF.
6. Reconnect the 2P connector on the EACV, then remove HAZARD fuse in the main fuse box for 10 seconds to reset ECU.
7. Restart and idle the engine with no-load conditions in which the headlights, blower fan, rear defogger, cooling fan, and air conditioner are not operating for one minute, then check the idle speed.

Idle speed should be:

Manual	$800 \pm 50 \text{ min}^{-1} \text{ (rpm)}$
Automatic	$800 \pm 50 \text{ min}^{-1} \text{ (rpm)}$ (in N or P)

8. Idle the engine for one minute with headlights (Hi) and rear defogger ON and check the idle speed.
If applicable, with Automatic transmission models, idle the engine for one minute in gear (except **N** or **P**) and check the idle speed.
Idle speed should be: $800 \pm 50 \text{ min}^{-1} \text{ (rpm)}$
9. Idle the engine for one minute with heater fan switch at HI (right end) and air conditioner on, then check the idle speed.

Idle speed should be: $800 \pm 50 \text{ min}^{-1} \text{ (rpm)}$

NOTE: If the idle speed is not within specifications, see System Troubleshooting Guide on page 6-60.

Timing Belt

Special Tools.....5 — 16

Illustrated Index5 — 17



Outline of Model Change


The service interval for the timing belt has been added.

Special Tools


Ref. No.	Tool Number	Description	Q'ty	Remarks
①	07JAB-0010000	Crank Pulley Holder Set	1	for Crankshaft pulley bolt
①-1	07JAA-0010100	Socket wrench 17 mm	(1)	
①-2	07JAB-0010100	Pulley Holder Attachment	(1)	
①-3	07JAB-0010200	Handle	(1)	



①-1



①-2



①-3


Timing Belt

Illustrated Index



NOTE :

- Refer to page 5-7, for alternator belt adjustment.
- Refer to page 5-8, for A/C compressor belt adjustment.
- Refer to page 5-9, for P/S pump belt adjustment.
- Before removing, mark direction of rotation.



Engine Removal/Installation



Outline of Model Change

The automatic transmission (4WD) has been adopted.


Engine Removal/Installation

4WD A/T only:

- Remove the cable clip and the control pin.
- Loosen the shift control cable nut, then remove the control cable.


NOTE:

- Take care not to bend the cable when removing it and lift the cable hanging by wire up to the body.
- On assembly, check the cable adjustment.





Additional Torque Specifications:



Oil Pan

Replacement5 — 24



Outline of Model Change

The automatic transmission (4WD) has been adopted.

Oil Pan


Replacement (4WD A/T)

⚠ WARNING

- Make sure jacks and safety stands are placed properly and hoist brackets are attached to correct positions on the engine. (See Section 1)
- Apply parking brake and block rear wheels, so car will not roll off stands and fall on you while working under it.

Removal:



1. Remove the engine splash shield.
2. Drain the engine oil.
3. Drain the transmission oil.
4. Remove the exhaust pipe A.
5. Disconnect the propeller shaft at the transmission (page 5-8).
6. Remove the transmission splash shield.
7. Remove the driven gear assembly from the transfer case.



8. Remove the transfer left side cover and then the drive gear from the transfer case. In this procedure, rotate the cover using the bolt as the axis, which bolt is unable to be removed from the cover.

NOTE:

Be careful not to damage the thrust sim and mating surface.




9. Remove the transfer case from the clutch housing.
10. Remove the clutch case cover.
11. Remove the oil pan by removing the bolts and nuts.



Installation:

Installation in the reverse order of removal.


1. Thoroughly clean the mating surface of the oil pan and engine case. Apply liquid gasket to both surface of the gasket.



NOTE:

- Replace gaskets and O-rings at disassembly.
- Use Honda genuine liquid gasket, Part NO. OY740-99986.
- Check that the mating surfaces are clean and dry before applying liquid gasket.
- Apply liquid gasket evenly, in a narrow bead centered on the mating surface.
- To prevent leakage of oil, apply liquid gasket to the inner threads of oil, apply liquid gasket to the inner threads of the bolt holes.
- Do not install the parts if 20 minutes or more have elapsed since applying liquid gasket. In that case, reapply liquid gasket after removing old residue.
- Fill the case with clean engine oil 30 minutes after assembly.


2. Tighten the bolts as shown below.
Torque: 12 N·m (1.2 kg-m, 9 lb-ft)




NOTE:

Tighten bolts and nuts in two steps and torque the bolts in a criss-cross pattern.

3. Apply liquid gasket to the clutch housing mating surface of the transfer case.




4. Attach the O-ring to transfer left side cover as shown below.



5. Install the transfer case on the clutch housing. Set the bolt through the transfer case and clutch housing as shown below.

NOTE:

Be careful not to damage the thrust shim and mating surface, and keep them clean.



(cont'd)



Oil Pan

Replacement (4WD A/T) (cont'd)


6. Install the following parts on and in the transfer shaft and transfer case.
- Drive gear thrust shim
 - Drive gear (lubricate with oil)
 - Transfer thrust shim
 - Transfer left side cover

NOTE:

Be careful not to damage the thrust shim and mating surface, and keep them clean.



7. Install the following parts in the transfer case.
- Driven gear thrust shim
 - Driven gear



8. If necessary, perform the following inspections
- Tooth contact between the transfer the driven and drive gears
 - The backlash at the companion flange
 - The backlash at the transfer frange
 - The transfer driven gear preload
 - The total preload

Exhaust Pipe and Muffler




Outline of Model Change

The exhaust pipe has been changed.

Exhaust Pipe and Muffler

Carbureted engine without CATA:



Radiator

Water Pump Inspection5 — 30



Outline of Model Change


The inspection of the water pump has been added.

Water Pump

Inspection

1. Remove the timing belt.
2. Check the water pump pulley turns freely.
3. Check the signs of seal leakage.

NOTE: Small amount of "weeping" from the bleed hole is normal.



Fuel and Emission

Carbureted Engine	6 — 1
PGM-FI Engine	6 — 75



Fuel and Emissions (Carbureted Engine)

Special Tools	6 - 2	Emission Control System	
Component Locations		Symptom-to-sub System Chart	6 - 38
Index	6 - 3	Throttle Control System	6 - 39
System Description		Positive Crankcase Ventilation	6 - 40
Vacuum Connections	6 - 5	Evaporative Emission Controls	6 - 41
Electrical Connections	6 - 8	Troubleshooting	
Carburetor		Self-Diagnostic Procedures	6 - 47
Symptom-to-System Chart	6 - 10	How to Read Flow Charts	6 - 49
Idle Control System	6 - 12	PGM-CARB Control System	
Power Valve	6 - 17	Symptom-to-System Chart	6 - 50
Slow Air jet Control System	6 - 20	Troubleshooting Flow Charts	
Primary Slow Mixture Cut-off		Oxygen Sensor	6 - 52
Solenoid Valve	6 - 22	Vehicle Speed Sensor	6 - 54
Idle Speed/Mixture	6 - 24	Manifold Absolute Pressure	
Automatic Choke and Fast Idle		Sensor	6 - 56
Choke Coil Tension and Linkage	6 - 28	Vacuum Switch	6 - 59
Fast Unloader	6 - 28	Coolant Temperature Sensor	6 - 62
Choke Opener	6 - 29	Ignition Coil Signal	6 - 64
Choke coil Heater	6 - 30	Intake Air Temperature Sensor	6 - 65
Linkage Adjustment	6 - 31	EACV	6 - 67
Fuel Supply System		Input Troubleshooting Flow Chart	
Symptom-to-Sub System Chart	6 - 33	Power Source (IG1, Bat) and	
Fuel Filters	6 - 34	Ground	6 - 69
Air Intake System		Clutch Switch Signal	6 - 70
Symptom-to-sub System Chart	6 - 35	Air Conditioning Signal	6 - 72
Intake Air Control System	6 - 36	A/C Clutch Relay	6 - 73




Outline of Model Change

• The D13B engine (1.3 ℓ SOHC 1-Carbureted PGM-CARB Engine) has been adopted. [KG, KS model]


Special Tools

Special Tools


Ref. No.	Tool Number	Description	Q'ty	Remarks
①	07JAZ—SH20100	R.P.M. Connecting Adaptor	1	
②	07614—0050100	Fuel Line Clamp	1	
③	07HAZ—PJ70000	ECU Test Harness A	1	
④	07HAZ—PJ70100	ECU Test Harness B	1	
⑤	07411—0020000	Digital Circuit Tester	1	
⑥	07GMJ—ML80100	Test Harness	1	




①



②




③



④



⑤




⑥

Component Locations



Index



[1-Carbureted Engine, KG, KS]



(cont'd)


Component Locations

Index (cont'd)




System Description


Vacuum Connections



System Description

Vacuum Connections (cont'd)






- ① IGNITION CONTROL SOLENOID VALVE
- ② AIR VENT CUT-OFF SOLENOID VALVE
- ③ AIR LEAK SOLENOID VALVE
- ④ FAST IDLE UNLOADER
- ⑤ PRIMRY SLOW MIXTURE CUT-OFF SOLENOID VALVE
- ⑥ THROTTLE CONTROLLER
- ⑦ VACUUM SWITCH
- ⑧ IDLE BOOST THROTTLE CONTROLLER
- ⑨ IDLE BOOST SOLENOID VALVE
- ⑩ A/C IDLE BOOST SOLENOID VALVE

- ⑪ CHOKE OPENER
- ⑫ PURGE CUT SOLENOID VALVE
- ⑬ ELECTRONIC AIR CONTROL VALVE (E. A. C. V)
- ⑭ MANIFOLD ABSOLUTE PRESSURE (MAP) SENSOR
- ⑮ POWER VALVE CONTROL SOLENOID VALVE
- ⑯ CHARCOAL CANISTER
- ⑰ PURGE CONTROL VALVE
- ⑱ TWO-WAY VALVE


System Description

Electrical Connections



- ① PRIMARY SLOW MIXTURE CUT-OFF SOLENOID VALVE
- ② POWER VALVE CONTROL SOLENOID VALVE
- ③ PURGE CUT SOLENOID VALVE
- ④ AIR LEAK SOLENOID VALVE
- ⑤ IDLE BOOST SOLENOID VALVE
- ⑥ IGNITION CONTROL SOLENOID VALVE
- ⑦ AIR VENT CUT-OFF SOLENOID VALVE

TERMINAL LOCATION



Carburetor

Symptom-to-System Chart

NOTE:

- Across each row in the chart, the sub systems that could be sources of a symptom are ranked in the order they should be inspected, starting with ①. Find the symptom in the left column, read across to the most likely source, then refer to the page listed at the top of that column. If inspection shows the system is OK, try the next system ②, etc.
- Before starting inspection, check that other items that affect engine performance are within specification. Check the self-diagnosis indicator, valve clearance, air cleaner, and PCV valve. In addition, check the ignition timing, function of the vacuum and centrifugal advance, and the condition of the spark plugs. If those items are all within specifications, begin with the troubleshooting listed in pages 6-26 and 6-27.

PAGE		SYSTEM	CARBURETOR			
			IDLE SPEED/ MIXTURE	IDLE CONTROL	AUTOMATIC CHOKE/ FAST IDLE SYSTEM	AIR VENT CUT-OFF SOLENOID VALVE
SYMPTOM			24	12	28	45
ENGINE WON'T START						①
DIFFICULT TO START ENGINE WHEN COLD	WHEN COLD				①	②
	WHEN WARM					②
IRREGULAR IDLING	WHEN COLD FAST IDLE OUT OF SPECIFICATION				①	
	WHEN WARM ENGINE SPEED TOO HIGH		①	②	③	
	WHEN WARM ENGINE SPEED TOO LOW		①	①		
	ROUGH IDLE/ FLUCTUATION		①	③		②
FREQUENT STALLING	WHILE WARMING UP			②	①	
	AFTER WARMING UP		①	②		②
POOR PERFORM- ANCE	MISFIRE OR ROUGH RUNNING				②	①
	LOSS OF POWER					②
	AFTERBURN		②			
	HESITATION/ SURGE					



CARBURETOR				FUEL SUPPLY	AIR INTAKE	EMISSION CONTROL
POWER VALVE	PRIMARY SLOW MIXTURE CUT-OFF SOLENOID VALVE	SLOW AIR JET CONTROL	ACCELERATOR PUMP			
17	22	20	—	33	35	47
	②	②		①		③
	①		②			③
	①	②				③
	②					③
						③
		②				②
		③				②
	①					③
	①	①				③
				③		③
③			③	②	①	①
					②	①
			②		②	①

Carburetor

Idle Control System

Testing

NOTE: Snap the accelerator pedal several times and check the idle speed with the accelerator pedal fully returned.


1. Start the engine and warm up to normal operating temperature (the cooling fan comes on).
2. Check the idle speed with headlights, heater blower, rear window defogger, cooling fan and air conditioner off.

Idle speed should be:

Manual $800 \pm 50 \text{ min}^{-1}$ (rpm)

- If OK, go to step 4.
 - If not, go to step 3.
3. Disconnect the two vacuum hoses at idle boost throttle controller and check each for vacuum.

There should be no vacuum in both hoses.




- If there is no vacuum, check the throttle valve shaft for binding or sticking and replace the idle boost throttle controller.
- If there is vacuum at the #20 vacuum hose, go to idle boost solenoid valve troubleshooting (page 6-13).
- If there is vacuum at the outside vacuum hose, go to A/C idle boost solenoid valve troubleshooting (page 6-15).

4. Disconnect the #20 vacuum hose at idle boost throttle controller and check vacuum.

NOTE: The engine coolant temperature must be below 80°C (176°F).


There should be vacuum.



- If there is vacuum, check the throttle valve shaft for binding or sticking and replace the idle boost throttle controller.
 - If there is no vacuum, go to the idle boost solenoid valve troubleshooting (page 6-13).
5. Check the idle speed with the A/C on.

Idle speed should be: $800 \pm 50 \text{ min}^{-1}$ (rpm)

- If not, disconnect the two vacuum hose at idle boost throttle controller and check each for vacuum. There should be vacuum in both hoses.



- If there is vacuum in both hoses, replace the idle boost throttle controller.
- If there is no vacuum at the #20 vacuum hose, go to idle boost solenoid valve troubleshooting (page 6-35).
- If there is no vacuum at the outside vacuum hose, go to A/C idle boost solenoid valve troubleshooting (page 6-15).



Troubleshooting Flow Chart Idle Boost Solenoid Valve

Inspection of Idle Boost Solenoid Valve.

Open the control box.

Disconnect the lower vacuum hose of the solenoid valve from the 6 way joint and connect a vacuum pump.

Disconnect #20 vacuum hose of the solenoid valve from the vacuum hose manifold and connect a vacuum gauge.

Start the engine.

NOTE: Engine coolant temperature must be below 80°C (176°F).

Apply vacuum.

Is vacuum indicated on the gauge?

NO

Measure voltage between RED (+) terminal and BLK (-) terminal on the control box.

YES

Warm up engine to normal operating temperature (cooling fan comes on).

Apply vacuum.

Is there battery voltage?

YES

Replace the solenoid valve.



NO

(To page 6-14)

(To page 6-14)


(cont'd)

IDLE BOOST SOLENOID VALVE



Carburetor

Idle Control System (cont'd)





Troubleshooting Flow Chart A/C Idle Boost Solenoid Valve

Inspection of A/C Idle Boost Solenoid Valve.

Disconnect the lower vacuum hose of the solenoid valve from the vacuum hose manifold and connect a vacuum pump.

Disconnect the upper vacuum hose of the solenoid valve from the idle boost throttle controller and connect a vacuum gauge.

Start the engine.


Apply vacuum.

Does solenoid valve hold vacuum?

NO

Disconnect the connectors near the solenoid valve.

Measure voltage between BLK/YEL (+) connector and BLU/RED (-) connector on the wire harness.



Turn the A/C switch ON.

Apply vacuum.


Is there voltage?

YES

Inspect short in BLU/RED wire between the solenoid valve and A/C switch.

NO

Replace the solenoid valve.




(To page 6-16)

(cont'd)

Carburetor

Idle Control System (cont'd)






Power Valve

Testing

1. Disconnect the #14 vacuum hose from the vacuum hose manifold and connect a vacuum pump. Apply vacuum.


It should hold vacuum.



- If it does not hold vacuum, replace the diaphragm and retest.
2. Start the engine and disconnect the #14 vacuum hose from the vacuum hose manifold, and connect a vacuum pump.
- There should be no vacuum for about 10 seconds after the engine is started.

And there should be vacuum within 15 seconds after the engine is started.

NOTE: The engine coolant temperature must be below 30°C (86°F).



- If not: go to troubleshooting (page 6-18).
3. Warm up the engine (the cooling fan comes on), and check the vacuum.
- There should be vacuum.
- If not, go to troubleshooting (page 6-18).

(cont'd)

Carburetor

Power Valve (cont'd)

Troubleshooting Flow Chart Power Valve Control Solenoid Valve

Inspection of Power Valve Control Solenoid Valve.

Open the control box.

Disconnect the lower vacuum hose of the solenoid valve from the 6 way joint and connect a vacuum pump.

Disconnect #14 vacuum hose of the solenoid valve from the vacuum hose manifold and connect a vacuum gauge.

Start engine.

Apply vacuum for about 10 seconds after the engine is started.

Is vacuum indicated on the gauge?

YES

Measure voltage between BLU/RED (+) terminal and BLK (-) terminal on the wire harness.

NO

Warm up engine to normal operating temperature (cooling fan comes on).

Is there battery voltage?

YES



Replace the solenoid valve.


NO

Measure voltage between BLU / RED (+) terminal and body ground.

(To page 6-19)

(To page 6-19)





Carburetor

Slow Air Jet Control System

Troubleshooting Flow Chart Air Leak Solenoid Valve

Inspection of Air Leak Solenoid Valve.

Disconnect the #2 vacuum hose from the vacuum hose manifold and connect a vacuum pump.

Start the engine.


Apply 100 mmHg (4 in.Hg) vacuum to the hose.

Does solenoid valve hold vacuum?

YES

Warm up the engine.

(To page 6-21)



VACUUM PUMP/GAUGE

Turn the ignition switch OFF.

Disconnect the BLU/YEL connector near the air cleaner.


Start the engine.

Measure voltage between BLU/YEL (+) and body ground.

Is there battery voltage?


YES

Replace the solenoid valve.



BLU/YEL


Check the self-diagnosis indicator (page 6-47). If OK, repair open in BLU/YEL wire between the solenoid valve and control unit (B6).



Carburetor


Primary Slow Mixture Cut-off Solenoid Valve

Troubleshooting Flow Chart Primary Slow Mixture Cut-off Solenoid Valve





(From page 6-22)



(cont'd)

Carburetor

Idle Speed/Mixture

Inspection/Adjustment


Propane Enrichment Method

▲WARNING Do not smoke during this procedure.
Keep any open flame away from your work area.


NOTE :

- This procedure requires a propane enrichment kit.
- Check that the warning light and self diagnosis indicator before making idle speed and mixture inspections.

1. Start the engine and warm up to normal operating temperature (the cooling fan comes on). Turn the ignition switch OFF. Start the engine with idle for two minutes and keep the engine speed 2,500-3,000 min^{-1} (rpm) for a one minute.
2. Disconnect the #8 vacuum hose from the intake air control diaphragm and clamp the hose end.



3. Connect a tachometer.




4. Check idle speed with the headlights, heater blower, rear window defogger, cooling fan and air conditioner off.

Idle speed should be :


Manual : $800 \pm 50 \text{ min}^{-1}$ (rpm)

Adjust the idle speed, if necessary, by turning the throttle stop screw.

NOTE : If the idle speed is excessively high, check the throttle control (page 6-39).




5. Disconnect the 2P connector from the EACV and disconnect the hose from vacuum hose manifold, then cap the hose end.






6. Disconnect air cleaner intake tube from air intake duct.
7. Insert the hose of the propane enrichment kit into the intake tube about 4-inches.

NOTE : Check that propane bottle has adequate gas before beginning test.



8. With engine idling, depress push button on top of propane device, then slowly open the propane control valve to obtain maximum engine speed. Engine speed should increase as percentage of propane injected goes up.

NOTE : Open the propane control valve slowly ; a sudden burst of propane may stall the engine.




RPM increase should be :

Manual : $40 \pm 20 \text{ min}^{-1} \text{ (rpm)}$

- If engine speed does not increase per specification, mixture is improperly adjusted. Go to step 9.
- If engine speed increase per specification, go to step 10.

9. Remove the mixture adjusting screw hole caps, and recheck maximum propane enriched rpm.



- If the propane enriched speed is too low, mixture is too rich : turn both mixture screws $1/4$ turn clockwise and recheck.
- If the propane enriched speed is too high, mixture is too lean : turn both mixture screws $1/4$ turn counterclockwise and recheck.

10. Reconnect the connector and hose. Close the propane control valve.
11. Remove the ECU fuse for 10 seconds to reset control unit and recheck idle speed. Turn the ignition switch OFF. Start the engine with idle for two minutes and keep the engine speed should be :


Manual : $800 \pm 50 \text{ min}^{-1} \text{ (rpm)}$

- If idle speed is as specified (Step 4) , go to step 12.
 - If idle speed is not as specified, adjust by turning throttle stop screws, then repeat step 9.
12. Remove propane enrichment kit and reconnect air cleaner intake tube on the air intake duct.

Carburetor


Idle Speed/Mixture

13. Reinstall the mixture adjusting screw hole cap.
14. Disconnect the # 20 vacuum hose from the idle boost throttle controller and connect a vacuum pump.



15. Apply vacuum, then check the idle speed with the headlight, heater blower, rear window defogger and cooling fan on.


Idle speed should be : $800 \pm 50 \text{ min}^{-1} \text{ (rpm)}$



Adjust the idle speed, if necessary, by turning the adjusting screw A.

16. Disconnect the vacuum pump and connect the # 20 vacuum hose, then check the idle speed with the headlight, heater blower, rear window defogger and cooling fan OFF.

17. If equipped with air conditioner, check the idle speed with the A/C on.
Idle speed should be : $800 \pm 50 \text{ min}^{-1} \text{ (rpm)}$



Adjusting the idle speed, if necessary, by turning the adjusting screw B.

18. If the idle speed does not reach the specified idle speeds in steps 14 though 17, go to idle control system testing (page 6-12).



CO Meter Method

⚠ WARNING Do not smoke during this procedure.
Keep any open flame away from your work area.

1. Follows steps 1 through 5 of the propane enrichment method.
2. Warm up and calibrate the CO meter according to the meter manufacture instructions.
3. Turn the engine off, restart the engine and complete the idle CO check within three minutes of restarting, with the headlights, heater blower, window defogger, cooling fan and air conditioner off.

CO meter should indicate 0.1% maximum.

If the idle CO is not within the specification, check the engine tune-up condition.

Carburetor


Choke Coil Tension and Linkage

Testing (COLD ENGINE)

1. Remove the air cleaner.
2. Open and close the throttle fully to let the choke close. The choke valve should close completely.

- If the choke closes properly, go on to the fast idle unloader test (page 6-28).

- If the choke does not close properly, spray linkage with carburetor cleaner, and check the linkage for signs of mechanical binding (use a spray can with an extension on the nozzle to reach the linkage).



—If the choke still does not close properly, remove the choke cover and inspect the linkage for free movement. Repair or replace parts as necessary, then reinstall the cover and adjust it so the index marks line up, and retest.

If the choke still does not close properly, replace the cover.

Fast Unloader


Testing

1. Disconnect the #18 vacuum hose from the fast idle unloader.
2. Open and close the throttle fully to engage the fast idle cam.
3. Start the engine.
The engine should run at fast idle.

- If the engine has fast idle, go on step 4.

- If the engine does not run at fast idle, remove the choke cover and check the operation of the fast idle cam.

4. Connect a vacuum pump to the fitting of the unloader and apply vacuum.



The fast idle speed should drop.

- If idle speed does not drop, check the unloader for leaks, blockage or damaged diaphragm. Remove the choke cover and check the unloader rod for free movement. Repair or replace as necessary.

- If idle speed drops, go on to step 5.




5. Reconnect the hose.
6. Wait for the engine to warm up (cooling fan comes on).

- If fast idle drops below 1,400 rpm. go on to the fast idle check.
- If fast idle does not drop below 1,400 rpm, disconnect the # 18 vacuum hose, and check that vacuum is present.

—If vacuum is present, check the unloader for leaks or blockage.
Remove the chockcover, and check the unloader rod for free movement. Repair or replace parts as necessary, and retest.

—If there is no vacuum at fitting, check for vacuum at the choke opener, and TWSV.

—Repair or replace as necessary.



Choke Opener


NOTE : Engine coolant temperature must be below TWSV set temperature 15°C (59°F).

1. Disconnect the choke heater wire.
2. Open and close the throttle fully to let the choke close.
3. Start the engine.
The choke valve should partially open.

● If the choke does not partially open, check the linkage for free movement, repair as necessary, and retest.

● If the choke still does not partially open, check the choke opener diaphragm.

Remove diaphragms two bolts, and attach a vacuum pump to the hose fitting. Block the orifice in the opener while you apply enough vacuum to pull the opener rod all the way in, then stop.



—If the rod will not stay in, replace the opener.

—If the rod stays in, check the vacuum port in the carburetor for blockage.

After replacing or re-installing the choke opener, retest it, then adjust it if necessary.


Carburetor

Chak coil Heater

Start the engine and let it run. As the engine reaches normal operating temperature the choke valve should fully open.

- If it does, test is complete.
- If it does not, inspect the linkage, and clean or repair it as necessary.
- If the choke still does not open all the way, disconnect the WHT/BLU choke cover wire from the engine compartment wire harness and check for voltage.

There should be battery voltage with the engine running.




—If the voltmeter reads 0 volts, check for an open circuit in the WHT/BLU wire between the choke cover connector and voltage regulator connector, then check the charge warning light circuit and alternator.


Fast Idle

Adjustment

1. Start the engine and wait for the engine to warm up (cooling fan comes on), then stop it and connect a tachometer.
2. Disconnect and plug the # 18 vacuum hose of the fast idle unloader.



3. While holding the choke valve closed, open and close the throttle fully to engage the choke and fast idle linkage.
4. Re-start the engine. Fast idle should be 3200 ± 500 (rpm) If not OK, reset the fast idle speed by turning the fast idle adjusting screw.






Linkage Adjustment

NOTE : This check is not necessary unless the linkage has been bent, choke opener has been replaced, or the car has poor cold starting.

This check can be made with the engine **HOT** or **COLD**.

1. Remove the choke cover.
2. While holding the choke valve closed, open and close the throttle fully to engage the choke and fast idle linkage.
3. Disconnect the choke opener hose from the vacuum manifold, and attach a check valve to it as shown. Then pressurize the choke opener with compressed air, 103-586 kPa (15-85 psi) is OK, to hold the bleed valve in it closed.




4. Gently push the choke opener lever towards the opener unit it stops until you feel (the opener rod seats against the pressurized bleed valve), then pull the choke drive lever down against the opener lever (to take all free play out of the linkage) and measure the clearance between the choke blade and casting.

1st stage Clearance :


$18^{\circ} \pm 1^{\circ}$

Adjust clearance by bending Tab D.

5. Remove the check valve, and reconnect the choke opener hose.
6. Hold both levers together, then push them toward the diaphragm again until they stop (Tab A on the opener lever seats against the carburetor), and measure the clearance at the choke valve.



7. While still holding opener lever Tab A against its seat, release the choke drive lever, and measure the clearance at the choke valve (Tab C on the drive lever should stay seated against the spring loop; if not, repeat step 2 and re-check) :



Carburetor

Choke Cover


Replacement

Removal :

1. Remove the air cleaner.
2. Remove the choke cover.

Installation :

1. Reinstall the cover and adjust it so that index marks align, then secure it with screws.
2. Reinstall the air clearer.



Fuel Supply System



Symptom-to-sub System Chart

NOTE:

- Across each row in the chart, the sub systems that could be sources of a symptom are ranked in the order they should be inspected, starting with ①. Find the symptom in the left column, read across to the most likely source, then refer to the page listed at the top of that column. If inspection shows the system is OK, try the next system ②, etc.
- Before starting inspection, check that other items that affect engine performance are within specification. Check the self-diagnosis indicator, valve clearance, air cleaner, and PCV valve. In addition, check the ignition timing, function of the vacuum and centrifugal advance, and the condition of the spark plugs. If those items are all within specifications, begin with the troubleshooting listed in this page.

PAGE		SYSTEM	FUEL FILTERS	FUEL PUMP	FUEL TANK	CONTAMINATED FUEL
SYMPTOM			34	—	—	*
		ENGINE WON'T START	③	①		②
POOR PERFORMANCE	MISFIRE OR ROUGH RUNNING		①			①
	LOSS OF POWER		①			①

* Fuel with dirt, water or a high percentage of alcohol is considered contaminated.

Fuel Filters

Replacement

Replace both front and rear filters at every 2 years or 40,000 km (24,000 miles) whichever comes first.


▲WARNING Do not smoke while working on the fuel system. Keep open flame away from work area.

Front

1. Use fuel line clamps to pinch off the fuel lines.
2. Disconnect the fuel lines and remove the fuel filter.

CAUTION: When disconnecting the fuel lines, slide back the clamps then twist the lines as you pull, to avoid damaging them.

3. Install the new fuel filter.
4. Remove the fuel line clamps.




FUEL FILTER

Rear

1. Block front wheels. Jack up the rear of the car and support with jackstands.
2. Push in the tab of the fuel filter to release the holder, then remove the filter from its bracket.
3. Attach fuel line clamps to the fuel lines and disconnect the lines from the filter.

CAUTION: To avoid damaging the fuel lines when disconnecting, slide back the clamps then twist the lines as you pull.

4. Install in the reverse order of removal.



Air Intake System



Symptom-to-sub System Chart

- NOTE:
- Across each row in the chart, the sub systems that could be sources of a symptom are ranked in the order they should be inspected, starting with ①. Find the symptom in the left column, read across to the most likely source, then refer to the page listed at the top of that column. If inspection shows the system is OK, try the next system ②, etc.
 - Before starting inspection, check that other items that affect engine performance are within specification. Check the self-diagnosis indicator, valve clearance, air cleaner, PCV valve. In addition, check the ignition timing, function of the vacuum and centrifugal advance, and the condition of the spark plugs. If those items are all within specifications, begin with the trouble-shooting listed in this page.


PAGE	SYSTEM	THROTTLE CABLE	AIR INTAKE CONTROL
		—	36
SYMPTOM			
LOSS OF POWER			①
AFTERBURN			①
HESITATION/SURGE			①

Air Intake System

Intake Air Control System

Testing (COLD ENGINE)

1. Disconnect the air intake duct.
2. With the engine cold, start the engine and let it run for about 5 seconds and stop. The air control door should rise on startup and remain fully open for at least 3 seconds after stopping the engine.




- If the door rises, the intake air control is OK, reconnect the air intake duct. If performing the inspection on intake air controls only, go on to hot engine inspection.

- If the door does not rise, check to see if the door is binding. If the door is not binding but fails to rise, or it rises but fails to stay up for 3 seconds after the cold cranking test, go to step 3.

3. Disconnect and plug the hose leading to the air bleed valve.
4. Crank the engine for approximately 5 seconds.
 - If the air control door does not rise or stay open for at least 3 seconds, proceed to step 5.

- If the door rises and stays up for at least 3 seconds, replace the air bleed valve and re-test (step 2).

5. Disconnect the vacuum hose from the air control diaphragm, connect a vacuum pump to the diaphragm inlet pipe and apply vacuum. The air control door should rise and stay up.



- If the door stays up, replace the check valve and re-test.
- If the door does not rise or stay up, replace the air control diaphragm and re-test.


6. Reconnect the air intake duct.



Testing (HOT ENGINE)

NOTE : As the outside air temperature drops, the bimetal spring in the bleed valve closes, causing the air control door to rise and allowing pre-heated air into the air cleaner ; consistent intake air temperature is maintained in this way.

1. With the engine running and the cooling fan ON, disconnect the air intake duct from the air cleaner and immediately check the control door position.
The air control door should be down.



- If the control door has dropped down to fully close the hot air intake duct, stop the engine and reconnect the air intake duct. Test is complete.
 - If the control door has not dropped to the fully closed position, go on to step 2.
2. Disconnect the vacuum hose from the air control diaphragm.
 - If the control door now closes, replace the air bleed valve and re-test.
 - If the control door does not close, correct whatever is causing the door to bind, and/or replace the air control diaphragm. Re-test.
 3. Stop the engine and reconnect the air intake duct. Test is complete.

Emission Control System

Sympton-to-sub System Chart

NOTE:

- Across each row in the chart, the sub systems that could be sources of a symptom are ranked in the order they should be inspected, starting with ①. Find the symptom in the left column, read across to the most likely source, then refer to the page listed at the top of that column. If inspection shows the system is OK, try the next system ②, etc.
- Before starting inspection, check that other items that affect engine performance are within specification. Check the self-diagnosis indicator, valve clearance, air cleaner, and PCV valve. In addition, check the ignition timing, function of the vacuum and centrifugal advance, and the condition of the spark plugs. If those items are all within specifications, begin with the troubleshooting listed in this page.

PAGE		SYSTEM	FEEDBACK CONTROL	THROTTLE CONTROL	EVAPORATIVE CONTROL
SYMPTOM			—	39	41
ENGINE WON'T START			①		
DIFFICULT TO START ENGINE	WHEN COLD		①		
	WHEN WARM		①	②	
IRREGULAR IDLING	WHEN COLD FAST IDLE OUT OF SPECIFICATION		①	②	
	WHEN WARM ENGINE SPEED TOO HIGH			①	
	WHEN WARM ENGINE SPEED TOO LOW		①		
	ROUGH IDLE/ FLUCTUATION		①		
FREQUENT STALLING	WHILE WARMING UP		①		
	AFTER WARMING UP		①		
POOR PERFORMANCE	MISFIRE OR ROUGH RUNNING				
	LOSS OFF POWER		①		
	AFTERBURN		①	②	
	HESITATION/SURGE		①		

Emission Control System




Throttle Control System

Testing (HOT ENGINE)

NOTE : If the dashpot diaphragm in the throttle controller is damaged or vacuum to the dashpot diaphragm is blocked or leaks, correct idle speed will not be obtained. The idle speed will be excessively high after warming up the engine.

1. Connect a tachometer, start the engine and allow it to reach normal operating temperature (cooling fan comes on).
2. Check that the idle speed is not excessively high.
 - If the idle speed is within specification, go on to step 3.
 - If the idle speed is excessively high, disconnect vacuum hose # 6 from the throttle controller and check for vacuum at the hose.




—If there is no vacuum, check vacuum line # 6 for leaks or blockade. Repair, clean or replace as necessary and re-test.

—If there is vacuum, replace the throttle controller and re-test.

3. With the engine idling, disconnect vacuum hose # 6 from the throttle controller.

Engine speed should rise to :
 $1800 \pm 300 \text{ min}^{-1} (\text{rpm})$

- If the $\text{min}^{-1} (\text{rpm})$ is not within specification, adjust the engine speed by adjusting screw.



ADJUSTING SCREW


- If the $\text{min}^{-1} (\text{rpm})$ does not change, check the throttle controller linkage for free movement. If there is no problem, replace the throttle controller and re-test.

Emission Control System

Positive Crankcase Ventilation

PCV Valve Test

1. Check the crankcase ventilation hoses and connections for leaks, crack or clogging.
2. Start the engine and allow it to idle.
3. Lightly kinch the breather hose between the PCV valve and intake manifold with your fingers or pliers. There should be 2 clicking sound from the PCV valve.



- If no sound is heard, replace the PCV valve and re-test.


Blow-by Filter Test

Inspect the condition of the blow-by filter.

- Replace the filter in the following instances :

—When the filter is stuck fast and oil is dripping or seeping through.

—When the filter is covered with dust and dirt so that clogging is evident.






Evaporative Emission Controls


Testing (COLD ENGINE)

NOTE : Engine coolant temperature must be below 75°C (167°F)

1. Disconnect the #7 vacuum hose at purge control diaphragm valve and connect vacuum pump/gauge to the hose.



2. Start the engine and allow to idle. Vacuum should not be available.
 - If there is no vacuum, disconnect the vacuum gauge and reconnect hose.
 - If there is vacuum, check for voltage at the purge cut-off solenoid valve.



—If no voltage, check the vacuum line for proper connection, cracks, blockage or disconnected hose. If OK, replace the solenoid valve.

—If there is voltage, check the self diagnosis indicator. If OK, substitute a known-good control unit and retest.


If symptom goes away, replace the original control unit.

Emission Control System


Evaporative Emission Controls

Testing (HOT ENGINE)

1. Disconnect the # 7 vacuum hose at the pumrge control diaphragm valve and connect a vacuum pump/gauge to the hose.



2. Wait for the engine to warm up and raise engine speed to 3,500 min⁻¹ (rpm). There should be vacuum.
 - If vacuum is available, go on to step 3.
 - If no vacuum, check for voltage at the purge cut-off solenoid valve.




—If there is voltage, check the vacuum line for proper connection, cracks, blockage or disconnected hose. If OK, replace the solenoid valve.

—If there is no voltage, measure between BLU/BLK (+) terminal and body ground.

- If there is volotage, check open in BLK wire. If OK, replace the solenoid valve.
- If there is no voltage, check open in BLU/BLK wire between the control box and control unit. If OK, check the Self diagnosis indicator.

3. Disconnect vacuum pump/gauge and reconnect the hose.
4. Remove fuel filler cap.
5. Remove the canister purge air hose from frame and connect hose to a vacuum gauge as shown.





6. Raise engine speed to 3,500 min⁻¹ (rpm).

Vacuum should appear on the gauge within 1 minute.

- If vacuum appears on the gauge in 1 minute, remove the gauge and go on to step 8.
- If no vacuum, disconnect the vacuum gauge and reinstall the fuel filler cap.


7. Remove the charcoal canister and check for signs of damage.

- If damaged, replace the canister.
- If OK, go on to step 8.

8. Stop the engine. Disconnect the hose from the canister PCV fitting.

Connect a vacuum pump to the canister PURGE fitting as shown, and apply vacuum.

Vacuum should remain steady.



- If vacuum remains steady, go on to step 7.
- If vacuum drops, replace the canister and retest.


9. Restart the engine. Reconnect the hose to the canister PCV fitting.

PURGE side vacuum should drop to zero.

- If PURGE side vacuum does not drop to zero, replace the canister and retest.
- If PURGE side vacuum drops to zero, connect a vacuum pump to canister PCV fitting, and apply vacuum. Vacuum should remain steady.
 - If vacuum remains steady, disconnect the vacuum pump. Re-check thermostatic valve operation on previous page.
 - If vacuum drops, replace canister and retest.

10. Connect a vacuum pump to TANK fitting as shown, and apply vacuum.

If should not hold vacuum.




- If it does not hold vacuum, reinstall fuel filler cap and canister; test is complete.
- If it holds vacuum, replace canister and retest.

Emission Control System


Evaporative Emission Controls (cont'd)

Two-Way Valve

1. Remove the filler cap.
2. Remove vapor line from the fuel tank and connect to T-fitting from vacuum gauge and vacuum pump as shown.



3. Slowly draw a vacuum while watching the gauge. Vacuum should stabilize at 5 to 15 mmHg (0.2 to 0.6 in. Hg).
 - If vacuum stabilizes momentarily (two-way valve opens) between 5 and 15 mmHg (0.2 and 0.6 in. Hg), go on to Step 4.
 - If vacuum stabilizes (valve opens) below 5 mmHg (0.2 in. Hg) or above 15 mmHg (0.6 in. Hg), install new valve and re-test.
4. Move vacuum pump hose from vacuum to pressure fitting, and move vacuum gauge hose from vacuum to pressure side as shown.



5. Slowly pressurize the vapor line while watching the gauge. Pressure should stabilize at 10 to 35 mmHg (0.4 to 1.4 in. Hg).
 - If pressure momentarily stabilizes (valve opens) at 10 to 35 mmHg (0.4 to 1.4 in. Hg), the valve is OK.
 - If pressure stabilizes below 10 mmHg (0.4 in. Hg) or above 35 mmHg (1.4 in. Hg), install a new valve and retest.

(cont'd)



Evaporative Emission Controls (cont'd)

Troubleshooting Flow Chart Air Vent Cut-off Solenoid Valve

Inspection of Air Vent Cut-off Solenoid Valve.

Disconnect the #8 vacuum hose of the solenoid valve from the vacuum hose manifold and connect a vacuum pump.

Disconnect the lower hose of the solenoid valve.

Apply vacuum.

Does solenoid valve hold vacuum?

NO

Replace the solenoid valve.

YES

Start the engine.

Apply vacuum.


Does solenoid valve hold vacuum?

YES

Turn the ignition switch OFF.

NO

Solenoid valve is OK.



Disconnect the 8P connector on the control box.


Start the engine.

(To page 6-46)

Emission Control System

Evaporative Emission Control (cont'd)


(page 6-45).




Self-Diagnostic Procedures




Turn the ignition on, pull down the passenger's side carpet inspection flap from under the dashboard and observe the LED on the top of the control unit. The LED indicates a system failure code by its blinking frequency. The control unit LED can indicate any number of simultaneous component problems by blinking separate codes, one after another.



Separate Problems:



Simultaneous Problems:




SELF-DIAGNOSIS INDICATOR BLINKS	SYSTEM INDICATED	PAGE
1	OXYGEN CONTENT	6-52
2	VEHICLE SPEED PULSER	6-54
3	MANIFOLD ABSOLUTE PRESSURE	6-55
4	VACUUM SWITCH SIGNAL	6-59
5	MANIFOLD ABSOLUTE PRESSURE	6-57
6	COOLANT TEMPERATURE	6-62
8	IGNITION COIL SIGNAL	6-64
10	INTAKE AIR TEMPERATURE	6-65
14	ELECTRONIC AIR CONTROL	6-67

If CODE 7, 9, 11, 12, 13 (or more than 14), count the number of blinks again; if the indicator is in fact blinking these codes, substitute a known-good control unit and recheck. If the indication goes away, replace the original control unit.

The Check Engine dash warning light and control unit LED may come on, indicating a system problem, when, in fact, there is a poor or intermittent electrical connection. First, check the electrical connections, clean or repair connections if necessary.


Self-Diagnostic Procedures

If the inspection for a particular failure code requires the ECU test harness, remove the right door sill molding, the small cover on the right kick panel, and pull the carpet back to expose the control unit. Unbolt the control unit bracket. Remove the control unit from the bracket. Connect the ECU test harness. Then check the system according to the procedure described for the appropriate code(s) listed on the following pages.



CAUTION:

- Puncturing the insulation on a wire can cause poor or intermittent electrical connections.
- For testing at connectors other than the ECU test harness, bring the tester probe into contact with the terminal from the connector side of wire harness connectors in the engine compartment. For female connectors, just touch lightly with the tester probe and do not insert the probe.



Troubleshooting



How to Read Flow Charts

A flow chart is designed to be used from start to final repair. It's like a map showing you the shortest distance. But beware; if you go off the "map" anywhere but a "stop" symbol, you can easily get lost.

START

(bold type)

Describes the conditions or situation to start a troubleshooting flow chart.

ACTION

Asks you to do something; perform a test, set up a condition, etc.

DECISION

Asks you about the result of an action by giving an "answer" and asking did you get the same answer: Yes or No.

STOP

(bold type)

The end of a series of actions and decisions, describes a final repair action and sometimes directs you to an earlier part of the flow to confirm your repair.

NOTE:

- The term "Intermittent Failure" is used several times in these charts. It simply means a system may have had a failure, but it checks out OK through all your tests. You may need to road test the car to reproduce the failure or if the problem was a loose connection, you may have unknowingly solved it while doing the tests.
- "Open" and "Short" are common electrical terms. An open is a break in a wire or at a connection. A short is an accidental connection of a wire to ground. In simple electronics, this usually means something won't work at all. In complex electronics (like electronic control units), this can sometimes mean something works, but not the way it's supposed to.
- If the electrical readings are not as specified when using the ECU test harness, check the ECU test harness connections before proceeding.

Symptom-to-System Chart

NOTE: Across each row in the chart, the systems that could be sources of a symptom are ranked in the order they should be inspected starting with ①. Find the symptom in the left column, read across to the most likely source, then refer to the page listed at the top of that column. If inspection shows the system is OK, try the next most likely system ②, etc.



PAGE	SYSTEM	PGM-CARB CONTROL SYSTEM						
		PGM-CARB CONTROL UNIT	OXYGEN SENSOR	VECHICLE SPEED PULSER	MANIFOLD ABSOLUTE PRESSURE SENSOR	VACUUM SWITCH	COOLANT TEMPERATURE SENSOR	IGCITION COIL SIGNAL
	SYMPTOM	69	52	54	55, 57	59	62	64
	SELF-DIAGNOSIS INDICATOR (LED) BLINKS	① or *	①	②	③ or ⑤	④	⑥	⑧
	ENGINE WON'T START							
	DIFFICULT TO START ENGINE WHEN COLD	(BU)					②	
IRREGULAR IDLING	WHEN COLD FAST IDLE OUT OF SPECIFIC	(BU)					②	
	ROUGH IDLE	(BU)	③		②			
	WHEN WARM RPM TOO HIGH	(BU)						
	WHEN WARM RPM TOO LOW	(BU)						
FREQUENT STALLING	WHILE WARMING UP	(BU)			②		③	
	AFTER WARMING UP	(BU)			②			
POOR PERFORMANCE	MISFIRE OR ROUGH RUNNING	(BU)	③	③	②			
	FAILS EMISSION TEST	(BU)	②		①			
	LOSS OF POWER	(BU)			③			

* CODE 7, 9, 11, 12, 13, or exceeds 14: count the number of blinks again. If the indicator is in fact blinking these codes, substitute a known-good control unit and recheck. If the indication goes away, replace the original ECU.

(BU): When the self-diagnosis indicator are on, the back-up system is in operation.

Substitute a known-good control unit and recheck. If the indication goes away, replace the original ECU.





PGM-CARB CONTROL SYSTEM			CARBURETOR	FUEL SUPPLY	AIR INTAKE	EMISSION CONTROL	
INTAKE AIR TEMPERA- TURE SENSOR	CLUTCH SWITCH SIGNAL	A/C SIGNAL				ELECTRONIC AIR CONTROL VALVE	OTHER EMISSION CONTROL
65	70	72				67	
							
				①			
			①				
③			①				③
③			①			③	③
	②	②	①				
			①				
			①			③	
			①			①	
			①	②			
			②		③	③	③
			③	②	①		②

Carburetor

Troubleshooting Flow Chart — Oxygen Sensor




Self-diagnosis LED blinks once: A problem in the Oxygen (O₂) Sensor circuit.



TEST HARNESS
07GMJ-ML80100



(From page 6-52)



Carburetor

Troubleshooting Flow Chart — Vehicle Speed Sensor



Self-diagnosis LED indicator blinks two times: A problem in the Vehicle Speed Sensor circuit.

LED indicates CODE 2.

Connect the ECU test harness A and B between the control unit and connector.

Block rear wheels and set the parking brake. Jack up the front of the car and support with safety stands.

Turn the ignition switch ON.

Slowly rotate left front wheel and measure voltage between A12 (+) terminal and B8 (-) terminal.

Does voltage pulse 0V and 3V?

YES

Substitute a known-good control unit and recheck. If prescribed voltage is now available replace the original control unit.

NO

Turn the ignition switch OFF.

Disconnect A and B connector from the control unit only, not the wire harness.

Turn the ignition switch ON.

A12 (-)

0-12V?

B15 (+)

Slowly rotate left front wheel and measure voltage between B15 (+) terminal and A12 (-) terminal.


Does voltage pulse 0V and 12V?

YES



Substitute a known-good control unit and recheck. If prescribed voltage is now available replace the original control unit.

NO

- Repair open or short in BLK/YEL wire between control unit (A12) and the speed sensor.
- Faulty speed sensor.



WARNING Block rear wheels before jacking up front of car.





Troubleshooting Flow Chart — MAP Sensor



Self-diagnosis LED indicator blinks three times: Most likely an electrical problem in the Manifold Absolute Pressure (MAP) Sensor system.



Self-diagnosis LED indicator blinks five times: Most likely a mechanical problem (broken hose) in the Manifold Absolute Pressure (MAP) Sensor system.



—Engine is warm and running.
—LED indicates CODE 3.

Turn the ignition switch OFF.

Remove HAZARD fuse in the main fuse box for 10 seconds to reset control unit.

Start the engine and allow to idle.

Does LED indicate CODE 3 ?

NO

Intermittent failure
(test drive may be necessary.)

YES

Turn the ignition switch OFF.

Connect the test harness between the MAP sensor and wire harness.

Turn the ignition switch ON.

Measure voltage between RED (+) terminal and GRN (-) terminal.


Is there approx. 5V ?

NO

YES

Measure voltage between WHT (+) terminal and GRN (-) terminal.

(To page 6-56)



TEST HARNESS
07GMJ-ML80100

Measure voltage between RED (+) terminal and body ground.

Is there approx. 5V ?

YES

Repair open in GRN wire between control unit (A13) and MAP sensor.

NO



Turn the ignition switch OFF.

(To page 6-56)

(cont'd)

Carburetor

Troubleshooting Flow Chart — MAP Sensor (cont'd)





LED indicates CODE 5.

Turn the ignition switch OFF.

Remove HAZARD fuse in the main fuse box for 10 seconds to reset control unit.

Start engine and keep engine speed at idle.

Does LED indicate CODE 5 ?

NO

Intermittent failure
(test drive may be necessary.)

YES

Stop engine.

Remove #21 hose from the vacuum hose manifold and connect a T. fitting from a vacuum gauge between the vacuum hose manifold and the MAP sensor.

Start engine.

Is there vacuum ?

NO

Repair as necessary.

YES

Connect a vacuum pump to #21 hose and apply vacuum.




Does it hold vacuum ?

NO

Replace #21 hose.

YES

(To page 6-58)




(cont'd)

Carburetor

Troubleshooting Flow Chart — MAP Sensor (cont'd)

(From page 6-57)





Troubleshooting Flow Chart — Vacuum Switch



Self-diagnosis LED indicator blinks four times: A problem in the vacuum switch.

- Engine is warm and running.
- LED indicates CODE 4.

Turn the ignition switch OFF.

Remove HAZARD fuse in the main fuse box for 10 seconds to reset control unit.

Start the engine and allow to idle.

Does LED indicates CODE 4 ?

NO

Intermittent failure
(test drive may be necessary.)

YES

Turn the ignition switch OFF.

Remove #4 hose from the vacuum hose manifold and connect a vacuum gauge.

Start engine and raise engine speed to 3,500 min⁻¹ (rpm).

Is there vacuum ?



NO

Repair as necessary.

YES

Start engine.

(To page 6-60)




(cont'd)

Carburetor

Troubleshooting Flow Chat — Vacuum Switch (cont'd)

(From page 6-59)

Connect a vacuum pump to #4 hose and apply vacuum.



Does it hold vacuum ?


NO

Replace #4 hose.

YES

Disconnect the 8p connector on the control box.

Measure resistance between No. 1 terminal and No. 7 terminal on the control box.



Does continuity exist ?

NO


Replace vacuum switch.

YES

Reconnect the vacuum hose.

Turn the ignition switch ON.

Measure voltage between BLK/YEL terminal and body ground on the wire harness.



Is there battery voltage ?

NO

Inspect No.14 fuse.

YES

Turn the ignition switch OFF.

Reconnect the 8p connector to the control box.

Is No.14 fuse OK ?

NO

Replace fuse.

YES

Repair open BLK/YEL wire between No.14 fuse and control box.

(To page 6 - 61)



(From page 6 - 60)

Connect the ECU test harness A and B between the control unit and connector (page 6-99).

Turn the ignition switch ON.

Measure voltage between A8 (+) terminal and B8 (-) terminal.


Is there battery voltage ?

NO

Repair open in BRN wire between control unit (A8) and vacuum switch.

YES

Substitute a known-good control unit and recheck. If symptom/indication goes away, replace the original control unit.



Carburetor

Troubleshooting Flow Chart — TW Sensor



Self-diagnosis LED indicator blinks six times: Most likely a problem in the Coolant Temperature (TW) Sensor circuit.

LED indicates CODE 6.

Turn the ignition switch OFF.

Remove HAZARD fuse in the main fuse box for 10 seconds to reset control unit.

Turn the ignition switch ON.

Does LED indicates CODE 6 ?

NO

Intermittent failure.
(test drive may be necessary.)

YES

Warm up engine to normal operating temperature (the cooling fan comes on).

Disconnect the C-6 and C-24 connectors.

Measure resistance between GRN/WHT terminal and RED/WHT terminal at C-24 connector.

Is there 200—400Ω ?

NO

YES

Reconnect C-6 and C-24 connectors, then disconnect the 2P connector from TW sensor.

Measure voltage between RED/WHT (+) terminal and body ground.

Is there approx. 5V ?

NO



YES


(To page 6 - 63)

Turn the ignition switch OFF.

Connect the ECU test harness A between the control unit and connector.

(To page 6 - 63)





Carburetor

Troubleshooting Flow Chart — Ignition Coil Signal



Self-diagnosis LED indicator blinks eight times: A problem in the ignition coil signal circuit.

LED indicates CODE 8.

Turn the ignition switch OFF.

Remove HAZARD fuse in the main fuse box for 10 seconds to reset control unit.

Turn the ignition switch ON.

Does LED indicates CODE 8 ?

NO

Intermittent failure
(test drive may be necessary.)

YES

Start the engine.

Connect the ECU test harness B between the control unit and connector.

Measure voltage between B11 (+) terminal and B8 (-) terminal.

Does voltage pulse 0V and 5V?



NO

Repair short or open
BLU wire between
control unit (B11) and
ignition coil.

YES

Substitute a known-good control unit and recheck. If symptom/indication goes away, replace the original control unit.

EACV





Troubleshooting Flow Chart — TA Sensor



Self-diagnosis LED indicator blinks ten times: Most likely a problem in the Intake Air Temperature (TA) Sensor circuit.

LED indicates CODE 10.

Turn the ignition switch OFF.

Remove HAZARD fuse in the main fuse box for 10 seconds to reset control unit.

Turn the ignition switch ON.

Does LED indicates CODE 10?

NO

Intermittent failure.
(test drive may be necessary.)

YES

Warm up engine to normal operating temperature (the cooling fan comes on).

Disconnect the C-6 and C-24 connectors.

Measure resistance between GRN/WHT terminal and RED/YEL terminal at C-24 connector.

Is there 1 — 4 k Ω ?

NO

Inspect for open or short in RED/YEL or GRN/WHT wire between C-24 connector and TA sensor. If wires are OK, replace the TA sensor.

YES

Reconnect C-6 and C-24 connectors, then disconnect the 2P connector from TA sensor.

Measure voltage between RED/YEL (+) terminal and body ground.

Is there approx. 5V?

NO

Turn the ignition switch OFF.

YES




Measure voltage between RED/YEL (+) terminal and GRN/WHT (-) terminal.

Connect the ECU test harness A between the control unit and connector.

(To page 6 - 66)


(To page 6 - 66)

(cont'd)



Carburetor

Troubleshooting Flow Chart — TA Sensor (cont'd)






Troubleshooting Flow Chart — EACV



Self-diagnosis LED indicator blinks fourteen times: A problem in the Electronic Air Control Valve (EACV) circuit.



(cont'd)

Carburetor

Troubleshooting Flow Chart — EACV (cont'd)


(From page 6 - 67)

Reconnect the 2P connector to EACV.

Connect the ECU test harness B between the control unit and connector.

Start the engine.

Measure voltage between B12 (+) terminal and B8 (-) terminal.




Is there battery voltage?

NO

Substitute a known- good control unit and recheck. If prescribed voltage is now available replace the original control unit.

YES

Measure voltage between B14 (+) terminal and B8 (-) terminal.



Is there voltage?

NO


Substitute a known-good control unit and recheck. If prescribed voltage is now available replace the original control unit.

YES

Repair open in BLU/YEL wire between control unit (B12) and EACV or BLU wire between control unit (B14) and EACV.



Input Troubleshooting Flow Chart — Power Source (IG1, Bat) and Ground



Carburetor

Input Troubleshooting Flow Chart — Clutch Switch Signal

Inspection of clutch switch signal

Connect the ECU test harness A and B between the control unit and connector.


Turn the ignition switch ON.

Measure voltage between A3 (+) terminal and B8 (-) terminal.

Is there 3 — 7V?

NO

YES



Turn the ignition switch OFF.

Disconnect the 2P connector on the clutch switch.


Check for continuity between the 2 terminals on the clutch switch.

Does continuity exist?

YES

NO

- Repair short in GRN wire between control unit (A3) and clutch switch.
- Substitute a known-good ECU and recheck. If prescribed volt-age is now available, replace the original ECU.




- Adjust the clutch pedal.
- Replace the clutch switch.

Depress the clutch pedal.

(To page 6 - 71)




(From page 6 - 70)




Carburetor

Input Troubleshooting Flow Chart — Air Conditioning Signal





Troubleshooting Flow Chart — A/C Clutch Relay



Fuel and Emissions(Fuel Inject- ed Engine)

Idle Control System

Idle speed Setting6 — 76

Fuel Supply System

Index6 — 77

Fuel Sub Pump6 — 78

Fuel Cut-off Relay6 — 80

Fuel Tank6 — 83



Outline of Model Changes

- The inspection/adjustment of idle speed has been modified. [1.5 ℓ]
- The fuel sub pump and the fuel cut-off relay has been adopted. [4D-4WD]


Idle Control System

Idle Speed Setting [1.5 l]


Inspection/Adjustment

1. Start the engine and warm it up to normal operating temperature (the cooling fan comes on).
2. Connect a tachometer.

RPM CONNECTING ADAPTER
07JAZ-SH20100



3. Disconnect the 2P connector from the EACV.



4. Check idling in no-load conditions in which the headlights, blower fan, rear defogger, cooling fan, and air conditioner are not operating.


Idle speed should be:

Manual	$625 \pm 50 \text{ min}^{-1} \text{ (rpm)}$
Automatic	$625 \pm 50 \text{ min}^{-1} \text{ (rpm)}$ (in N or P)

Adjust the idle speed, if necessary, by turning the idle adjusting screw.

NOTE: If the idle speed is excessively high, check the throttle control system.

IDLE ADJUSTING SCREW



5. Turn the ignition switch OFF.
6. Reconnect the 2P connector on the EACV, then remove HAZARD fuse in the main fuse box for 10 seconds to reset ECU.
7. Restart and idle the engine with no-load conditions in which the headlights, blower fan, rear defogger, cooling fan, and air conditioner are not operating for one minute, then check the idle speed.

Idle speed should be:

Manual	$800 \pm 50 \text{ min}^{-1} \text{ (rpm)}$
Automatic	$800 \pm 50 \text{ min}^{-1} \text{ (rpm)}$ (in N or P)

8. Idle the engine for one minute with headlights (Hi) and rear defogger ON and check the idle speed.
If applicable, with Automatic transmission models, idle the engine for one minute in gear (except **N** or **P**) and check the idle speed.
Idle speed should be: $800 \pm 50 \text{ min}^{-1} \text{ (rpm)}$
9. Idle the engine for one minute with heater fan switch at HI (right end) and air conditioner on, then check the idle speed.
Idle speed should be: $800 \pm 50 \text{ min}^{-1} \text{ (rpm)}$

NOTE: If the idle speed is not within specifications, see System Troubleshooting Guide on page 6-60.


Fuel Supply System



Index [KS,KW,KX 4D-4WD]


Description

Four-wheel drive vehicles use a propellor shaft. With four-door, four-wheel drive vehicles, the fuel tank is divided into left and right halves which straddle the propellor shaft. Because of that, there is a fuel sub pump to feed the fuel from the right to the left tank and a fuel cut-off relay for control.



FUEL CUT-OFF RELAY

- Operation 6-80
- Testing 6-81




Fuel Supply System

Fuel Sub Pump

Description

Because of its compact impeller design, the fuel sub pump is installed inside the fuel tank, thereby saving space and simplifying the fuel line system.



The fuel sub pump is comprised of a DC motor, a circumference flow pump, a relief valve for protecting the fuel line systems, a check valve for retaining residual pressure, an inlet port, and a discharge port. The pump assembly consists of the impeller (driven by the motor), the pump casing (which forms the pumping chamber), and the pump cover.

Operation


1. When the engine is started, the fuel cut-off relay actuates the pump, and the motor turns together with the impeller. Differential pressure is generated by the numerous grooves around the impeller.
2. Fuel entering the inlet port flows inside the motor from the pumping chamber and is forced through the discharge port via the check valve. If fuel flow is obstructed at the discharge side of the fuel line, the relief valve will open to bypass the fuel to the inlet port and prevent excessive fuel pressure.
3. When the engine stops, the pump stops automatically. However, a check valve closes by spring action to retain the residual pressure in the line, helping the engine to restart more easily.



Testing

▲WARNING Do not smoke during the test. Keep open flame away from your work area.

1. Remove the fuel sub pump.
2. Measure the amount of fuel flow for a minute by connecting battery positive to the A terminal, and negative to the B terminal.




Amount should be :
760 cm³ (25.7oz)min. in a minute at 12V

- If the fuel sub pump is OK, check for :
 - Clogged fuel filter.
 - Clogged fuel line.
 - Fuel cut-off relay failure(page 6-80).

Replacement


▲WARNING Do not smoke while working on fuel system. Keep open flame away from work area.

1. Remove the rear seat, then remove the maintenance access cover.
2. Remove the fuel pump mounting nuts.
3. Remove the fuel sub pump from the fuel tank.



Fuel Supply System

Fuel Cut-off Relay



Operation


The switch is on when the right side fuel tank contains fuel. When power from the battery is supplied to the fuel cut-off relay and the engine is started by turning the ignition switch on, the ignition pulse signal is input to the relay from the primary side of the ignition coil, the fuel sub pump operates and fuel is fed from the right to the left side.

The ignition pulse signal is not generated by the primary side of the ignition coil when the engine stops ; therefore, the fuel sub pump does not operate. Also, the float switch turns off when there is no fuel in the right side tank, so the sub fuel pump does not operate.



Testing

1. Keep the ignition switch in the OFF position.
2. Disconnect the 7P connector.
3. Check for continuity between the BLK wire ④ in the connector and body ground.



4. Attach the positive probe of voltmeter to the BLK/YEL wire ⑦ and the negative probe to the BLK wire ④.
5. Turn the ignition switch ON.

Battery voltage should be available.

• If there is no voltage, check the wiring from the ignition switch and the fuel cut-off relay as well as No. 14(10A) fuse.

6. Turn the ignition switch OFF.
Attach the positive probe of voltmeter to the BLU wire ② and the negative probe to the BLK wire ④.

7. Turn the ignition switch ON.

Battery voltage should be available.


• If there is no voltage, check the wiring between the ignition coil and the fuel cut-off relay.

8. Turn the ignition switch OFF.
Connect a jumper wire between the YEL/BLK wire ③ and BLK/YEL wire ⑦.

9. Turn the ignition switch ON.

The fuel sub pump should work.

• If the fuel sub pump does not work, remove the maintenance access cover. Check that battery voltage is available at the fuel sub pump connector when the ignition switch is turned ON (positive probe to the YEL/BLK wire, negative probe to the BLK wire).




—If battery voltage is available, replace the fuel pump.

—If there is no voltage, check for continuity between the GRN/RED wire in the connector and the fuel sub relay.

Fuel Supply System

Fuel Cut-Off Relay (cont'd)

10. Remove the fuel sub pump from the fuel tank.
11. Attach the positive probe of voltmeter to the GRN/RED wire ① and the negative probe to the BLK wire ④.
12. Suspend the float switch in a container of water as shown.



13. Check for continuity between the GRN/RED wire ① and the BLK wire ④.

- If there is no continuity, replace the float switch.

If all the testes are OK, replace the fuel cut-off relay and retest.



Fuel Tank

Replacement

⚠ WARNING Do not smoke while working on fuel system. Keep open flame away from work area.

1. Block front wheels. Jack up the rear of the car and support with jackstands.
2. Remove the drain bolt and drain the fuel into an approved container.
3. Remove the exhaust pipe B and muffler.
4. Remove the No.3 propeller shaft from the rear differential.
5. Remove the rear seat and disconnect the fuel gauge sending unit connector.
6. Remove the two-way valve cover and fuel hose protector.
7. Disconnect the hoses.


CAUTION:

- When disconnecting the hoses, slide back the clamps, then twist hoses as you pull, to avoid damaging them.
- Clean the flared joint of high pressure hoses thoroughly before reconnecting them.

8. Place a jack, or other support, under the tank.
9. Remove the strap nuts and let the straps fall free.
10. Remove the fuel tank.

NOTE: The tank may have stuck on the undercoat applied to its mount. To remove, carefully pry it off the mount.

11. Install a new washer on the drain bolt, then install parts in the reverse order of removal.



Manual Transmission

L3 (2WD).....	8 — 1
L3 (4WD)	8 — 13



L3 (2WD)

Special Tools	8 — 2
Illustrated Index	8 — 4
Shift Fork	
Disassembly	8 — 6
Reassembly	8 — 6
Mainshaft Thrust Shim	
Adjustment	8 — 7
Countershaft	
Disassembly	8 — 10
Reassembly	8 — 11




Outline of Model Changes

- The spring pin has been added to the shift fork shaft.
- The mainshaft thrust shim has been changed.
- The countershaft ball bearing has been changed.

Special Tools


Special Tools

Ref. No	Tool Number	Description	Q'ty	Remarks
①	07GAJ-PG20102	Mainshaft Clearance Inspection Tool Set	1	
①-1	07GAJ-PG20110	Mainshaft Holder	1	
①-2	07GAJ-PG20120	Collar	1	
①-3	07GAJ-PG20130	Mainshaft Base	1	
②	07744-0010200	Pin Driver 3.0 mm	1	
③	07744-0010400	Pin Driver 5.0 mm	1	
④	07979-PJ40001	Magnet Stand Base	1	




Illustrated Index

Refer to the drawing below for the transmission disassembly/reassembly.
Clean all parts thoroughly in solvent and dry with compressed air.

 Lubricate all parts with oil before reassembly.

NOTE: This transmission uses no gaskets between the major housings; use PART NO. 0Y746-99986 for the liquid gasket. Assemble the housings within 20 minutes after applying the liquid gasket and allow it to cure at least 30 minutes after assembly before filling the transmission with oil.





Torque Value

A	—40 N·m (4.0 kg-m, 29 lb-ft)
B	—15 N·m (1.5 kg-m, 11 lb-ft)
C	—29 N·m (2.9 kg-m, 21 lb-ft)
D	—25 N·m (2.5 kg-m, 18 lb-ft)
E	—55 N·m (5.5 kg-m, 40 lb-ft)
F	—28 N·m (2.8 kg-m, 21 lb-ft)
G	—26 N·m (2.6 kg-m, 19 lb-ft)


NOTE: Always clean the magnet 72 whenever the transmission housing is disassembled.

- | | | |
|----------------------------------|---------------------------|------------------------------------|
| ① SEALING WASHER | ③① SYNCHRO SPRING | ⑥④ NEEDLE BEARING |
| ② OIL DRAIN PLUG | ③② SYNCHRO RING | ⑥⑤ MAINSHAFT |
| 40 N·m (4.0 kg-m, 29 lb-ft) | ③③ COUNTERSHAFT 1st GEAR | ⑥⑥ SPRING WASHER |
| ③ 32 mm SEALING BOLT | ③④ NEEDLE BEARING | ⑥⑦ BALL BEARING |
| ④ OIL SEAL | ③⑤ COUNTERSHAFT | ⑥⑧ OIL SEAL |
| ⑤ OIL FILLER PLUG | ③⑥ NEEDLE BEARING | ⑥⑨ REVERSE IDLER GEAR |
| 45 N·m (4.5 kg-m, 33 lb-ft) | ③⑦ OIL GUIDE PLATE | ⑦① REVERSE IDLER SHAFT |
| ⑥ SEALING WASHER | ③⑧ 5th/REVERSE SHIFT FORK | REVERSE SHIFT HOLDER |
| ⑦ TRANSMISSION HOUSING | SHAFT | ⑦② MAGNET |
| ⑧ BACK-UP LIGHT SWITCH | ③⑨ ROLLER | ⑦③ REVERSE SELECT SPRING |
| 25 N·m (2.5 kg-m, 18 lb-ft) | ④① 5th DETENT SPRING | ⑦④ REVERSE RETURN SELECT |
| ⑨ CLUTCH CABLE BRACKET | ④② 5th SHIFT FORK | ⑦⑤ SHIFT ARM C |
| ⑩ BREATHER TUBE | ④③ OIL GUIDE PLATE | ⑦⑥ SHIFT ARM A |
| ⑪ 1st/2nd SHIFT FORK | ④④ THRUST SHIM | ⑦⑦ REVERSE LOCK CAM |
| ⑫ 1st/2nd SHIFT FORK SHAFT | Selection, page 8-7 | ⑦⑧ SHIFT ARM B |
| ⑬ SHIFT FORK SPRING | ④⑤ BALL BEARING | ⑦⑨ INTERLOCK |
| ⑭ STEEL BALL | ④⑥ SYNCHRO HUB | ⑧① DOWEL PIN |
| ⑮ SPRING PIN | ④⑦ SYNCHRO SLEEVE | ⑧② SPRING |
| ⑯ SNAP RING | ④⑧ SYNCHRO SPRING | ⑧③ SPRING COLLAR |
| ⑰ COUNTERSHAFT LOCKNUT | ④⑨ SYNCHRO RING | ⑧④ SPRING BOLT |
| 110→0→110 N·m (11.0→0→11.0 kg-m, | ④⑩ 5th GEAR | ⑧⑤ SPRING |
| 80→0→80 lb-ft) | ⑤① NEEDLE BEARING | ⑧⑥ SHIFT ROD |
| ⑱ WASHER | ⑤② 3rd/4th SHIFT FORK | ⑧⑦ BOOT |
| ⑲ BALL BEARING | ⑤③ SHIFT PIECE | ⑧⑧ SHIM |
| Disassembly, page 8-10 | ⑤④ SPRING PIN | ⑧⑨ DIFFERENTIAL ASSEMBLY |
| Reassembly, page 8-11 | ⑤⑤ SPACER COLLAR | ⑧⑩ 28 mm PLUG |
| ⑳ NEEDLE BEARING | ⑤⑥ 4th GEAR | ⑨① 1st/2nd SELECT SPRING |
| ㉑ COUNTERSHAFT 5th GEAR | ⑤⑦ NEEDLE BEARING | ⑨② SHIFT ARM SHAFT |
| ㉒ COUNTERSHAFT 4th GEAR | ⑤⑧ SYNCHRO RING | ⑨③ OIL SEAL |
| ㉓ COUNTERSHAFT 3rd GEAR | ⑤⑨ SYNCHRO SPRING | ⑨④ CLUTCH HOUSING |
| ㉔ COUNTERSHAFT 2nd GEAR | ⑤⑩ SYNCHRO HUB | ⑨⑤ INTERLOCK GUIDE BOLT |
| ㉕ NEEDLE BEARING | ⑤⑪ SYNCHRO SLEEVE | ⑨⑥ FRICTION DAMPER (2nd gear side) |
| ㉖ DISTANCE COLLAR | ⑤⑫ SYNCHRO SPRING | Disassembly, page 8-10 |
| ㉗ SYNCHRO RING | ⑤⑬ SYNCHRO RING | Reassembly, page 8-11 |
| ㉘ SYNCHRO SPRING | ⑤⑭ 3rd GEAR | ⑨⑦ FRICTION DAMPER (1st gear side) |
| ㉙ REVERSE GEAR | | Disassembly, page 8-10 |
| ㉚ SYNCHRO HUB | | Reassembly, page 8-11 |
| | | ⑨⑧ THRUST WASHER |


Shift Fork

Disassembly

1. Remove the shift fork shaft by removing the spring pins from the shift forks.





CAUTION: Do not lose the spring-loaded detent while disassembling the shift forks and shift fork shafts.



Reassembly

1. Insert the shift fork shaft into the shift forks and drive in the spring pins.

NOTE: Do not lose the steel balls and spring when reassembling.




Mainshaft Thrust Shim



Adjustment

1. Remove the thrust shim and oil guide plate from the transmission housing.
2. Install the 3rd/4th synchro hub, spacer collar, 5th synchro hub, ball bearing and thrust washer on the mainshaft. Install the assembly in the transmission housing.



3. Measure the distance B between the end of the transmission housing and thrust washer.


NOTE:

- Use a straight edge and feeler gauge.
- Measure at three locations and average the readings.

4. Measure the distance C between the surfaces of the clutch housing and bearing inner race.

NOTE:

- Use a straight edge and feeler gauge.
- Measure at three locations and average the readings.



5. Select the proper shim (or shim pair) on the basis of the following calculations:

NOTE: Do not use more than two shims.

(Basic Formula)

$$(B) + (C) - 0.95 = \text{shim thickness}$$

Example of calculation:

Distance B (2.00mm) + Distance C (0.09mm) = 2.09 mm
subtract the spring washer height (0.95mm) = the required thrust shim (1.14mm)

D12B, D13B, D14A, D15B : 65 mm Thrust Shim

	PART NUMBER	THICKNESS
A	23931-PL3-A10	0.60 mm (0.0236 in.)
B	23932-PL3-A10	0.63 mm (0.0284 in.)
C	23933-PL3-A10	0.66 mm (0.0260 in.)
D	23934-PL3-A10	0.69 mm (0.0272 in.)
E	23935-PL3-A10	0.72 mm (0.0283 in.)
F	23936-PL3-A10	0.75 mm (0.0295 in.)
G	23937-PL3-A10	0.78 mm (0.0307 in.)
H	23938-PL3-A10	0.81 mm (0.0319 in.)
I	23939-PL3-A10	0.84 mm (0.0331 in.)
J	23940-PL3-A10	0.87 mm (0.0343 in.)
K	23941-PL3-A10	0.90 mm (0.0354 in.)
L	23942-PL3-A10	0.93 mm (0.0366 in.)
M	23943-PL3-A10	0.96 mm (0.0378 in.)
N	23944-PL3-A10	0.99 mm (0.0390 in.)
O	23945-PL3-A10	1.02 mm (0.0402 in.)
P	23946-PL3-A10	1.05 mm (0.0413 in.)
Q	23947-PL3-A10	1.08 mm (0.0425 in.)
R	23948-PL3-A10	1.11 mm (0.0437 in.)
S	23949-PL3-A10	1.14 mm (0.0449 in.)
T	23950-PL3-A10	1.17 mm (0.0461 in.)
U	23951-PL3-A10	1.20 mm (0.0472 in.)
V	23952-PL3-A10	1.23 mm (0.0484 in.)
W	23953-PL3-A10	1.26 mm (0.0496 in.)
X	23954-PL3-A10	1.29 mm (0.0508 in.)
Y	23955-PL3-A10	1.32 mm (0.0520 in.)
Z	23956-PL3-A10	1.35 mm (0.0531 in.)
AA	23957-PL3-A10	1.38 mm (0.0543 in.)
AB	23958-PL3-A10	1.41 mm (0.0555 in.)
AC	23959-PL3-A10	1.44 mm (0.0567 in.)
AD	23960-PL3-A10	1.47 mm (0.0579 in.)
AE	23961-PL3-A10	1.50 mm (0.0591 in.)
AF	23962-PL3-A10	1.53 mm (0.0602 in.)
AG	23963-PL3-A10	1.56 mm (0.0614 in.)
AH	23964-PL3-A10	1.59 mm (0.0626 in.)
AI	23965-PL3-A10	1.62 mm (0.0638 in.)
AJ	23966-PL3-A10	1.65 mm (0.0650 in.)
AK	23967-PL3-A10	1.68 mm (0.0661 in.)
AL	23968-PL3-A10	1.71 mm (0.0673 in.)
AM	23969-PL3-A10	1.74 mm (0.0685 in.)
AN	23970-PL3-A10	1.77 mm (0.0697 in.)
AO	23971-PL3-A10	1.80 mm (0.0709 in.)

(cont'd)


Mainshaft Thrust Shim

Adjustment (cont'd)

D16A: 70 mm Thrust Shim

	PART NUMBER	THICKNESS
A	23931-PL3-B00	0.60 mm (0.0236 in.)
B	23932-PL3-B00	0.63 mm (0.0284 in.)
C	23933-PL3-B00	0.66 mm (0.0260 in.)
D	23934-PL3-B00	0.69 mm (0.0272 in.)
E	23935-PL3-B00	0.72 mm (0.0283 in.)
F	23936-PL3-B00	0.75 mm (0.0295 in.)
G	23937-PL3-B00	0.78 mm (0.0307 in.)
H	23938-PL3-B00	0.81 mm (0.0319 in.)
I	23939-PL3-B00	0.84 mm (0.0331 in.)
J	23940-PL3-B00	0.87 mm (0.0343 in.)
K	23941-PL3-B00	0.90 mm (0.0354 in.)
L	23942-PL3-B00	0.93 mm (0.0366 in.)
M	23943-PL3-B00	0.96 mm (0.0378 in.)
N	23944-PL3-B00	0.99 mm (0.0390 in.)
O	23945-PL3-B00	1.02 mm (0.0402 in.)
P	23946-PL3-B00	1.05 mm (0.0413 in.)
Q	23947-PL3-B00	1.08 mm (0.0425 in.)
R	23948-PL3-B00	1.11 mm (0.0437 in.)
S	23949-PL3-B00	1.14 mm (0.0449 in.)
T	23950-PL3-B00	1.17 mm (0.0461 in.)
U	23951-PL3-B00	1.20 mm (0.0472 in.)
V	23952-PL3-B00	1.23 mm (0.0484 in.)
W	23953-PL3-B00	1.26 mm (0.0496 in.)
X	23954-PL3-B00	1.29 mm (0.0508 in.)
Y	23955-PL3-B00	1.32 mm (0.0520 in.)
Z	23956-PL3-B00	1.35 mm (0.0531 in.)
AA	23957-PL3-B00	1.38 mm (0.0543 in.)
AB	23958-PL3-B00	1.41 mm (0.0555 in.)
AC	23959-PL3-B00	1.44 mm (0.0567 in.)
AD	23960-PL3-B00	1.47 mm (0.0579 in.)
AE	23961-PL3-B00	1.50 mm (0.0591 in.)
AF	23962-PL3-B00	1.53 mm (0.0602 in.)
AG	23963-PL3-B00	1.56 mm (0.0614 in.)
AH	23964-PL3-B00	1.59 mm (0.0626 in.)
AI	23965-PL3-B00	1.62 mm (0.0638 in.)
AJ	23966-PL3-B00	1.65 mm (0.0650 in.)
AK	23967-PL3-B00	1.68 mm (0.0661 in.)
AL	23968-PL3-B00	1.71 mm (0.0673 in.)
AM	23969-PL3-B00	1.74 mm (0.0685 in.)
AN	23970-PL3-B00	1.77 mm (0.0697 in.)
AO	23971-PL3-B00	1.80 mm (0.0709 in.)

6. Check the thrust clearance in the manner described below.
 - a. Install the shims selected in the transmission housing.
 - b. Install the thrust washer and spring washer in the mainshaft.




NOTE:

- Clean the thrust washer, spring washer and shim thoroughly before installation.
 - Install the thrust washer, spring washer and shim properly.
- c. Install the mainshaft in the clutch housing.
 - d. Place the transmission housing over the mainshaft and onto the clutch housing.
 - e. Tighten the clutch and transmission housings with several 10mm bolts.
 - f. Tap the mainshaft with a plastic hammer.

7. Check the thrust clearance in the manner described below.

CAUTION: Measurement should be made at room temperature.


- a. Slide the mainshaft base and the collar over the mainshaft.





b. Attach the mainshaft holder to the mainshaft as follows:


- Back-out the mainshaft holder bolt and loosen the two hex bolts.
- Fit the holder over the mainshaft so its lip is towards the transmission.
- Align the mainshaft holder's lip around the groove at the inside of the mainshaft splines, then tighten the hex bolts.



c. Seat the mainshaft fully by tapping its end with a plastic hammer.

d. Thread the mainshaft holder bolt in until it just contacts the wide surface of the mainshaft base.

e. Zero a dial gauge on the end of the mainshaft.



f. Turn the mainshaft holder bolt clockwise; stop turning when the dial gauge has reached its maximum movement. The reading on the dial gauge is the amount of mainshaft end play.

CAUTION: Turning the shaft holder bolt more than 60 degrees after the needle of the dial gauge stops moving may damage the transmission.


g. Clearance is correct if reading is between 0.13–0.20mm (0.0051–0.0079 in).

If not, recheck necessary shim thickness.


Countershaft

Disassembly


1. Raise the locknut tab from the groove of the shaft and remove the locknut and the spring washer.
2. Support 4th gear on steel blocks as shown and press the shaft out of ball bearing.
CAUTION: Remove the ball bearing using a press and steel blocks as shown. Use of a jaw-type puller can cause damage to the gear teeth.



3. Using a press as shown, remove the friction damper (2nd gear side) from the spacer collar.




4. Remove the friction damper (1st gear side) and needle bearing from the countershaft.






Reassembly


1. Using a press, install the friction damper (1st gear side) to the countershaft as shown.



2. Using a press, install the friction damper (2nd gear side) to the spacer collar.



3. Install the ball bearing using a press as shown.



4. Install the spring washer, tighten the locknut and then stake the locknut tab into the groove.

LOCKNUT

110 → 0 → 110 N·m (11.0 → 0 → 11.0kg-m, 80 → 0 → 80 lb-ft)

L3 (4WD)

Special Tools	8 — 14
Illustrated Index	8 — 16
Mainshaft Thrust Shim	
Adjustment	8 — 18
Countershaft	
Disassembly	8 — 20
Clearance Inspection	8 — 21
Reassembly	8 — 23



Outline of Model Changes

- The mainshaft thrust shim has been changed.
- The countershaft ball bearing has been changed.
- The countershaft thrust washer has been changed.

Special Tools

Special Tools				
Ref. No	Tool Number	Description	Q'ty	Remarks
①	07GAJ-PG20102	Mainshaft Clearance Inspection Tool Set	1	
①-1	07GAJ-PG20110	Mainshaft Holder	1	
①-2	07GAJ-PG20130	Mainshaft Base	1	
②	07979-PJ40001	Magnet Stand Base	1	


The diagram shows two components of the Mainshaft Clearance Inspection Tool Set. Component ①-1 is a Mainshaft Holder, a complex metal bracket with a central circular opening and several adjustment points. Component ①-2 is a Mainshaft Base, a cylindrical metal ring. Both are labeled with circled numbers and arrows pointing to them.

The diagram shows a Magnet Stand Base, a rectangular metal plate with a central elongated slot. It is labeled with a circled number ②.

Illustrated Index

NOTE :

- Clean all parts thoroughly in solvent and dry with compressed air.
- Lubricate all parts with oil before reassembly.





NOTE : Remove and clean the magnet ⑧ whenever the transmission is disassembled.


Torque Value		
A: 6mm Bolt	12 N·m (1.2 kg-m, 9 lb-ft)	
B: 6mm Special bolt A	15 N·m (1.5 kg-m, 11 lb-ft)	
C: 8mm Bolt	26 N·m (2.6 kg-m, 19 lb-ft)	
D: 10mm Bolt	45 N·m (4.5 kg-m, 33 lb-ft)	
E: 6mm Special bolt B	17 N·m (1.7 kg-m, 12 lb-ft)	

- | | | | |
|--|----------------------------------|------------------------------------|---------------------------------|
| ① SPRING PIN | ②⑨ TAPER ROLLER BEARING
INNER | ⑥① SUPER-LOW 1st SHAFT | ⑩ DOWEL PIN |
| ② 1st/2nd SHIFT FORK SHAFT | ③⑩ NEEDLE BEARING | ⑥② 5th/REVERSE SHIFT
FORK SHAFT | ⑩ 2-4WD SELECTOR |
| ③ SUPER-LOW SHIFT PIECE | ③① TRANSFER SHAFT | ⑥③ 5th SHIFT FORK | ⑩ STOPPER BOLT |
| ④ 1st/2nd SHIFT FORK | ③② TRANSFER DRIVEN GEAR | ⑥④ 3rd/4th SHIFT FORK | ⑩ LOCK PLATE |
| ⑤ SNAP RING | ③③ NEEDLE BEARING | ⑥⑤ 5th/REVERSE SHIFT PIECE | ⑩ O-RING |
| ⑥ FRONT DIFFERENTIAL ASSEMBLY | ③④ SUPER-LOW SHIFT LEVER | ⑥⑥ LOCK WASHER | ⑩ SPEEDOMETER GEAR |
| ⑦ SNAP RING | ③⑤ SUPER-LOW SHIFT
PIECE B | ⑥⑦ OIL GUIDE PLATE | ⑩ CLUTCH HOUSING |
| ⑧ LOCKNUT | ③⑥ SPRING PIN | ⑥⑧ THRUST SHIM | ⑩ THRUST SHIM |
| 110 → 0 → 110N·m (11.0 → 0
→ 11.0 kg-m, 80 → 0 → 80lb-ft) | ③⑦ SUPER-LOW SHIFT
FORK SHAFT | ⑥⑨ BALL BEARING | Selection, page 8-18 |
| ⑨ SPRING WASHER | ③⑧ LOCK WASHER | ⑦① SYNCHRO SLEEVE | ⑩ TRANSFER DRIVE GEAR |
| ⑩ BALL BEARING | ③⑨ SUPER-LOW SHIFT FORK | ⑦② SYNCHRO HUB | ⑩ TAPER ROLLER BEARING
INNER |
| ⑪ 5th GEAR | ③⑩ THRUST SHIM | ⑦③ SYNCHRO SPRING | ⑪ BEARING OUTER RACE |
| ⑫ 4th GEAR | ③⑪ BALL BEARING | ⑦④ SYNCHRO RING | ⑫ O-RING |
| ⑬ 3rd GEAR | ③⑫ DISTANCE COLLAR | ⑦⑤ 5th GEAR | ⑬ TRANSFER THRUST SHIM |
| ⑭ 2nd GEAR | ③⑬ NEEDLE BEARING | ⑦⑥ NEEDLE BEARING | ⑭ TRANSFER L.SIDE COVER |
| ⑮ NEEDLE BEARING | ③⑭ FRICTION DAMPER | ⑦⑦ SPACER COLLAR | ⑮ SELECTOR SLEEVE |
| ⑯ DISTANCE COLLAR | ③⑮ SUPER-LOW 2nd GEAR | ⑦⑧ 4th GEAR | ⑯ TRANSFER DISTANCE COLLAR |
| Selection, page 8-22 | ③⑯ SYNCHRO RING | ⑦⑨ SYNCHRO RING | ⑰ DOWEL PIN A |
| ⑰ FRICTION DAMPER | ③⑰ SYNCHRO SPRING | ⑦⑩ SYNCHRO SPRING | ⑰ TRANSFER CASE |
| ⑱ SYNCHRO RING | ③⑱ SYNCHRO SLEEVE | ⑧① SYNCHRO SLEEVE | ⑱ SPRING |
| ⑲ SYNCHRO SPRING | ③⑲ SYNCHRO HUB | ⑧② SYNCHRO HUB | ⑲ DETENT BALL |
| ⑳ REVERSE GEAR | ③⑳ SUPER-LOW 2nd SHAFT | ⑧③ 3rd GEAR | ⑲ SELECTOR FORK |
| ㉑ SYNCHRO HUB | ④① BALL BEARING | ⑧④ MAINSHAFT | ⑲ DOWEL PIN B |
| ㉒ 1st GEAR | ④② THRUST WASHER | ⑧⑤ THRUST WASHER | ⑲ OIL SEAL |
| ㉓ THRUST WASHER | ④③ THRUST NEEDLE BEARING | ⑧⑥ SPRING WASHER | ⑲ TRANSFER DRIVEN GEAR |
| Selection, page 8-22 | ④④ SUPER-LOW 1st GEAR | ⑧⑦ BALL BEARING | ⑲ TAPER ROLLER BEARING
INNER |
| ㉔ SUPER-LOW 3rd GEAR | ④⑤ NEEDLE BEARING | ⑧⑧ OIL SEAL | ⑲ BEARING OUTER RACE |
| ㉕ COUNTERSHAFT | ④⑥ DISTANCE COLLAR | ⑧⑨ MAGNET | ⑲ TRANSFER SPACER |
| ㉖ NEEDLE BEARING | ④⑦ THRUST WASHER | ⑧⑩ REVERSE IDLER SHAFT | ⑲ O-RING |
| ㉗ OIL GUIDE PLATE | ④⑧ SPRING WASHER | ⑧⑪ WASHER | ⑲ DRIVEN GEAR THRUST SHIM |
| ㉘ BEARING OUTER RACE | ④⑨ DISTANCE COLLAR | ⑧⑫ REVERSE IDLER GEAR | ⑲ TRANSFER REAR COVER |
| | ④⑩ SPRING PIN | ⑧⑬ SPRING PIN | ⑲ THRUST WASHER |
| | | ⑧⑭ LOCK COLLAR | ⑲ BEARING OUTER RACE |
| | | ⑧⑮ REVERSE SHIFT HOLDER | ⑲ TAPER ROLLER BEARING
INNER |
| | | ⑧⑯ SUPER-LOW SHIFT PIECE
BAR | ⑲ OIL SEAL |
| | | ⑧⑰ DETENT BALL | ⑲ COMPANION FLANGE |
| | | ⑧⑱ BALL SPRING | ⑲ TRANSFER DUST COVER |
| | | ⑧⑲ SPRING COLLAR | ⑲ SPRING WASHER |
| | | ⑧⑳ REVERSE SHIFT FORK | ⑲ LOCKNUT |
| | | ⑧㉑ DOWEL PIN | 120 N·m (12 kg-m, 87 lb-ft) |

Mainshaft Thrust Shim

Adjustment

1. Remove the thrust shim and oil guide plate from the transmission housing.
2. Install the 3rd/4th synchro hub, spacer collar, 5th synchro hub, ball bearing and thrust washer on the mainshaft. Install the assembly in the transmission housing.



3. Measure the distance B between the end of the transmission housing and thrust washer.


NOTE:

- Use a straight edge and feeler gauge.
- Measure at three locations and average the readings.

4. Measure the distance C between the surfaces of the clutch housing and bearing inner race.

NOTE:

- Use a straight edge and feeler gauge.
- Measure at three locations and average the readings.



5. Select the correct thickness thrust shim as follows:
 - a. Add the height © of clutch housing ball bearing inner race surface and clutch housing seal surface determined in (step 4) to the measurement ⑤ of mainshaft and transmission housing end in (step 3).
 - b. Subtract the standard clearance 0.94 mm (0.0370 in.) from the dimension determined in step 5a.

Example

Distance B: 2.64 mm (0.1039 in.)
 Distance C : +0.04 mm (0.0016 in.)
 2.68 mm (0.1055 in.)

Thrust shim height: 2.68 mm (0.1055 in.)
 (minimum) -0.94 mm (0.0370 in.)
 1.74 (0.0685 in.)

Part No.	Thickness
23941--PH8--900	1.20 mm (0.0472 in)
23942--PH8--900	1.23 mm (0.0484 in)
23943--PH8--900	1.26 mm (0.0496 in)
23944--PH8--900	1.29 mm (0.0509 in)
23945--PH8--900	1.32 mm (0.0520 in)
23946--PH8--900	1.35 mm (0.0531 in)
23947--PH8--900	1.38 mm (0.0543 in)
23948--PH8--900	1.41 mm (0.0555 in)
23949--PH8--900	1.44 mm (0.0567 in)
23950--PH8--900	1.47 mm (0.0579 in)
23951--PH8--900	1.50 mm (0.0591 in)
23952--PH8--900	1.53 mm (0.0602 in)
23953--PH8--900	1.56 mm (0.0614 in)
23954--PH8--900	1.59 mm (0.0626 in)
23955--PH8--900	1.62 mm (0.0638 in)
23956--PH8--900	1.65 mm (0.0649 in)
23957--PH8--900	1.68 mm (0.0661 in)
23958--PH8--900	1.71 mm (0.0673 in)
23959--PH8--900	1.74 mm (0.0685 in)
23960--PH8--900	1.77 mm (0.0697 in)
23961--PH8--900	1.80 mm (0.0709 in)
23962--PH8--900	1.83 mm (0.0720 in)
23963--PH8--900	1.86 mm (0.0732 in)
23964--PH8--900	1.89 mm (0.0744 in)
23965--PH8--900	1.92 mm (0.0756 in)
23966--PH8--900	1.95 mm (0.0768 in)
23967--PH8--900	1.98 mm (0.0780 in)
23968--PH8--900	2.01 mm (0.0791 in)
23969--PH8--900	2.04 mm (0.0803 in)
23970--PH8--900	2.07 mm (0.0815 in)
23971--PH8--900	2.10 mm (0.0827 in)
23972--PH8--900	2.13 mm (0.0839 in)
23973--PH8--900	2.16 mm (0.0850 in)
23974--PH8--900	2.19 mm (0.0862 in)
23975--PH8--900	2.22 mm (0.0874 in)
23976--PH8--900	2.25 mm (0.0886 in)
23977--PH8--900	2.28 mm (0.0898 in)
23978--PH8--900	2.31 mm (0.0909 in)
23979--PH8--900	2.34 mm (0.0921 in)
23980--PH8--900	2.37 mm (0.0933 in)

Select the thrust shim in the range between
 1.74 mm (0.0685 in.) from the part list.




6. Check the thrust clearance in the manner described below.

- a. Install the shims selected in the transmission housing.
- b. Install the thrust washer and spring washer in the mainshaft.

NOTE:

- Clean the thrust washer, spring washer and shim thoroughly before installation.
- Install the thrust washer, spring washer and shim properly.




- c. Install the mainshaft in the clutch housing.
- d. Place the transmission housing over the mainshaft and onto the clutch housing.
- e. Tighten the clutch and transmission housings with several 10 mm bolts.
- f. Tap the mainshaft with a plastic hammer.

7. Check the thrust clearance in the manner described below.


CAUTION: Measurement should be made at room temperature.

- a. Slide the mainshaft base over the mainshaft.




b. Attach the mainshaft holder to the mainshaft as follows:

- Back-out the mainshaft holder bolt and loosen the two hex bolts.
- Fit the holder over the mainshaft so its lip is towards the transmission.
- Align the mainshaft holder's lip around the groove at the inside of the mainshaft splines, then tighten the hex bolts.



- c. Seat the mainshaft fully by tapping its end with a plastic hammer.
- d. Thread the mainshaft holder bolt in until it just contacts the wide surface of the mainshaft base.
- e. Zero a dial gauge on the end of the mainshaft.



- f. Turn the mainshaft holder bolt clockwise; stop turning when the dial gauge has reached its maximum movement. The reading on the dial gauge is the amount of mainshaft end play.

CAUTION: Turning the shaft holder bolt more than 60 degrees after the needle of the dial gauge stops moving may damage the transmission.


- g. Clearance is correct if reading is between 0.08–0.15 mm (0.0031–0.0059 in.). If not, recheck necessary shim thickness.

Countershaft

Disassembly


1. Raise the locknut tab from the groove of the shaft and remove the locknut and spring washer.
2. Support 4th gear on steel blocks as shown and press the shaft out of ball bearing.

CAUTION: Remove the ball bearing using a press and steel blocks as shown. Use of a jaw-type puller can cause damage to the gear teeth.




3. Remove the friction damper (2nd gear side) from the spacer collar.

NOTE: Disregard the steps 3 and 4 except when selecting a thrust washer or replacing parts.



4. Remove the friction damper (1st gear side) from the Super-Low 3rd gear.




Countershaft

Clearance Inspection



1. Assemble the gears, distance collar, thrust washer, synchro hub, synchro ring, etc. as per the instructions shown below.
2. 4th gear, 5th gear and ball bearing are press fit.



Thrust washer

Part Number	Thickness
23921-PH8-900	1.95 mm (0.07677 in)
23922-PH8-900	1.96 mm (0.07717 in)
23923-PH8-900	1.97 mm (0.07556 in)
23924-PH8-900	1.98 mm (0.07795 in)
23925-PH8-900	1.99 mm (0.07835 in)
23926-PH8-900	2.00 mm (0.07874 in)
23927-PH8-900	2.01 mm (0.07913 in)
23928-PH8-900	2.02 mm (0.07953 in)
23929-PH8-900	2.03 mm (0.07992 in)
23930-PH8-900	2.04 mm (0.08031 in)
23931-PH8-900	2.05 mm (0.08071 in)
23932-PH8-900	2.06 mm (0.08110 in)
23933-PH8-900	2.07 mm (0.08150 in)
23934-PH8-900	2.08 mm (0.08189 in)
23935-PH8-900	2.09 mm (0.08228 in)
23936-PH8-900	2.10 mm (0.08268 in)


Distance collar

Part Number	Thickness
23911-PK5-000	29.03-29.05 mm (1.1429-1.1435 in)
23912-PK5-000	29.01-29.03 mm (1.1421-1.1429 in)
23913-PK5-000	28.99-29.01 mm (1.1413-1.1421 in)
23914-PK5-000	28.97-28.99 mm (1.1405-1.1431 in)
23915-PK5-000	28.95-28.97 mm (1.1398-1.1405 in)

3. Tighten the countershaft locknut to the correct torque.

NOTE: Place the shaft in a vice with soft jaws.

110 → 0 → 110 N · m
(11.0 → 0 → 11.0 kg-m, 80 → 0 → 80 lb-ft)




4. Measure and record the clearance between the super-low gear and thrust washer.

Super-low Gear Clearance:

Standard : 0.03—0.08 mm
(0.001—0.003 in.)

Service Limit: 0.18 mm (0.007 in.)




5. If the clearance is out of tolerance, select the appropriate thrust washer for the correct clearance from the charts on page 8-21

6. Measure the clearance between the 2nd gear and 3rd gear.

2nd and 3rd Gear Clearance:

Standard : 0.03—0.08 mm
(0.001—0.003 in.)

Service Limit: 0.18 mm (0.007 in.)




7. If the clearance is out tolerance, select the appropriate distance collar for the correct clearance from the charts on page 8-21.

Countershaft




Reassembly


1. Using a press, install the friction damper (2nd gear side) to the spacer collar.



2. Using a press install the friction damper (1st. gear side) to the Super-Low 3rd gear.



3. Install the 4th gear, 5th gear and ball bearing using a press as shown.



4. Install the spring washer, tighten the locknut and then stake the locknut tab into the groove.

LOCKNUT

110 → 0 → 110N·m (11.0 → 0 → 11.0 kg-m, 80 → 0 → 80 lb-ft)

Automatic Transmission

2WD Automatic Transmission9 — 1
4WD Automatic Transmission9 — 5



2WD Automatic Transmission

Shift Cable

Adjustment9 — 2

Throttle Control Cable

Adjustment/Inspection9 — 3




Outline of Model Changes

Shift cable adjustment and throttle control cable adjustment/inspection have been changed.


Shift Cable

Adjustment


1. Start the engine. Shift to reverse to see if the reverse gear engages.
2. With the engine off, remove the console.



3. Shift to Neutral, then remove the lock pin from the cable adjuster.



4. Check that the hole in the adjuster is perfectly aligned with the hole in the shift cable.




NOTE: There are two holes in the end of the shift cable. They are positioned 90° apart to allow cable adjustments in 1/4 turn increments.

5. If not perfectly aligned, loosen the locknut on shift cable and adjust as required.
6. Tighten the locknut.
7. Install the lock pin on the adjuster.

NOTE: If you feel the lock pin binding as you re-install it, the cable is still out of adjustment and must be readjusted again.

8. Start the engine and check the shift lever in all gears. If any gear does not work properly, refer to Troubleshooting.

Throttle Control Cable



Adjustment/Inspection


NOTE: Before adjusting the throttle control cable, make sure:

- The throttle cable free play is correct.
- The engine is at normal operating temperature (cooling fan comes on).
- The idle speed is correct.

Inspection :

NOTE: You can work the throttle linkage body with your hand.

1. Remove the throttle cable free play.
2.
 - **Carburetor Engine**
Make sure that the choke is released.
 - **PGM-FI Engine**
Disconnect the vacuum hose from the dashpot diaphragm. Connect the vacuum pump and keep vacuum applied.
3. Apply light thumb pressure to the throttle control lever, then work the accelerator or throttle linkage. The lever should move just as the engine speed increases above idle. If not, proceed to Adjustment.



Adjustment :


1. Loosen the nuts on the control cable at the transmission end and synchronize the control lever to the throttle.

NOTE :

- While continuing to press down the throttle control lever, the throttle linkage is open. The control lever should begin to move at precisely the same time as the linkage.
- Correct "Fine Tune" adjustment of the throttle control cable is critical for proper operation of the transmission and lock-up torque converter.

2. Check the following items before starting the engine:

Depress the accelerator to the floor. While depressed, check that there is play in the throttle control lever.



- Check that the cable moves freely by depressing the accelerator.

4WD Automatic Transmission

Special Tools	9 — 6
Description	9 — 7
4WD Disengagement Precautions	9 — 31
Electrical System	
Circuit Diagram	9 — 32
Component Location	9 — 34
Troubleshooting Procedures	9 — 36
Symptom-to-Component Chart	
Electrical System	9 — 37
Electrical Troubleshooting	9 — 39
A/T Speed Pulser	9 — 59
Lock-up Control Solenoid	
Valve A/B	9 — 60
Shift Control Solenoid Valve A/B	9 — 61
S ₄ Switch	9 — 62
Low (1st) Switch	9 — 62
Hydraulic System	
Symptom-to-Component Chart	
Hydraulic System	9 — 63
Road Test	9 — 66
Pressure Testing	9 — 68
Stall Speed	9 — 73
Fluid Level	9 — 74
Transmission	
Removal	9 — 75
Installation	9 — 79
Shift Cable	
Removal/Installation	9 — 80
Adjustment	9 — 81
Gear Shift Selector	9 — 82
Throttle Control Cable	9 — 83

NOTE :

- This section covers the on-car service of the automatic transmission.
- For automatic transmission service, refer to the S5 Automatic Transmission Maintenance and Repair (No. 62PS500).

Outline of Model Change


The 4WD automatic transmission has been adopted.




Special Tools

Special Tools


Ref. No.	Tool Number	Description	Qty	Remarks
①	07JAJ-PH80100	Drive Gear Gauge	1	
②	07KAJ-PS50100	Driven Gear Dummy Shaft	1	
③	07406-0020003	Gauge Set	1	
③-1	07406-0020201	Gauge Hose	1	
④	07746-0010400	Attachment 52x55mm	1	
⑤	07746-0010500	Attachment 62x68mm	1	
⑥	07746-0030100	Driver 40mm I.D.	1	
⑦	07746-0030400	Attachment 35mm I.D.	1	
⑧	07749-0010000	Driver	1	
⑨	07907-6010300	Socket Wrench Handle	1	
⑩	07926-SD90000	Flange Holder	1	
⑪	07948-SG20200	Oil Seal Driver	1	




①




②



③




③-1



④




⑤




⑥



⑦




⑧



⑨



⑩



⑪

Description



The Automatic Transmission is a combination of a 3-element torque converter and triple-shaft automatic transmission which provides 4 speeds forward and 1 speed reverse. The entire unit is positioned in line with the engine.

Torque Converter, Gears and Clutches

The torque converter consists of a pump, turbine and stator, assembled in a single unit.

The torque converter is connected to the engine crankshaft so they turn together as a unit as the engine turns. Around the outside of the torque converter is a ring gear which meshes with the starter pinion when the engine is being started. The entire torque converter assembly serves as a while transmitting power to the transmission mainshaft.

The transmission has three parallel shafts, the mainshaft, countershaft and sub-shaft. The mainshaft is in line with the engine crankshaft.

The mainshaft includes the clutches for 1st, and 2nd/4th, and gears for 3rd, 2nd, 4th, Reverse and 1st (3rd gear is integral with the mainshaft, while reverse gear is integral with 4th gear).

The countershaft includes 3rd clutch and gears for 2nd, 3rd, and 4th, Reverse and 1st.

4th and reverse gears can be locked to the countershaft at its center, providing 4th gear or Reverse, depending on which way the selector is moved.

The sub-shaft includes the low hold clutch.

The gears on the mainshaft are in constant mesh with those on the countershaft. When certain combinations of gears in the transmission are engaged by the clutches, power is transmitted from the mainshaft to the countershaft to provide **[S]**, **[D]**, **[2]** and **[R]**.

Electronic Control

The electronic control system consists of an automatic control unit, sensors, and 4 solenoid valves. Shifting and lock-up are electronically controlled for comfortable driving under all conditions.

The A/T control unit is located under the driver's seat.

Hydraulic Control

The valve assembly includes the main valve body, secondary valve body, servo valve body, regulator valve body and lock-up valve body, through the respective separator plates.

They are bolted to the torque converter case as an assembly.

The main valve body contains the manual valve, 1-2 shift valve, 2-3 shift valve, 3-4 shift valve, pressure relief valve, 3rd orifice control valve, and oil pump gear.

The secondary valve body includes the CPC valve, servo control valve, modulator valve, kickdown valves, 4th relief valve and 2nd orifice control valve.

The servo valve body contains the accumulator pistons, throttle B valve, and the servo valve.

The regulator valve body contains the torque converter check valve, pressure regulator valve and lock-up control valve. Fluid from the regulator passes through the manual valve to the various control valves.

The lock-up shift valve body contains a lock-up timing valve B and lock-up shift valve.

Shift Control Mechanism

Input from various sensors located throughout the car determines which shift control solenoid valve the A/T control unit will activate. Activating a shift control solenoid valve changes modulator pressure, causing a shift valve to move. This pressurizes a line to one of the clutches, engaging that clutch and its corresponding gear.

Lock-up Mechanism

In **[S]** or **[D]**, in 2nd, 3rd and 4th, pressurized fluid is drained from the back of the torque converter through an oil passage, causing the lock-up piston to be held against the torque converter cover. As this takes place, the mainshaft rotates at the same speed as the engine crankshaft. Together with hydraulic control, an electronic control unit optimizes the timing of the lock-up mechanism.

The lock-up shift valve body controls the range of lock-up according to lock-up control solenoid valves A and B, and throttle valve B. When lock-up control solenoid valves A and B activate, modulator pressure changes. Lock-up control solenoid valves A and B are mounted on the torque converter housing, and are controlled by the A/T control unit.

(cont'd)

Description

Gear Selection


The selector lever has six positions: **P** PARK, **R** REVERSE, **N** NEUTRAL, **D** 1st through 4th gear ranges, **S** 1st through 3rd gear ranges, and **2** 2nd gear.

Position	Description
P PARK	Front wheels locked; parking pawl engaged with parking gear on countershaft. All clutches released.
R REVERSE	Reverse; reverse selector engaged with countershaft reverse gear and 4th gear clutch locked.
N NEUTRAL	All clutches released.
D DRIVE (1 through 4)	General driving; starts off in 1st, shifts automatically to 2nd, 3rd, then 4th, depending on vehicle speed and throttle position. Downshift through 3rd, 2nd and 1st on deceleration to stop. The lock-up mechanism comes into operation in D .
S DRIVE (1 through 3)	For rapid acceleration at highway speeds and general driving; starts off in 1st, shifts automatically to 2nd, then 3rd (S4 switch: OFF), and then 4th (S4 switch: ON) depending on vehicle speed and throttle position. Downshifts through 2nd to 1st on deceleration to stop.
2 SECOND	For engine braking or better traction starting off on loose or slippery surfaces. LOW switch: OFF; stays in 2nd gear LOW switch: ON and below 30 mph (50 km/h approx.); in 1st gear LOW switch: ON and above 30 mph (50 km/h approx.); in 2nd gear

Starting is possible only in **P** and **N** through the use of a slide-type, neutral-safety switch.

Position Indicator

A position indicator in the instrument panel shows what gear has been selected without having to look down at the console.





Clutches

1st Clutch

The 1st clutch is on the right end of the mainshaft. In the [2], [S] or [D] position, constant hydraulic pressure is applied to the mainshaft through the 1st clutch to the mainshaft 1st gear.

The clutch plate is mounted on the clutch drum, while the clutch disc is fitted to the mainshaft 1st gear.

The 1st gears are attached to the mainshaft and countershaft through needle bearings, one for each gear.

When select lever is placed in the [2], [S] or [D] position, hydraulic pressure is applied from the right side cover through the mainshaft, and thus to the clutch drum; as the pressure rises, the clutch piston presses the clutch plate and clutch disc, thus causing the clutch to engage.

Power is transmitted from the mainshaft 1st gear, through the countershaft 1st gear, to the one-way clutch, parking gear, and finally to the countershaft. The one-way clutch locks in the forward direction when in 1st gear. In the [2], [S] or [D] position, all others beside 1st gear are not engaged, thus transmitting no power.

Low Hold Clutch

The low hold clutch is on the sub-shaft paralleled with the mainshaft, to transmit the power without affecting the one-way clutch.

2nd Clutch

The 2nd clutch is right of center on the mainshaft and is the same construction as the 1st clutch;

The 2nd clutch is joined back-to-back to the 4th clutch. The mainshaft 2nd gear uses a needle bearing. The countershaft 2nd gear is splined on the countershaft.

In 2nd gear of [2], [S] or [D], hydraulic pressure is applied to the clutch drum from the mainshaft, thus transmitting power from the mainshaft 2nd gear to the countershaft 2nd gear.

3rd Clutch

The 3rd clutch is on the right end of the countershaft.


The clutch hub is joined to the countershaft 3rd gear, on the countershaft, supported by a single needle bearing.

In 3rd gear of [S] or [D], hydraulic pressure is applied to the 3rd clutch on the countershaft, thus causing the clutch to engage, and transmitting power.

4th Clutch

The 4th clutch is identical to the 2nd clutch, to which it is joined on the mainshaft. The clutch hub is joined to the mainshaft 4th gear and reverse gear, supported by two needle bearings.

In 4th gear of [D] or [S] with S4 switch turned on, hydraulic pressure is generated within the mainshaft, applying pressure to the 4th clutch on the mainshaft.



(cont'd)



Description

Clutches (cont'd)

One-way Clutch

A one-way sprag clutch disengages 1st gear when in the 2nd, 3rd and 4th gear ranges. The clutch is splined to the countershaft between the 1st gear and the parking gear. It is composed of sprag elements and the retainer which supports the central section of the sprags. When the respective gears move in the → directions, the sprags incline to the left, with the result that they lock the gears together.

When shifting from 1st to 2nd in the [2] position with LOW switch ON, or in the [S] or [D] position, the different ratio of the two gears causes the countershaft to rotate (via 2nd gear) at a speed greater than that of 1st gear. As a result, the parking gear is rotated in the → direction, and the sprags move away from their locking position. In the 3rd or 4th gear of [S] or [D] the same difference of ratio keeps the sprags from locking and keeps 1st gear disengaged.





Lock-up Clutch


1. Operation (clutch on)

With the lock-up clutch on, the oil in the chamber between the converter cover and lock-up piston is discharged, and the converter oil exerts pressure through the piston against the converter cover. As a result, the converter turbine is locked on the converter cover firmly. The effect is to bypass the converter, thereby placing the car in direct drive.

Power flow

The power flows by way of:

Engine
↓
Drive plate
↓
Torque converter cover
↓
Lock-up piston
↓
Damper spring
↓
Turbine
↓
Mainshaft




2. Operation (clutch off)

With the lock-up clutch off, the oil flows in the reverse of CLUTCH ON. As a result, the lock-up piston is moved away from the converter cover; that is, the torque converter lock-up is released.

Power flow

Engine
↓
Drive plate
↓
Torque converter cover
↓
Pump
↓
Turbine
↓
Mainshaft



Description


Power Flow

Position \ Part	Torque Converter	Sub-shaft 1st Gear, Low Hold Clutch	1st Gear 1st Clutch	1st Gear One-way Clutch	2nd Gear 2nd Clutch	3rd Gear 3rd Clutch	4th		Reverse Gear	Parking Gear
							Clutch	Gear		
P	○	×	×	×	×	×	×	×	×	○
R	○	×	×	×	×	×	○	×	○	×
N	○	×	×	×	×	×	×	×	×	×
S	1st	○	×	○	×	×	×	×	×	×
	2nd	○	×	※○	○	×	×	×	×	×
	3rd	○	×	※○	×	○	×	×	×	×
	4th (S4 : ON)	○	×	※○	×	×	○	○	×	×
D	1st	○	×	○	×	×	×	×	×	×
	2nd	○	×	※○	○	×	×	×	×	×
	3rd	○	×	※○	×	○	×	×	×	×
	4th	○	×	※○	×	×	○	○	×	×
2	2nd	○	×	※○	○	×	×	×	×	×
	1st Acceleration	○	○	○	×	×	×	×	×	×
	1st Deceleration	○	○	※○	×	×	×	×	×	×

○ : Engaged

×

※ : Also the 1st clutch engaged, power is not transmitted by means of one-way clutch.





Electronic Control System

The electronic control system consists of the automatic control unit, sensors, and 4 solenoid valves. Shifting and lock-up are electronically controlled for comfortable driving under all conditions.

The automatic control unit is located under the driver's seat.

Shift control

Getting a signal from each sensor, the automatic control unit detects the appropriate gear shifting and activates shift control solenoid valves A and/or B.

The combination of driving signals to shift control solenoid valves A and B is shown in the table below.

Shift control sol. valve Position (gear)	A	B
<input type="checkbox"/> <input type="checkbox"/> (1st)	OFF	ON
<input type="checkbox"/> <input type="checkbox"/> (2nd)	ON	ON
<input type="checkbox"/> <input type="checkbox"/> (3rd)	ON	OFF
<input type="checkbox"/> <input type="checkbox"/> with S4 ON (4th)	OFF	OFF
<input type="checkbox"/> (1st)	ON	ON
<input type="checkbox"/> (2nd)	ON	OFF

Lock-up control

From sensor input signals, the automatic control unit detects whether to turn the lock-up ON or OFF and activates lock-up control solenoid valve A and/or B accordingly.


The combination of driving signals to lock-up control solenoid valves A and B is shown in the table below.

Solenoid valve Lock-up condition	A	B
Lock-up OFF	OFF	OFF
Lock-up, slight	ON	OFF
Lock-up, half	ON	ON
Lock-up, full	ON	ON
Lock-up during deceleration	ON	Duty operation OFF ↔ ON

(cont'd)

Description

Electronic Control System (cont'd)



Description

Hydraulic Flow


No.	DESCRIPTION OF PRESSURE	No.	DESCRIPTION OF PRESSURE	No.	DESCRIPTION OF PRESSURE	No.	DESCRIPTION OF PRESSURE
1	LINE	5	CPC	30	3RD CLUTCH	91	TORQUE CONVERTER
2	LINE	6	MODULATE	31	3RD CLUTCH	92	TORQUE CONVERTER
2'	LINE	6'	MODULATE (DUTY CONTROL)	40	4TH CLUTCH	93	OIL COOLER
3	LINE	10	1ST CLUTCH	41	4TH CLUTCH	94	TORQUE CONVERTER
3'	LINE	15	LOW HOLD CLUTCH	42	4TH CLUTCH	95	LUBRICATION
3''	LINE	20	2ND CLUTCH	55	THROTTLE B	96	TORQUE CONVERTER
4	LINE	21	2ND CLUTCH	55'	THROTTLE B	99	SUCTION
4'	CPC	22	2ND CLUTCH	90	TORQUE CONVERTER	X	BLEED

N Position

As the engine turns, the oil pump also starts to operate. Automatic Transmission Fluid is drained from (99) and discharged into (1). Then, ATF pressure is controlled by the regulator valve and becomes the line pressure (1). The torque converter inlet pressure (1) enters (94) of torque converter through the orifice and discharges into (90).

The torque converter check valve prevents the torque converter pressure from falling.

Under this condition, the hydraulic pressure is not applied to the clutches as the manual valve stops line pressure (1).




NOTE: When used, "left" or "right" indicates direction on the flow chart.

Hydraulic Flow (cont'd)

2nd Gear in **2** Position

The flow of fluid up to the 2-3 shift valve is same as in the 1st gear. As the speed of the vehicle reaches the prescribed value, the shift control solenoid valve B is turned off (shift control solenoid valve A remains on). The 2-3 shift valve is moved to the left, consequently the low hold clutch pressure (15) becomes the 2nd clutch pressure (20) as it passes through the 2-3 shift valve, and passes to the 2nd clutch.

The hydraulic pressure also flows to the 1st clutch. However no power will transmit by means of the one way clutch.



NOTE: When used, "left" or "right" indicates direction of the flow chart.

Description

Hydraulic Flow (cont'd)


2nd Gear in **S** or **D** Position

The flow of fluid up to the 1-2 and 2-3 shift valves is the same as in the 1st speed. When the vehicle speed is increased and reaches the prescribed value, the solenoid valve A is turned on by means of the control unit. As a result, the 1-2 shift valve is moved to the left and uncovers the port leading to the 2nd clutch; the 2nd clutch is engaged.

The fluid flows by way of:

—Line Pressure (4) → Clutch Pressure Control Valve—Clutch Pressure Control Pressure (4') → 1-2 Shift Valve—Clutch Pressure Control Pressure (5) → 2-3 Shift Valve—2nd Clutch Pressure (22) → Orifice—2nd Clutch Pressure (20) → 2nd Clutch.

The hydraulic pressure also flows to the 1st clutch. However no power will transmit by means of the one-way clutch.



NOTE: When used, "left" or "right" indicates direction on the flow chart.




3rd Gear in **S** or **D** Position

The flow of fluid up to the 1-2, 2-3 and 3-4 shift valves is the same as in the 2nd speed. As the speed of the car reaches the prescribed value, the shift control solenoid valve B is turned off (shift control valve A remains on). The 2-3 shift valve is then moved to the left, uncovering the oil port leading to the 3rd clutch. Since the 3-4 shift valve is moved to the right to cover the oil port to the 4th clutch, the 3rd clutch is turned on.

Fluid flows by way of:

—Line Pressure (4) → Clutch Pressure Control Valve—Clutch Pressure Control Pressure (4') → 1-2 Shift Valve—Clutch Pressure Control Pressure (5) → 2-3 Shift Valve—3rd Clutch Pressure (31) → 3-4 Shift Valve (not controlled)—3rd Clutch Pressure (31) → 3rd Clutch

The hydraulic pressure also flows to the 1st clutch. However no power will transmit by means of the one-way clutch as in the 2nd gear.



NOTE: When used, "left" or "right" indicates direction on the flow chart.

(cont'd)

Description

Hydraulic Flow (cont'd)


4th Gear in **S** Position with S4 Switch Turned On, or **D** Position

The flow of fluid up to the 1-2, 2-3 and 3-4 shift valves is the same as in the 3rd speed. When the speed of the car reaches the prescribed value, the shift control solenoid valve A is turned off (shift control solenoid valve B remains off). As this takes place, 3-4 shift valve is moved to the left and uncovers the oil port leading to the 4th clutch. Since the 1-2 and 2-3 shift valves are kept on the left side, the fluid flows through the 4th clutch; the power is transmitted through the 4th clutch.

Fluid flows by ways of:

- Line Pressure (4) → Clutch Pressure Control Valve—Clutch Pressure Control Pressure (4') → 1-2 Shift Valve—Clutch Pressure Control Pressure (5) → 2-3 Shift Valve—3rd Clutch Pressure (31) → 3-4 Shift Valve—3rd Clutch Pressure (31) → 3-4 Shift Valve—4th Clutch Pressure (42) → Manual Valve—4th Clutch Pressure (40) → 4th Clutch

The hydraulic pressure also flows to the 1st clutch. However no power will transmit by means of the one-way clutch as in 2nd and 3rd gears.



NOTE: When used, "left" or "right" indicates direction on the flow chart.



R Position


The flow of fluid through the torque converter circuit is the same as in the **N**. The fluid (1) from the oil pump flows through the manual valve and becomes the line pressure (3). It then flows through the 1-2 shift valve to the servo valve (3), causing the shift fork shaft to be moved in the reverse direction.

Under this condition, the shift control solenoid valve A on whereas the valve B is turned off as in 3rd. As a result, the 1-2 shift valve is also moved to the left. The fluid (3)' will flow through the servo valve and manual valve to the 4th clutch; power is transmitted through the 4th clutch.

Reverse Inhibitor Control

When the **R** position is selected while the vehicle is moving forward at a speed over 10 km/h, the control unit outputs 1st signal (A: OFF, B: ON), the 1-2 shift valve is moved to the right. The line pressure (3) is intercepted by the 1-2 shift valve, consequently the power is not transmitted as the 4th clutch and servo valve are not operated.

When the select lever is moved from the **R** position to the **D**, **S** or **2** position, the servo control valve is moved to the left by the 1st or 2nd pressure to move the servo valve.



NOTE: When used, "left" or "right" indicates direction on the flow chart.

(cont'd)


Description

Hydraulic Flow (cont'd)

P **Position**

The flow of fluid through the torque converter is the same in **N** position.

The line pressure (1) is intercepted by the manual valve, and is not supplied to the clutches. The power is not transmitted.




NOTE: When used, "left" or "right" indicates direction on the flow chart.



Lock-Up Operation

1. No Lock-Up

The pressurized fluid regulated by the modulator works on both ends of the lock-up shift valve and on the left side of the lock-up control valve. Since, under this condition, the pressures working on both ends of the lock-up shift valve are equal, the shift valve is moved to the right by the tension of the valve spring alone. The fluid from the oil pump will flow through the left side of the lock-up clutch to the torque converter; i. e., the lock up clutch is in OFF condition.



NOTE: When used, "left" or "right" indicates direction on the flow chart.

(cont'd)

Description

Hydraulic Flow (cont'd)

2. Partial Lock-Up

Lock-Up Control Solenoid Valve A : ON

Lock-Up Control Solenoid Valve B : OFF


The control unit switches the solenoid valve A to on to release the modulator pressure in the left cavity of the lock-up shift valve. The modulator pressure in the right cavity of the lock-up shift valve overcomes the spring force, thus the lock-up shift valve is moved to the left side.

The modulator pressure is separated to the two passages:

Torque Converter Inner Pressure: entered into right side — to engage lock-up clutch

Torque Converter Back Pressure: entered into left side — to disengage lock-up clutch

The back pressure (F2) is regulated by the lock-up control valve whereas the position of the lock-up timing valve B is determined by the throttle B pressure, tension of the valve spring and pressure regulated by the modulator. Also the position of the lock-up control valve is determined by the throttle valve B pressure, back pressure of the lock-up control valve and torque converter pressure regulated by the check valve. In low speed range, the throttle B pressure working on the right side of the lock-up control valve is low, causing the valve to be moved to the right. With the lock-up control solenoid valve B kept off, the modulator pressure is maintained in the left end of the lock-up control valve; in other words, the lock-up control valve is moved but slightly to the left side. This slight movement of the lock-up control valve causes the back pressure to be lowered slightly, resulting in partial.



NOTE: When used, "left" or "right" indicates direction on the flow chart.




3. Half Lock-Up

Lock-Up Control Solenoid Valve A: ON Lock-Up Control Solenoid Valve B: ON

The modulator pressure is released by the solenoid valve B, causing the modulator pressure in the left cavity of the lock-up control valve to lower.

Also the modulator pressure in the left cavity of the lock-up timing valve B is low. However the throttle B pressure is still low at this time, consequently the lock-up timing valve B is kept on the right side by the spring force.

With the lock-up control solenoid valve B turned on, the lock-up control valve is moved somewhat to the left side, causing the back pressure (F2) to lower. This allows greater amount of the fluid (F1) to work on the lock-up clutch so as to engage the clutch. The back pressure (F2) which still exists prevents the clutch to be engaged fully.



NOTE: When used, "left" or "right" indicates direction on the flow chart.

(cont'd)

Description

Hydraulic Flow (cont'd)

4. Full Lock-Up


Lock-Up Control Solenoid Valve A : ON

Lock-Up Control Solenoid Valve B : ON

When the vehicle speed further increases, the throttle valve B pressure is increased in accordance with the throttle opening.

The lock-up timing valve B overcomes the spring force and moves to the left side. Also this valve closes the oil port leading to the torque converter check valve.

Under this condition, the throttle B pressure working on the right end of the lock-up control valve becomes greater than that on the left end (modulator pressure in the left end has already been released by the solenoid valve B); i. e., the lock-up control valve is moved to the left. As this happens, the torque converter back pressure is released fully, causing the lock-up clutch to be engaged fully.




NOTE: When used, "left" or "right" indicates direction on the flow chart.



5. Deceleration Lock-Up

Lock-Up Control Solenoid Valve A: ON Lock-Up Control Solenoid Valve B: Duty Operation (ON ↔ OFF)

The A/T control unit switches the solenoid valve B to on and off alternately in high speed under certain condition. The slight lock-up and half lock-up regions are maintained so as to lock the torque converter properly.




NOTE: When used, "left" or "right" indicates direction on the flow chart.

Description


Hydraulic Control

The valve body includes the main valve body, the second accumulator body, the regulator valve body, the secondary valve body, the servo body, and the lock-up valve body.

The oil pump is driven by splines on the right end of the torque converter which is attached to the engine. Oil flows through the regulator valve, to maintain specified pressure through the main valve body to the manual valve, governor valve, and servo body, directing pressure to each of the clutches.



4WD Disengagement Precautions




The 4WD System shifts instantaneously and automatically from front wheel drive to four wheel drive when greater traction is needed.

WARNING The 4WD system must be manually disengaged before performing service that requires only the front wheels or only the rear wheels to be turning. Disengaging the system will prevent sudden movement of the car, which may result in personal injury.


Towing:

CAUTION: Before towing the car with either the front or rear wheels raised off the ground, place the transmission in neutral and manually disengage the 4WD system to prevent the raised wheels from turning.




4WD Disengagement:

1. With the car on the ground, locate the orange disengagement lever on the transmission.





2. Loosen the lock bolt at the slotted end of the lever.




3. Move the lever by turning the middle bolt counter-clockwise.
4. Confirm that the lever is in the fully disengaged position by rocking the car back and forth while placing slight counterclockwise pressure on the middle bolt. Tighten lock bolt to 14 N·m (1.4 kg-m, 11 lb-ft).
5. After service or towing is complete, return the lever to the normal engaged position.


Circuit Diagram





Component Location






Troubleshooting Procedures

The A/T Control Unit has a built-in self-diagnosis function. The S₄ indicator light in the gauge assembly and LED display on the A/T control unit blink when the A/T control unit senses an abnormality in the input or output systems. The number of blinks from the LED display varies according to the problem, which can be diagnosed by counting the number of blinks.

For problem diagnosis count the number of blinks from the LED display as shown on the Symptom-to-Component Chart. If no abnormality is found from your inspection, refer to the hydraulic system Symptom-to-Component Chart.



When the ignition switch is turned ON, the S₄ indicator light comes on for about two seconds regardless of whether there is a problem. The S₄ indicator light will also come on when in S₄ mode.

If there is a system problem, the S₄ indicator light will come on and continue to blink until the ignition key is turned OFF. When the ignition key is turned ON again, the S₄ indicator light will not blink again for the original problem. But if the A/T control unit senses the original abnormality again with ignition switch ON, the S₄ indicator light will blink again for the original problem. Therefore, even though the S₄ indicator light does not come on when turning the ignition key ON, check the LED display for automatic transmission problem diagnosis.


Since the LED problem code is retained in memory, it will blink again whenever the ignition key is turned on. If the LED problem code is not memorized, check the following causes:

- Check the Hazard fuse (10A) in the main fuse box.
- Check for an open circuit in the WHT/GRN wire between the Hazard fuse (10A) and A/T control unit B12 terminal.

After making repair, disconnect the Hazard fuse (10A) in the main fuse box for more than ten seconds to reset LED display memory.

Symptom-to-Component Chart

Electrical System



Number of LED display blinks	S ₄ indicator light	Symptom	Probable Cause	Ref. page
1	Blinks	<ul style="list-style-type: none"> • Lock-up clutch does not engage. • Lock-up clutch does not disengage. • Frequent engine stalling. • Low light does not blink. 	<ul style="list-style-type: none"> • Disconnected lock-up control solenoid valve A connector • Open or short in lock-up control solenoid valve A wire. • Faulty lock-up control solenoid valve A 	9 — 43
2	Blinks	<ul style="list-style-type: none"> • Lock-up clutch does not engage. • Low light does not blink. 	<ul style="list-style-type: none"> • Disconnected lock-up control solenoid valve B connector • Open or short in lock-up control solenoid valve B wire. • Faulty lock-up control solenoid valve B 	9 — 44
3	Blinks or OFF	<ul style="list-style-type: none"> • Lock-up clutch does not engage. • Low light does not blink. 	<ul style="list-style-type: none"> • Disconnected throttle angle sensor connector • Open short in throttle angle sensor wire • Faulty throttle angle sensor 	9 — 45
4	Blinks	<ul style="list-style-type: none"> • Lock-up clutch does not engage. • Low light does not blink. 	<ul style="list-style-type: none"> • Disconnected speed pulser connector • Open or short in speed pulser wire • Faulty speed pulser 	9 — 46
5	Blinks	<ul style="list-style-type: none"> • Fails to shift other than 2nd↔4th gear. • Lock-up clutch does not engage. • Low light does not blink. 	<ul style="list-style-type: none"> • Short in shift Position console switch wire. • Faulty shift position console switch 	9 — 47
6	OFF	<ul style="list-style-type: none"> • Fails to shift other than 2nd↔4th gear. • Lock-up clutch does not engage. • Lock-up clutch engages and disengages alternately. • Low light does not blink. 	<ul style="list-style-type: none"> • Disconnect shift position console switch connector • Open in shift position console switch wire • Faulty shift position console switch. 	9 — 49
7	Blinks	<ul style="list-style-type: none"> • Fails to shift other than 1st↔4th, 2nd↔4th, or 2nd↔3rd gears. • Fails to shift (stuck in 4th gear). • Low light does not blink. 	<ul style="list-style-type: none"> • Disconnected shift control solenoid valve A connector • Open or short in shift control solenoid valve A wire • Faulty shift control solenoid valve A 	9 — 51
8	Blinks	<ul style="list-style-type: none"> • Fails to shift (stuck in 1st gear or 4th gear). • Low light does not blink. 	<ul style="list-style-type: none"> • Disconnected shift control solenoid valve B connector • Open or short in shift control solenoid valve B wire • Faulty shift control solenoid valve B 	9 — 52
9	Blinks	<ul style="list-style-type: none"> • Lock-up clutch does not engage. • Low light does not blink. 	<ul style="list-style-type: none"> • Disconnected A/T speed pulser • Open or short in A/T speed pulser wire • Faulty A/T speed pulser 	9 — 53
10	Blinks	<ul style="list-style-type: none"> • Lock-up clutch does not engage. • Lock light does not blink. 	<ul style="list-style-type: none"> • Disconnected coolant temperature sensor connector • Open or short in coolant temperature sensor wire • Faulty coolant temperature sensor 	9 — 54
11	OFF	<ul style="list-style-type: none"> • Lock-up clutch does not engage. • Low light does not blink. 	<ul style="list-style-type: none"> • Disconnected ignition coil connector • Open or short in ignition coil wire • Faulty ignition coil 	9 — 55

NOTE:

- If a customer describes the symptoms for codes 3, 6 or 11, yet the LED is not blinking, it will be necessary to recreate the symptom by test driving, and then checking the LED with the ignition STILL ON.
- If the LED display blink 12 or more times, the control unit is faulty.

(cont'd)

Symptom-to-Component Chart

Electrical System (cont'd)

If the self-diagnosis LED indicator does not blink, perform an inspection according to the table listed below.

Symptom	Probable Cause	Ref. page
S ₄ light is not on for 2 seconds after ignition is first turned on.	_____	9 — 39
Low light is not on for 2 seconds after ignition is first turned on.	_____	9 — 40
Do not change S ₄ mode.	Check S ₄ switch signal	9 — 41
Do not change Low mode.	Check Low switch signal	9 — 56
Lock-up clutch does not dusty operation (ON↔OFF)	Check A/C signal with operation A/C.	9 — 57
Lock-up clutch does not engage		
Fails to shift from 2nd to 1st gear when shift up to S or D range from releasing brakepetal with shift lever in N range	Check brake light switch signal.	9 — 58



Electrical Troubleshooting

Troubleshooting Flow Chart

S₄ indicator light does not come on with the ignition switch ON. (It should come on for about 2 sec.)

Disconnect the 12 P connector from the control unit.

Check for continuity between the B1 (BLK/RED) terminal and body ground, and between the B6 (BLK/RED) terminal and body ground.

Is there continuity?

NO

Repair open in BLK/RED wire between the B1 terminal and G101 and/or between the B6 terminal and G101.

YES

Turn the ignition switch ON.

Measure voltage between the B2 (BLK/YEL) and B1 (BLK/RED) terminals, and between the B7 (BLK/YEL) and B1 terminals.

Is there battery voltage?

NO

Repair open or short in BLK/YEL wire between the B2/B7 terminal and the dash fuse box.

YES

Turn the ignition switch OFF.

Measure resistance between the B11 (YEL/RED) and B1 BLK/RED terminals.

Is the resistance more than 100 Ω ?

NO

Repair Short in YEL/RED wire between the B11 terminal and the gauge assembly.

YES

Connect the 12P connector to the control unit.

Turn the ignition switch ON. Be sure that the voltage is available for 2 sec. between the B11 (YEL/RED) terminal and B1 BLK/RED terminals.

Is the voltage 6-12 V?


YES

Check for open or short in YEL/RED wire between the B11 terminal and the gauge assembly. If wire is OK, check the S₄ Indicator Light Bulb and the Safety Indicator Circuit.

NO

Check for loose control unit connectors. If necessary, substitute a known good control unit and recheck.

View from wire side.



Electrical Troubleshooting

Troubleshooting Flow Chart

Low indicator light does not come on with the ignition switch ON. (It should come on for about 2 sec.)

Disconnect the 12 P connector from the control unit.

Check for continuity between the B1 (BLK/RED) terminal and body ground, and between the B6 (BLK/RED) terminal and body ground.

Is there continuity?

NO

Repair open in BLK/RED wire between the B1 terminal and G101 and/or between the B6 terminal and G101.

YES

Turn the ignition switch ON.

Measure voltage between the B2 (BLK/YEL) and B1 (BLK/RED) terminals, and between the B7 (BLK/YEL) and B1 terminals.

Is there battery voltage?

NO

Repair open or short in BLK/YEL wire between the B2/B7 terminal and the dash fuse box.

YES

Turn the ignition switch OFF.

Measure resistance between the B10 (RED/YEL) and B1 (BLK/RED) terminals.

Is the resistance more than 100 Ω ?

NO

Repair Short in RED/YEL wire between the B10 terminal and the gauge assembly.

YES

Connect the 12P connector to the control unit.

Turn the ignition switch ON. Be sure that the voltage is available for 2 sec. between the B10 (RED/YEL) terminal and B1 (BLK/RED) terminals.

Is the voltage 6-12 V?





YES

Check for open or short in RED/YEL wire between the B10 terminal and the gauge assembly. If wire is OK, check the Low Indicator Light Bulb and the Safety Indicator Circuit.

NO

Check for loose control unit connectors. If necessary, substitute a known good control unit and recheck.

View from wire side.





S₄ won't engage.

Disconnect the 18P and 12P connectors from the control unit.

Check for continuity between the A13 (GRN) and B1 (BLK/RED) terminals.

Is there continuity? YES

Check for short in GRN wire between the A13 terminal and the S₄ switch. If wire is OK, check the S₄ Switch (page 9-62).

NO

Check for continuity between the A13 (GRN) and B1 (BLK/RED) terminals while pressing the S₄ switch.


Is there continuity? NO

Check for open in GRN wire between the A13 terminal and the S₄ switch. If wire is OK, check the S₄ Switch (page 9-62).

YES

Check for loose control unit connectors. If necessary, substitute a known good control unit and recheck.

View from wire side.



Electrical Troubleshooting

Troubleshooting Flow Chart

Fails to shift from 2nd to first on releasing the brake pedal when stopped in D or S.

Depress the brake pedal and check that the brake lights come on.

Do the lights come on?

NO

Repair the Brake Light Circuit.

YES

Disconnect the 18P and 12P connectors from the control unit.

Depress the brake pedal.

Measure the voltage between the A12 (GRN/WHT) and B1 (BLK/RED) minals.

Is there battery voltage?


NO

Repair open in GRN/WHT wire between the A12 and the brake light switch.

YES

Check for loose control unit connectors. If necessary, substitute a known good control unit and recheck

View from wire side.





Self-diagnosis LED indicator blinks once.

Disconnect the 12P connector from the control unit.

Turn the ignition switch ON.

Measure the voltage between the B3 (RED) and B1 (BLK/RED) terminals.

Is there voltage?

YES

Repair short to power source in RED wire between the B3 terminal and the lock-up control solenoid valve A.

NO

Turn the ignition switch OFF.

Measure the resistance between the B3 (RED) and B1 (BLK/RED) terminals.

Is the resistance 14-30Ω?

NO

Check for open in RED wire between the B3 terminal and the lock-up control solenoid valve A. If wire is OK, check the Lock-up Control Solenoid valve A.

YES

Disconnect the 2P connector from the lock-up control solenoid valves assembly.

Check for continuity between the B3 (RED) and B1 (BLK/RED) terminals.

Is there continuity?

YES




Repair short to ground in RED wire between the B3 terminal and the lock-up control solenoid valve A.

NO

Connect the 2P connector to the lock-up control solenoid valve assembly.

Check for loose control unit connectors. If necessary, substitute a known good control unit and recheck.

View from wire side.



Electrical Troubleshooting

Troubleshooting Flow Chart

Self-diagnosis LED indicator blinks twice.

Disconnect the 12P connector from the control unit.

Turn the ignition switch ON.

Measure the voltage between the B8 (GRN/BLK) and B1 (BLK/RED) terminals.

Is there voltage?

YES

NO

Turn the ignition switch OFF.

Measure the resistance between the B8 (GRN/BLK) and B1 (BLK/RED) terminals.

Is the resistance 14-30 Ω ?

NO

YES

Disconnect the 2P connector from the lock-up control solenoid valves assembly.

Check for continuity between the B8 (GRN/BLK) and B1 (BLK/RED) terminals.

Is there continuity?




YES


NO

Connect the 2P connector to the lock-up control solenoid valve assembly.



Check for loose control unit connectors. If necessary, substitute a known good control unit and recheck.

View from wire side.





View from wire side.



* $\pm 10\%$

Electrical Troubleshooting

Troubleshooting Flow Chart

Self-diagnosis LED indicator blinks four times.

Jack up the front of the car and block one wheel.

▲WARNING

- Set the parking brake securely and block the rear wheels.
- Jack up the front of the car and support with a rigid rack.

Turn the ignition switch ON and shift transmission to N

Rotate the front wheel and measure the voltage between the A6 (YEL/RED) and B1 (BLK/RED) terminals.

Does the voltage 0 — 5 V appear alternately?

NO

YES

Substitute a known good control unit and recheck.

Turn the ignition switch OFF.

Disconnect the 18P and 12P connectors from the control unit.

Turn the ignition switch ON.

Rotate the front wheel and check for voltage between the B1 (BLK/RED) and A6 (YEL/RED) terminals.



Does the voltage 0 — 5 V appear alternately?

NO

YES

Check for loose control unit connectors. If necessary, substitute a known good control unit and recheck.

View from wire side.



Check for short or open in YEL/RED wire between the A6 terminal and the gauge assembly. If wire is OK, check the Speed Pulser.



Self-diagnosis LED indicator blinks five times.

Turn the ignition switch ON.

Shift to other than R position.

Measure the voltage between the A1 (GRN/RED) and B1 (BLK/RED) terminals.

Is there battery voltage?

NO

YES

Shift to other than N position.

Measure the voltage between the A2 (GRN) and B1 (BLK/RED) terminals.

Is there battery voltage?

NO

YES

Shift to other than D position.

Measure the voltage between the A3 (GRN/BLK) and B1 (BLK/RED) terminals.

Is there battery voltage?

NO

YES




(To page 9-48).

Check for short in GRN/RED wire between the A1 terminal and the shift position console switch. If wire is OK, check for loose connectors. If necessary, substitute a known good control unit and recheck.

Check for short in GRN wire between the A2 terminal and the shift position console switch. If wire is OK, check for loose control unit connectors. If necessary, substitute a known good control unit and recheck.

Check for short in GRN/BLK wire between the A3 terminal and the shift position console switch. If wire is OK, check for loose control unit connectors. If necessary, substitute a known good control unit and recheck.

View from wire side.



(cont'd)

Electrical Troubleshooting

Troubleshooting Flow Chart (cont'd)

(From page 9-47)

Shift to other than S position.

Measure the voltage between the A4 (GRN/BLU) and B1 (BLK/RED) terminals.

Is there battery voltage?

NO

YES

Shift to other than 2 position.

Measure the voltage between the A5 (GRN/YEL) and B1 (BLK/RED) terminals.


Is there battery voltage?

NO


YES

Substitute a known good control unit and recheck.

View from wire side.



Check for short in GRN/BLU wire between the A4 terminal and the shift position console switch. If wire is OK, check for loose control unit connectors. If necessary, substitute a known good control unit and recheck.



Check for short in GRN/YEL wire between the A5 terminal and the shift position console switch. If wire is OK, check for loose control unit connectors. If necessary, substitute a known good control unit and recheck.



Self-diagnosis LED indicator blinks six times.

Turn the ignition switch ON.

Shift to R position.

Measure the voltage between the A1 (GRN/RED) and B1 (BLK/RED) terminals.

Is there voltage?

YES

Repair open in GRN/RED wire between the A1 terminal and the shift position console switch.

NO

Shift to N position.

Measure the voltage between the A2 (GRN) and B1 (BLK/RED) terminals.

Is there voltage?

YES

Repair open in GRN wire between the A2 terminal and the shift position console switch.

NO

Shift to D position.

Measure the voltage between the A3 (GRN/BLK) and B1 (BLK/RED) terminals.

Is there voltage?




YES

Repair open in GRN/BLK wire between the A3 terminal and the shift position console switch.

NO

(To page 9-50)

View from wire side.




(cont'd)

Electrical Troubleshooting

Troubleshooting Flow Chart (cont'd)

(From page 9-49)





Self-diagnosis LED indicator blinks seven times.

Disconnect the 12P connector from the control unit.

Turn the ignition switch ON.

Measure the voltage between the B4 (BLU) and B1 (BLK/RED) terminals.

Is there voltage? YES
NO

Repair short to power source in BLU wire between the B4 terminal and the shift control solenoid valve A.

Turn the ignition switch OFF.

Measure the resistance between the B4 (BLU) and B1 (BLK/RED) terminals.

Is the resistance 12-24 Ω ? NO
YES

Check for open in BLU wire between the B4 terminal and the shift control solenoid valve A. If wire is OK, check the Shift Control Solenoid Valve A.

Disconnect the 2P connector from the shift control solenoid valves assembly.

Check for continuity between the B4 (BLU) and B1 (BLK/RED) terminals.




Is there continuity? YES
NO

Repair short to ground in BLU wire between the B4 terminal and the shift control solenoid valve A.

Connect the 2P connector to the shift control solenoid valves assembly.


Check for loose control unit connectors. If necessary, substitute a known good control unit and recheck.

View from wire side.






Electrical Troubleshooting

Troubleshooting Flow Chart



View from wire side.





Self-diagnosis LED indicator blinks nine times.

Jack up the front of the car.

WARNING

- Set the parking brake securely and block the rear wheels.
- Jack up the front of the car and support with a rigid rack.

Turn the ignition switch ON.

Rotate the front wheels and measure the voltage between the A7 (BRN/BLK) and B1 (BLK/RED) terminals.


Do 0 and approx. 5 V appear alternately?

NO

YES

Substitute a known good control unit and recheck.


View from wire side.



Turn the ignition switch OFF.

Disconnect the 18P and 12P connectors from the control unit.

Rotate the front wheels and check for continuity between the A7 (BRN/BLK) and B1 (BLK/RED) terminals.



Do continuity and infinity alternately appear?

NO

YES

Check for open or short in BRN/BLK wire between the A7 terminal and the A/T speed pulser. If wire is OK, check the A/T Speed Pulser.

Check for loose control unit connectors. If necessary, substitute a known good control unit and recheck.

Electrical Troubleshooting

Troubleshooting Flow Chart

Self-diagnosis LED indicator blinks ten times.

Turn the ignition switch ON.

Check whether the PGM-FI LED display blinks.

Does the LED blink?

NO

Repair the PGM-FI System.

YES

Turn the ignition switch OFF.

Disconnect the 18P and 12P connectors from the control unit.

Turn the ignition switch ON.

Measure the voltage between the A15 (BLU/WHT) and B1 (BLK/RED) terminals.

Is the voltage 4.75 — 5.25 V?

NO

Repair open or short in BLU/WHT wire between the A15 terminal and the A32 terminal of the PGM-FI ECU.

YES

Turn the ignition switch OFF.

Connect the 18P and 12P connectors to the control unit.

Start the engine and warm it up to normal operating temperature.

Measure the voltage between the A11 (RED/WHT) and B1 (BLK/RED) terminals.

Is the voltage 0.50 — 1.20 V?



NO

Repair open or short in RED/WHT wire between the A11 terminal and the coolant temperature sensor.

YES

Check for loose control unit connectors. If necessary, substitute a known good control unit.

View from wire side.





Self-diagnosis LED indicator blinks eleven times.

Disconnect the 18P and 12P connectors from the control unit.

Start the engine.

Measure the voltage between the A10 (BLU) and B1 (BLK/RED) terminals.

Is there battery voltage?


NO

Repair open or short in BLU wire between the A10 terminal and the ignition coil.

YES


Check for loose control unit connectors. If necessary, substitute a known good control unit and recheck.


View from wire side.



Electrical Troubleshooting


Troubleshooting Flow Chart





Electrical Troubleshooting

Troubleshooting Flow Chart




A/T Speed Pulser




Test

1. Apply the parking brake, jack up the front and rear of the car.
2. Disconnect the A/T speed pulser 2P connector.
3. Rotate the front wheels and be sure that continuity and no continuity appear alternately between the two terminals.




Removal/Inspection

1. Remove the 6 mm bolt from the transmission housing and remove the A/T speed pulser assembly.



2. Bring a magnet close to the A/T speed pulser assembly and check for continuity.



A/T speed pulser assembly is in good condition if there is:

- Continuity with a magnet close to the pulser assembly.
- No continuity with a magnet away from the pulser assembly.

If the A/T speed pulser is normal, go to Rotor Disassembly/Inspection.

3. Replace the O-ring with a new one before reassembling the A/T speed pulser.

CAUTION: Carefully inspect the A/T speed pulser before installing. Do not install it that shows signs of being dropped or improperly handled.

Lock-up Control Solenoid Valve A/B

Test


NOTE: Lock-up control solenoid valves A and B must be removed/replaced as an assembly.

1. Disconnect the connector from the lock-up control solenoid valve A/B.

NOTE: Do not remove the lock-up control solenoid valve A/B stay.

2. Measure the resistance between the No.1 terminal (SOL. V A) of the lock-up control solenoid valve connector and body ground and between the No. 2 terminal (SOL. V B) and body ground.

STANDARD: 14–30 Ω



3. Replace the lock-up control solenoid valve assembly if the resistance is out of specification.
4. Connect the No.1 terminal of the lock-up control solenoid valve connector to the battery positive terminal and body ground. Connect the No.2 terminal to the battery positive terminal and body ground. A clicking sound should be heard each time the connection is made.
5. If not, check for continuity between the A/T control unit B3 or B8 harness and body ground. (page 9 – 43, 44)
6. Replace the lock-up control solenoid valve assembly if there is continuity between the A/T control unit B3 or B8 harness and body ground. (page 9 – 43, 44)


Replacement

1. Remove the mounting bolts and lock-up control solenoid valve assembly.

NOTE: Be sure to remove or replace the lock-up control solenoid valves A and B as an assembly.

2. Check the lock-up control solenoid valve oil passages for dust or dirt and replace as an assembly, if necessary.

BOLT
12 N·m
(1.2 kg-m, 9 lb-ft)



3. Clean the mounting surface and oil passages of the lock-up control solenoid valve assembly and install a new base gasket.
4. Check the connector for rust, dirt or oil and reconnect it securely.

Shift Control Solenoid Valve A/B



Test


NOTE: Shift control solenoid valves A and B must be removed/replaced as an assembly.

1. Disconnect the connector from the shift control solenoid valve A/B.

NOTE: Do not remove the shift control solenoid valve A/B stay.

2. Measure the resistance between the No.1 terminal (SOL. V A) of the solenoid valve connector and body ground and between the No.2 terminal (SOL. V B) and body ground.

STANDARD: 12–24 Ω




3. Replace the shift control solenoid valve assembly if the resistance is out of specification.
4. Connect the No.1 terminal of the solenoid valve connector to the battery positive terminal and the No.2 terminal to the battery positive terminal. A clicking sound should be heard each time the connection is made.
5. If not check for continuity between the harness and body ground.
6. Replace the shift control solenoid valve assembly if there is continuity between the harness and body ground.

Replacement

1. Remove the mounting bolts and shift control solenoid valve assembly.

NOTE: Be sure to remove or replace the shift control solenoid valves A and B as an assembly.

2. Check the shift control solenoid valve oil passages for dust or dirt and replace as an assembly, if necessary.




3. Clean the mounting surface and oil passages of the shift control solenoid valve assembly and install a new base gasket.
4. Check the connector for rust, dirt or oil and reconnect it securely.

S4 Switch

Test

1. Remove the center console.
2. Disconnect the switch connector.
3. Check for continuity between A and B terminals. There should be continuity when the switch is pressed.





LOW (1st) Switch

Test


1. Remove the console.
2. Disconnect the switch connector and remove the LOW switch.
3. Check for continuity between the terminals by pressing and releasing the switch button according to the table below.

TERMINAL	B	A	C	D	E
POSITION					
PRESS	○	○		○	○
RELEASE				○	○



Symptom-to-Component Chart

Hydraulic System



SYMPTOM	Check these items on PROBABLE CAUSE LIST	Check these items on NOTES PAGE	PROBABLE CAUSE
Engine runs, but car does not move in any gear.	1, 2, 3, 6, 7, 8, 39, 44	K, L, R, S	1. ATF level too low 2. Oil pump seized, gear damaged, foreign matter stuck in gear
Car moves in 2, but not in S or D	7, 9, 10, 11	C, M, O	3. Regulator valve stuck or spring weak/damaged
Car moves in S or D, but not in 2	7, 12, 13	C	4. Servo shaft stuck
Car moves S, D or 2, but not in R	4, 7, 14, 23, 36, 59	C, N, Q	5. 3rd gears worn/damaged 6. Mainshaft damaged
Poor acceleration Engine races when starting off in S: —Stall rpm high in S, D and 2	1, 2, 3, 7, 44, 47	C K, L	7. Shift cable misadjusted or cut; end pin disconnected
—Stall rpm high in S and D	7, 9, 11	M, N	8. Final gear worn/damaged
—Stall rpm high in 2	7, 13, 16	O	9. Countershaft and one-way clutch seized/damaged
—Stall rpm normal	17, 35, 50, 51		10. 1st gear worn/damaged
—Stall rpm low			11. 1st clutch faulty a. Clutch piston stuck b. Foreign matter stuck in clutch check valve c. Clutch O-ring worn/damaged d. Clutch disc worn e. Clutch feed pipe/O-ring worn/damaged
Excessive idle vibration	2, 35, 39, 50, 51	B, K, L	12. 2nd gear worn/damaged
No up shift	57, 46	J, L	13. 2nd clutch faulty a. Clutch piston stuck b. Foreign matter stuck in clutch check valve c. Clutch O-ring worn/damaged d. Clutch disc worn e. Clutch seal ring seized/damaged
Jumps from 1st to 3rd in S	57		14. Reverse gears worn/damaged
Jumps from 1st to 4th in D	54, 57		15. ATF level too high
Shift-up point too early/late: —1st to 2nd, 2nd to 3rd, 3rd to 4th	57		16. Torque converter one-way clutch seized
—1st to 2nd	23, 53, 57		17. Engine throttle cable misadjusted
—2nd to 3rd	24, 54, 57		18. Intake manifold vacuum tube broken
—3rd to 4th	25, 53, 57		19. Vacuum modulator valve (Throttle valve B) faulty
Harsh upshift from 1st to 2nd	13, 19, 20, 18, 23, 29	A, C, D, E, V	20. 1-2 shift valve faulty
Harsh upshift from 2nd to 3rd	19, 21, 23, 18, 24, 26, 29, 30, 33	A, C, D, E, H, V	21. 2-3 shift valve faulty
Harsh upshift from 3rd to 4th	19, 22, 24, 18, 25, 30, 31, 32, 34	A, C, D, E, V	22. 3-4 shift valve faulty
Harsh downshift from 2nd to 1st	19, 20, 23, 18, 26, 29, 40, 62	A, C, D, E, H, V	23. 2nd accumulator faulty
Harsh downshift from 3rd to 2nd	19, 21, 23, 18, 24, 31, 41, 61	A, C, D, E, I, T, V	24. 3rd accumulator faulty
Harsh downshift from 4th to 3rd	19, 22, 24, 18, 25, 32, 42, 58, 60	A, C, D, E, V	25. 4th accumulator faulty
Engine races when shifting from 2nd to 3rd. (Shift point OK)	19, 21, 23, 18, 24, 26, 27, 31, 33	C, D, E, H, U, V	26. 2nd orifice control valve faulty
Engine races when shifting from 3rd to 4th. (Shift point OK)	19, 22, 24, 18, 25, 27, 30, 32, 34	C, D, E, I, U, V	27. Foreign material in main orifice
Excessive shock when shifting from 2nd to 3rd (Shift point OK)	19, 23, 24, 18, 29, 41, 48	E, V	28. Foreign material in 1st orifice
Excessive shock when shifting from 3rd to 4th (Shift point OK)	19, 24, 25, 18, 30, 31, 42, 48	E, I, V	29. Foreign material in 2nd orifice
Car creeps forward in N (Shift cable adjusted properly).	11, 13, 33, 34, 36, 37, 38	C, D	30. 3rd orifice control valve faulty
Excessive time lag from N to S/D (Shift cable adjusted properly).	11, 28	C	31. Foreign material in 3rd orifice
			32. Foreign material in 4th orifice
			33. 3rd clutch faulty a. Clutch piston stuck b. Foreign material stuck in clutch check valve c. Clutch O-ring worn/damaged d. Clutch disc worn e. Clutch feed pipe/O-ring worn/damaged
			34. 4th clutch faulty a. Clutch piston stuck b. Foreign material stuck in clutch check valve c. Clutch O-ring worn/damaged d. Clutch disc worn e. Clutch feed pipe/O-ring worn/damaged
			35. Engine power low
			36. Needle bearing seized
			37. Thrust washer seized

(cont'd)

Symptom-to-Component Chart

Hydraulic System (cont'd)

SYMPTOM	Check these items on PROBABLE CAUSE LIST	Check these items on NOTES PAGE	PROBABLE CAUSE
Excessive time lag from N to R (Shift cable adjusted properly).	4,20,34,59	C	38. Clutch clearance incorrect
Abnormal noise in all gears, neutral and park	2,5,43	K,L,Q	39. Drive plate faulty or transmission assembly im- properly installed.
Engine accelerates up to 31 mph (50 km/h), but not more	16		40. 2nd check ball stuck
Vibration in all gears	39		41. 3rd check ball stuck
Hard to shift	7,45	P	42. 4th check ball stuck
Car has only 4th gear	57	L	43. Mainshaft/countershaft bearing damaged
Transmission has no parking	7,45	P	44. Oil filter clogged
Stall rpm is high, but clutch pressure OK in all positions	47		45. Body/case shift cable joint damaged
Lock-up clutch disengagement —Engine stalls easily —No power in low/middle speed —Noise/vibration in low/middle speed —Excessive shock while shifting	18,19,49,50, 51,52,55,56, 57	E,V	46. Modulator valve faulty
Lock-up clutch hunts ON-OFF —Engine RPM goes up and down while holding throttle steady. —Car surges back and forth while driving.	18,19,51,55, 56,57	E,V	47. Torque converter check valve faulty
Lock-up clutch does not engage	18,19,47,49, 50,51,55,57	E,V	48. Foreign material in separator orifice
			49. Lock-up timing valve B faulty
			50. Lock-up shift valve faulty
			51. Lock-up piston in torque converter faulty
			52. Lock-up control valve faulty
			53. Shift control solenoid valve A faulty
			54. Shift control solenoid valve B faulty
			55. Lock-up control solenoid valve A faulty
			56. Lock-up control solenoid valve B faulty
			57. Automatic transmission control unit faulty
			58. 4th exhaust valve faulty
			59. Servo control valve faulty
			60. 4-3 kickdown valve faulty
			61. 3-2 kickdown valve faulty
			62. 2-1 orifice control valve faulty



The following symptoms can be caused by improper repair or assembly.	Check these items on PROBABLE CAUSE DUE TO IMPROPER REPAIR	Check these ITEMS ON NOTES PAGE
Car creeps in N.	R1, R2	
Car does not move in S or D.	R5	
Trans lock up in R.	R4	
Trans has no park.	R3	
Excessive drag in trans.	R8	R, K
Excessive vibration, rpm related.	R9	
Noise with wheels moving only.	R7	
Main seal pops out.	R10	S
Various shifting problems.	R11, R12	
Harsh upshifts.	R13	

PROBABLE CAUSES DUE TO IMPROPER REPAIR	
R1	Improper clutch clearance
R2	Improper gear clearance
R3	Parking pawl installed upside down
R4	Parking shift arm installed upside down
R5	Sprag clutch installed upside down
R6	Feed pipe missing in governor shaft
R7	Reverse hub installed upside down
R8	Oil pump binding
R9	Torque converter not fully seated in oil pump
R10	Main seal improperly installed
R11	Springs improperly installed
R12	Valves improperly installed
R13	Ball check valves not installed
R14	Shift fork bolt not installed

NOTES	
A	Flushing procedure (repeat 3 times): 1. Drain the trans. 2. Refill with 3 qts. of Dexron recommended type ATF. 3. Start the engine and shift trans to D. 4. Let trans shift through gears at least 5 times. 5. Shift to reverse and neutral at least 5 times. 6. Drain and refill.
B	Set idle rpm in gear to specified idle speed. If still no good, adjust the motor mounts as outlined in engine section of service manual.
C	If the large clutch piston O-ring is broken, inspect the piston groove for rough machining.
D	If the clutch pack is seized, or is excessively worn, inspect the other clutches for wear, and check the orifice control valves and throttle valves for free movement.
E	If throttle valve B is stuck, inspect the clutches for wear.
G	If the 1—2 valve is stuck closed, the transmission will not upshift. If stuck open, the transmission has no low gear.
H	If the 2nd orifice control valve is stuck, inspect the 2nd and 3rd clutch packs for wear.
I	If the 3rd orifice control valve is stuck, inspect the 3rd and 4th clutch packs for wear.
J	If the clutch pressure control valve is stuck closed, the transmission will not shift out of low gear.

NOTES	
K	Improper alignment of main valve body and torque converter case may cause oil pump seizure. The symptoms are mostly an rpm-related ticking noise high pitched squeak. In severe instances, it may stall the engine. Follow instruction procedure.
L	If the oil screen is clogged with particles of steel or aluminum, inspect the oil pump and differential pinion shaft. If both are OK, and no cause for the contamination is found, replace the torque converter.
M	If the low clutch feedpipe guide in the end cover is scored by the mainshaft, inspect the ball bearing for excessive movement in the transmission housing. If OK, replace the end cover as it is dented. The O-ring under the guide is probably broken.
N	Replace the mainshaft if the bushings for the low and 4th feedpipe are loose or damaged. If the low feedpipe is damaged or out of round, replace it. If the 4th feedpipe is damaged or out of round, replace the end cover.
O	A worn or damaged sprag clutch is mostly a result of shifting the trans in S or D while the wheels rotate in reverse, such as rocking the car in snow.
P	Inspect the frame for collision damage.
Q	Inspect for damage or wear: 1. ATV Sensor shaft woodruff key 2. Reverse selector gear teeth chamfers 3. Engagement teeth chamfers of countershaft 4th & reverse gear 4. Shift fork, for scuff marks in center 5. Differential pinion shaft for wear under pinion gears 6. Bottom of 3rd clutch for swirl marks Replace items 1, 2, 3 and 4 if worn or damaged. If trans makes clicking, grinding or whirring noise, also replace mainshaft 4th gear and reverse idler gear and counter 4th gear in addition to 1, 2, 3, or 4. If differential pinion shaft is worn, overhaul differential assy and replace oil screen and thoroughly clean trans, flush torque converter and cooler and lines. If bottom of 3rd clutch is swirled and trans makes gear noise, replace countershaft and ring gear.
R	Be very careful not to damage the torque converter case when replacing the main ball bearing. You may also damage the oil pump when you torque down the main valve body; this will result in oil pump seizure if not detected. Use proper tools.
S	Install the main seal flush with the torque converter case. If you push it into the torque converter case until it bottoms out, it will block the oil return passage and result in damage.
T	Harsh downshifts when coasting to a stop with zero throttle may be caused by a bent-in throttle valve B (vacuum modulator valve).
U	Check if servo valve check valve stopper cap is installed. If it was not installed, the check valve may have been pushed out by hydraulic pressure causing a leak (internal) affecting all forward gears.
V	Throttle cable adjustment is essential for proper operation of the transmission. Not only does it affect the shift points if misadjusted but also the shift quality and lockup clutch operation. A too long adjusted cable will result in throttle pressure being too low for the amount of engine torque input into the transmission, and may cause clutch slippage. A too short adjusted cable will result in too high throttle pressures which may cause harsh shifts, erratic shifts and torque converter hunting.

Road Test

NOTE: After transmission is installed:

- Make sure the floor mat does not interfere with accelerator pedal travel. Fully depress accelerator pedal and check to make sure the throttle lever is fully opened.
- Release the accelerator pedal and check both inner control cables to be sure they have slight play.

Warm up the engine to operating temperature.

D and **S** Range

1. Apply parking brake and block the wheels. Start the engine, then move the selector to **D** while depressing the brake pedal. Depress the accelerator pedal, and release it suddenly. Engine should not stall.
2. Check that shift points occur at approximate speeds shown. Also check for abnormal noise and clutch slippage.
3. Apply parking brake and block the wheels. Start the engine, then move the selector **S** while depressing the brake pedal. Depress the accelerator pedal, and release it suddenly. Engine should not stall.

• Upshift

D		1st—2nd	2nd—3rd	3rd—4th	LC.ON
1/12 throttle	km/h	14—18	27—33	45—52	21—25
Coasting down-hill from a stop	mph	8.7—11.2	16.7—20.6	28.1—32.5	13.1—15.6
1/2 throttle	km/h	33—39	62—70	95—105	108—112
Acceleration from a stop	mph	20.5—24.3	38.5—43.6	59.0—65.3	67.1—69.7
Full-throttle	km/h	55—63	102—110	152—160	143—147
Acceleration from a stop	mph	34.1—39.2	63.3—68.4	94.4—99.5	88.8—91.4

S (with S4 switch in operation)		1st—2nd	2nd—3rd	3rd—4th	LC.ON
1/12 throttle	km/h	20—24	32—38	49—55	38—42
Coasting down-hill from a stop	mph	12.4—15.0	19.8—23.7	30.4—34.2	23.6—26.2
7/16 throttle	km/h	33—39	64—72	95—105	112—116
Acceleration from a stop	mph	20.5—24.3	39.7—44.8	59.0—65.3	69.6—72.1
Full-throttle	km/h	55—63	102—110	152—160	143—147
Acceleration from a stop	mph	34.1—39.2	63.3—68.4	94.4—99.5	88.8—91.4

2 (LOW switch OFF)		1st—2nd
1/12 throttle	km/h	13—17
Coasting down-hill from a stop	mph	8.0—10.6
7/16 throttle	km/h	24—30
Acceleration from a stop	mph	14.9—18.7
Full-throttle	km/h	50—58
Acceleration from a stop	mph	31.0—36.1



• Downshift

		LC.OFF	4th—3rd	3rd—2nd	2nd—1st
1/12 throttle	km/h	17—21	27—33	—	9—15
	mph	10.5—13.1	16.7—20.6	—	5.5—9.4
7/16 throttle When car is slowed by increased grade, wind, etc.	km/h	81—85	—	—	—
	mph	50.3—52.9	—	—	—
Full-throttle When car is slowed by increased grade, wind, etc.	km/h	138—142	130—140	85—95	42—50
	mph	85.7—88.3	80.7—87.1	52.8—59.1	26.1—31.1

Ⓢ (with S4 switch in operation)

		LC.OFF	4th—3rd	3rd—2nd	2nd—1st
1/12 throttle	km/h	37—41	27—33	—	9—15
	mph	22.9—25.5	16.7—20.6	—	5.5—9.4
7/16 throttle When car is slowed by increased grade, wind, etc.	km/h	92—96	—	—	—
	mph	57.1—59.7	—	—	—
Full-throttle When car is slowed by increased grade, wind, etc.	km/h	138—142	130—140	85—95	46—54
	mph	85.7—88.3	80.7—87.1	52.8—59.1	28.5—33.6

CAUTION: Do not shift from ⓓ or Ⓢ to 2 (LOW switch OFF) at speeds over 100 km/h (62.5 mph); you may damage the transmission.

2 (LOW switch OFF)

		2nd—1st
1/12 throttle	km/h	7—13
	mph	4.3—8.1
7/16 throttle When car is slowed by increased grade, wind, etc.	km/h	—
	mph	—
Full-throttle When car is slowed by increased grade, wind, etc.	km/h	44—54
	mph	27.3—33.6

CAUTION: Do not shift from ⓓ or Ⓢ to 2 (LOW switch ON) at speeds over 55 km/h (34.2 mph); you may damage the transmission.

2 (2nd Gear)

1. Accelerate from a stop at full throttle. Check that there is no abnormal noise or clutch slippage.
2. Upshifts and downshifts should not occur with the selector in this range.

R (Reverse)

Accelerate from a stop at full throttle, and check for abnormal noise and clutch slippage.

P (Park)

Park car on a slope (approx. 16°), apply the parking brake, and shift into Park. Release the brake; the car should not move.

Pressure


Testing

CAUTION: Before testing, be sure transmission is filled to proper level.

NOTE:

- Stop engine when attaching hoses for pressure tests.
Torque hose fitting to 18 N·m (1.8 kg-m, 12 lb-ft).
- Do not reuse aluminum washers.


GAUGE SET 07406-0020003
(includes pressure hose set 07406-0020201)



Line Pressure Measurement

1. Set the parking brake securely.
2. Run the engine at 2,000 min⁻¹ (rpm).

**LINE PRESSURE
INSPECTION HOLE**




PRESSURE	SELECTOR POSITION	SYMPTOM	PROBABLE CAUSE	FLUID PRESSURE	
				Standard	Service Limit
Line	N or P	No (or low) Line pressure	Torque converter, oil pump pressure regulator, torque converter check valve, oil pump	785–834 kPa (8.0–8.5 kg/cm ² , 114–121 psi)	735 kPa (7.5 kg/cm ² , 107 psi)



Clutch Pressure Measurement

1. Jack up the front and rear of the car and support them with rigid racks.
2. Run the engine at $2,000 \text{ min}^{-1}(\text{rpm})$.



PRESSURE	SELECTOR POSITION	SYMPTOM	PROBABLE CAUSE	FLUID PRESSURE	
				Standard	Service Limit
1st Clutch	S or D	No or low 1st pressure	1st Clutch	785—834 kPa (8.0—8.5 kg/cm ² , 114—121 psi)	735kPa (7.5 kg/cm ² , 107 psi)
1st Hold Clutch	2 (With S, switch in operation)	No or low 1st hold ressure	1st Hold Clutch	785—834 kPa (8.0—8.5 kg/cm ² , 114—121 psi)	735 kPa (7.5 kg/cm ² , 107 psi)
2nd Clutch	2 (With S, switch OFF.)	No or low 2nd pressure	2nd Clutch	785—834 kPa (8.0—8.5 kg/cm ² , 114—121 psi)	735 kPa (7.5 kg/cm ² , 107 psi)
2nd Clutch	S or D	No or low 2nd pressure	2nd Clutch	490 kPa (5.0 kg/cm ² , 71 psi) (throttle fully closed)	441 kPa (4.5 kg/cm ² , 64 psi) (throttle fully closed)
3rd clutch	S (With S, switch OFF.)	No or low 3rd pressure	3rd Clutch	834 kPa (8.5 kg/cm ² , 121 psi) (throttle more than 3/8 opened)	735 kPa (7.5 kg/cm ² , 107 psi) (throttle more than 3/8 opened)
4th Clutch	S (With S4 switch in operation) or D	No or low 4th pressure	4th Clutch		
	R		Servo valve or 4th Clutch	735—834 kPa (8.0—8.5 kg/cm ² , 114—121 psi)	735 kPa (7.5 kg/cm ² , 107 psi)

(cont'd)


Pressure

Testing (cont'd)


Low/High Pressure Test

1. Raise car and support with safety stands.
2. Attach the gauge set to the appropriate pressure test port.
3. Remove the cable end of the throttle control cable from the throttle control lever.


NOTE: Do not loosen the locknuts, simply unhook the cable end.




4. Warm up engine to normal operating temperature (cooling fan comes on).
5. With the engine idling, move the selector lever to D3 or D4.
6. Slowly move the throttle linkage to increase engine rpm until pressure is indicated on the appropriate gauge. Then release the throttle linkage, allowing the engine to return to an idle, and record the pressure reading.
7. Repeat step 6 for each clutch pressure being inspected.



8. With the engine idling, lift the throttle control lever up approximately 1/2 of its possible travel and increase the engine rpm until pressure is indicated on the appropriate gauge. Record the highest pressure reading obtained.



9. Repeat step 8 for each clutch pressure being inspected.




PRESSURE	SELECTOR POSITION	SYMPTOM	PROBABLE CAUSE	FLUID PRESSURE kPa (kg/cm ² , psi)	
				Standard	Service Limit
2nd clutch	S or D	No or low 2nd pressure	2nd clutch	490–834 (5.0–8.5, 71–121) Variable engine throttle valve opening.	441–735 (4.5–7.5, 64–107) Variable engine throttle valve opening.
3rd clutch	S (With S₄ switch OFF)	No or low 3rd pressure	3rd clutch		
4th clutch	S (With S₄ switch in operation) or D	No or low 4th pressure	4th clutch		

Pressure

Testing (cont'd)

Throttle B Pressure Measurement

1. Jack up the front and rear of the car and support them with rigid racks.
2. Run the engine at $1,000 \text{ min}^{-1} (\text{rpm})$.
3. Disconnect the throttle control cable from the throttle lever and set the control lever in full throttle position.



PRESSURE	SELECTOR POSITION	SYMPTOM	PROBABLE CAUSE	FLUID PRESSURE	
				Standard	Service Limit
Throttle B	<input checked="" type="checkbox"/> S or <input checked="" type="checkbox"/> D	No (or low) Throttle B pressure	Throttle valve B	785–834 kPa (8.0–8.5 kg/cm ² , 114–121 psi)	735 kPa (7.5 kg/cm ² , 107 psi)

Stall Speed



Test

CAUTION:

- To prevent transmission damage, do not test stall speed for more than 10 seconds at a time.
- Do not shift the lever while rising the engine speed.
- Be sure to remove the pressure gauge before testing stall speed.

1. Engage parking brake and block the front wheels.
2. Connect safety chains to both front two hooks and attach, with minimum slack, to some strong stationary object.
3. Connect tachometer, and start the engine.
4. After the engine has warmed up to normal operating temperature, shift into **D₄**.
5. Fully depress the brake pedal and accelerator for 6 to 8 seconds, and note engine speed.
6. Allow 2 minutes for cooling, then repeat same test in **2**, and **R**.


NOTE: Stall speed in **D₄**, **2** and **R** must be the same, and must also be within limits:

Stall Speed RPM:

Specification: 2,750 min⁻¹ (rpm)

Service Limit: 2,300—2,900 min⁻¹ (rpm)

TROUBLE	PROBABLE CAUSE
Stall rpm high in 2 , D₄ , and R	<ul style="list-style-type: none"> • Low fluid level or oil pump output. • Clogged oil strainer. • Pressure regulator valve stuck closed. • Slipping clutch.
Stall rpm high in D₄ only	<ul style="list-style-type: none"> • Slippage of 1st clutch.
Stall rpm low in 2 , D₄ , and R	<ul style="list-style-type: none"> • Engine output low, throttle cable misadjusted. • Oil pump seized. • Torque converter one-way clutch slipping.



Fluid Level

Checking/Changing

Checking

With the car on level ground, pull the transmission dipstick and check the level of fluid immediately after the engine is shut off (within one minute). The fluid level should be between the full and low marks. Push the dipstick all the way in to check the fluid level. If the level is at, or below, the low mark, add DEXRON-II type automatic transmission fluid.


Changing

1. Bring the transmission up to operating temperature by driving the car. Park the car on level ground, turn the engine off, then remove drain plug.
2. Reinstall the drain plug with a new washer, then refill the transmission to the full mark on the dipstick.

Automatic transmission Capacity:

3.2 l (3.4 U.S. qts., 2.8 Imp. qt) at change

6.4 l (6.8 U.S. qts, 5.8 Imp. qt) after overhaul



Transmission

Removal



⚠ WARNING


- Make sure jacks and safety stands are placed properly, and hoist brackets are attached to correct positions on the engine.
- Apply parking brake and block rear wheels, so car will not roll off stands and fall on you while working under it.

CAUTION: Use fender covers to avoid damaging painted surfaces.

1. Disconnect the battery negative (–) and positive (+) cables from the battery.
2. Remove the 3 mounting bolts and loosen the 1 bolt located at the side of the battery base, and intake hose base, and intake hose band of the throttle body.
3. Remove the air cleaner case complete with the intake hose.
4. Remove the starter motor and transmission ground cables.

5. Disconnect the lock-up control solenoid valve and shift control solenoid valve wire connectors and A/T speed pulser connector.
6. Disconnect the control cable at the control lever.
7. Drain transmission oil/fluid. Use a drive socket wrench to remove the drain plug. Remove the oil filler plug to speed draining. Reinstall the drain plug with a new washer.
8. Disconnect the cooler hoses at the joint pipes.

NOTE: Check for any signs of leak at the hose joints.




(cont'd)

Transmission

Removal (cont'd)

9. Disconnect the connectors and remove the mounting bolts, then remove the distributor from the cylinder head.




10. Remove the shift cable by removing the cotter pin, control pin, control lever roller and loosening the locking nut.

CAUTION: Take care not to bend the cable when removing it and lift the cable hanging by wire it up to the body.

11. Disconnect the speedometer cable.


NOTE: Do not disassemble speedometer gear holder.

12. Remove the 4 mounting bolts, then remove the propeller shaft.



13. Remove the torque converter cover.


14. Remove the plug, then remove the drive plate bolts one at a time while rotating the crankshaft pulley.





15. Remove the engine splash shield and the right wheel well splash shield.
16. Remove the header pipe.
17. Remove the cotter pin and lower arm ball joint nut, separate the ball joint and lower arm.
18. Remove the bolts and nut, then remove the right radius rod.
19. Remove the right, left driveshafts and intermediate shaft.
20. Remove the 9 mounting bolts, then remove the transmission cover.

NOTE: Coat all precision finished surfaces with clean engine oil or grease.
Tie plastic bags over the driveshaft ends.




(cont'd)

Transmission

Removal (cont'd)

21. Install the bolts at the cylinder head and attach a hoist chain to the bolt and the other end to the engine hanger plates, then lift the engine slightly to unload the mounts.
22. Attach a chain hoist to the transmission hoist bracket and transmission housing mounting bolt. Raise the hoist just enough to remove slack from the chain.
23. Place a jack under the transmission and raise transmission just enough to take weight off mounts.
24. Remove the transmission mounting bolt of the engine side.
25. Remove the bolts from the front transmission mount.
26. Remove the rear transmission mount bracket by removing the 4 mounting bolts.
27. Remove the 4 mounting bolts, then remove the side transmission mount.
28. Remove the 4 transmission mounting bolts.
29. Loosen the side engine mounting bolt, tilt the engine and pull the transmission away from the engine until it clears the 14 mm dowel pins, then lower on the transmission jack.





Installation

Install the transmission in the reverse order of removal. After the transmission is in place:

CAUTION: Take care not to bend the cable when installing it.

- Torque engine and transmission mounting bolts in sequence shown.

CAUTION: Failure to tighten the bolts in the proper sequence can cause excessive noise and vibration, and reduce bushing life: check that the bushings are not twisted or offset.

- Check that the spring clip on the end of each drive-shaft clicks into place.

CAUTION: Use new spring clips on installation.


- Refill the transmission with ATF.
- Check the ignition timing.
- Start the engine, set the parking brake, and shift the transmission through all gears three times. Check for proper control cable adjustment.

- Let the engine reach operating temperature with the transmission in Neutral or Park, then turn it off and check the fluid level.
- Road test as described on page 9 — 66.

45 N·m (4.5 kg-m, 33 lb-ft)

STARTER MOTOR

65 N·m (6.5 kg-m, 47 lb-ft)



Shift Cable

Removal/Installation

▲ WARNING


- Make sure jacks and safety stands are placed properly and hoist brackets are attached to correct positions on the engine.
- Apply parking brake and block rear wheels, so car will not roll off stands and fall on you while working under it.

1. Remove the shift cable by removing the cotter pin, control pin, control lever roller and loosening the locking nut.
2. Remove the front console.
3. Remove the lock pin from the cable adjuster, then remove the shift cable.

4. Remove the header pipe.
5. Remove the propeller shaft and front stabilizer.
6. Remove the bolts, then remove the cable grommet holder and grommet.
7. Pull the shift cable out from the engine compartment.

CAUTION: Take care not to bend the cable when removing it.


8. Install the shift cable in the reverse order of removal.
NOTE: On reassembly, check the cable adjustment.






Adjustment

1. Start the engine. Shift to reverse to see if the reverse gear engages. If not, refer to Troubleshooting.
2. With the engine off, remove the console.
3. Shift to **N** position, then remove the lock pin from the cable adjuster.



4. Check that the hole in the adjuster is perfectly aligned with the hole in the shift cable.




NOTE: There are two holes in the end of the shift cable. They are positioned 90° apart to allow cable adjustments in 1/4 turn increments.

5. If not perfectly aligned, loosen the lock nut on shift cable and adjust as required.
6. Tighten the lock nut.
7. Install the lock pin on the adjuster.

NOTE: If you feel the lock pin binding as you reinstall it, the cable is still out of adjustment and must be readjusted.

8. Start the engine and check the shift lever in all gears. If any gear does not work properly, refer to troubleshooting on page 9 — 63.

Gear Shift Selector



Throttle Control Cable



Adjustment/Inspection


NOTE: Before adjusting the throttle control cable, make sure:

- The throttle cable free play is correct.
- The engine is at normal operating temperature (cooling fan comes on).
- The idle speed is correct.

Inspection:

NOTE: You can work the throttle linkage body with your hand.


1. Disconnect the vacuum tube from the dash pot. connect the vacuum pump and keep vacuum applied.
This simulates a normal operating amount of pull by the dash pot as if the engine were running.
2. Remove the throttle cable free play.
3. Apply light thumb pressure to the throttle control lever, then work the accelerator or throttle linkage. The lever should move just as the engine speed increases above idle. If not, proceed to Adjustment.



Adjustment:

1. Loosen the nuts on the control cable at the transmission end and synchronize the control lever to the throttle.

NOTE: To tailor the shift/lock-up characteristics to a particular customers driving expectations, you can adjust the control cable up to 3 mm shorter than the "synchronized" point.



Transfer


Inspection

1. Shift the disengagement lever to 2WD.

LOCK BOLT


14 N·m (1.4 kg-m, 11 lb-ft)

MIDDLE BOLT



2. Check the backlash at the companion flange with a dial indicator; measure as shown, then rotate the flange 180° and measure again.

Standard: 0.10–0.15 mm (0.004–0.006 in.)




3. If the backlash is outside the specifications, adjust as per the instruction described on page 9 – 97.




Gear Tooth Contact

1. Shift the disengagement lever to 2WD.
2. Remove the transfer drive and driven gear assembly.



3. Apply Prussian Blue evenly to the driven gear teeth.
4. Reinstall the gear and tighten the mounting bolts to the correct torque.
5. Turn the companion flange back and forth several times, then remove the driven gear assembly and inspect the pattern on the gear's teeth.





6. If the contact pattern is not as shown, correct it according to the instructions on page 9 — 97.

7. If the tooth contact is correct, reassemble the drive and driven gears as follows.

NOTE:


- Replace the O-ring with a new one.
- Coat the O-ring with oil.
- Apply liquid gasket (P/N OY740—99986) to threads of L. side cover attaching bolts.




Transfer

L. Side Cover Race Replacement

1. Remove the drive gear bearing race with a bearing puller as shown.




2. Install the new race with the special tools as shown.




Transfer Driven Gear Disassembly

1. Slide the driven gear assembly into the torque converter housing and secure with the six bolts.




2. Raise the locknut tab from the groove of the driven gear shaft.
3. Hold the companion flange with the special tool and remove the lock nut with a 32 mm socket.







4. Remove the driven gear from the transfer rear cover by tapping the driven gear shaft.




5. Remove the inner driven gear bearing from the driven gear shaft.




6. Pry the oil seal off the transfer rear cover.



7. Remove the bearing race from the transfer rear cover.



8. Remove the bearing race from the transfer rear cover.




Transfer


Driven Gear Pre-load

NOTE: Clean all tools and parts thoroughly in solvent and dry with compressed air.

1. Press the inner driven gear bearing race into the transfer rear cover with the special tools as shown.




2. Press the outer driven gear bearing race into the transfer rear cover with the special tools as shown.



3. Coat the races with clean oil.

4. Slide the inner driven gear bearing onto the special tools. Install the special tools with bearing into the rear cover.



5. Install the outer driven gear bearing, companion flange, spring washer and driven shaft locknut.

NOTE :


- Use a new driven shaft locknut.
- Do not assemble the oil seal.
- Take care the spring washer direction.



6. Install a screw driver into the special tool and then torque the locknut to 10 N·m (1.0kg-m, 7lb-ft).

**DRIVEN GEAR
DUMMY SHAFT
07KAJ-PS50100**


SCREW DRIVER



7. Measure the driven pinion preload.

NOTE: Before measuring the preload, turn the threaded shaft several times to seat the bearing.

Standard: 0.5–0.8 N·m (5.0–8.0 kg-cm, 4.3–6.9 lb-in)



8. If the preload is outside the above limits, re-adjust by turning the locknut.


NOTE: Do not overtighten the locknut.

Adjustment/Reassembly, (Thrust Shim Selection)

1. Insert the threaded shaft/driven gear rear cover assembly into the transfer housing.

NOTE: The pre-load must be properly adjusted before selecting shims. See page 9 – 88.


2. Remove the drive gear bearing with a bearing puller.



3. Lubricate the drive gear bearing with clean oil, then install it on the Drive Gear Gauge. Slide the bearing and gauge onto the transfer shaft.

NOTE:


- Do not install the drive gear thrust shim.
- Pull the Rear cover assembly out slightly to allow the drive gear gauge to seat.



(cont'd)


Transfer

Adjustment/Reassembly (Thrust Shim Selection) (cont'd)



4. Install L. side cover without the bolts.
5. To determine driven gear thrust shim thickness, measure the clearance between the transfer rear cover and transfer case with a feeler gauge, then record the clearance.

NOTE: The clearance should be taken while pressing the dummy shaft all the way in.



6. The correct rear cover shim thickness is determined by recording the clearance between the transfer rear cover and the transfer case, then adding or subtracting the machining tolerance, which is etched in to the driven gear.

NOTE: The plus (+) or minus (-) number given as machining tolerance represents hundredths of a millimeter.

Example:


- Clearance measured in Step 5: 1.08 mm
- Machining tolerance etched in the driven gear: (+2)

Corrected driven gear thrust shim thickness:
 $1.08 + 0.02 \text{ mm} = 1.10 \text{ mm}$

Example:

- Clearance measured in Step 5: 1.08 mm
- Machining tolerance etched in the driven gear: (-3)

Corrected driven gear rear cover shim thickness:
 $1.08 - 0.03 \text{ mm} = 1.05 \text{ mm}$




DRIVEN GEAR THRUST SHIM:

Part No.	Thickness
29481-PH8-000	0.50 mm (0.020 in.)
29482-PH8-000	0.85 mm (0.033 in.)
29483-PH8-000	0.90 mm (0.035 in.)
29484-PH8-000	0.95 mm (0.037 in.)
29485-PH8-000	1.00 mm (0.039 in.)
29486-PH8-000	1.05 mm (0.041 in.)
29487-PH8-000	1.10 mm (0.043 in.)
29488-PH8-000	1.15 mm (0.045 in.)
29489-PH8-000	1.20 mm (0.047 in.)
29491-PH8-000	1.25 mm (0.049 in.)
29492-PH8-000	1.30 mm (0.051 in.)



7. To determine the left side cover shim thickness measure the clearance between the transfer L. side cover and transfer case with a feeler gauge, and record the clearance.

NOTE: The clearance should be measured while pressing the L. side cover all the way against the transfer case.




8. The correct shim thickness is determined by recording the clearance between the transfer case and the left side cover, then adding or subtracting the machining tolerance, which is etched into the drive gear.

Example:

- Clearance measured in Step 7: 1.04 mm
 - Machining tolerance etched on drive gear: (+2)
- Corrected transfer thrust shim thickness:
 $1.04 + 0.02 \text{ mm} = 1.06 \text{ mm}$

Example:


- Clearance measured in Step 7: 1.04 mm
 - Machining tolerance etched on drive gear: (-1)
- Corrected transfer thrust shim thickness:
 $1.04 - 0.01 \text{ mm} = 1.03 \text{ mm}$



TRANSFER GEAR THRUST SHIM:

Part No.	Thickness
29461-PS5-000	0.30 mm (0.012 in.)
29462-PS5-000	1.00 mm (0.039 in.)
29463-PS5-000	1.03 mm (0.041 in.)
29464-PS5-000	1.06 mm (0.042 in.)
29465-PS5-000	1.09 mm (0.043 in.)
29466-PS5-000	1.12 mm (0.044 in.)
29467-PS5-000	1.15 mm (0.045 in.)
29468-PS5-000	1.18 mm (0.046 in.)
29469-PS5-000	1.21 mm (0.048 in.)
29471-PS5-000	1.24 mm (0.049 in.)
29472-PS5-000	1.27 mm (0.050 in.)
29473-PS5-000	1.30 mm (0.051 in.)
29474-PS5-000	1.33 mm (0.052 in.)

9. Press the drive gear bearing on the drive gear.




(cont'd)


Transfer

Adjustment/Reassembly (Thrust Shim Selection) (cont'd)

10. Install two 1.75 mm "dummy shim" (P/N 29415-PH8000) on the transfer shaft. Slide the drive gear onto the transfer shaft.



11. Place the shim selected in Step 7 on the L. side cover, and install the cover on the transfer case without bolt.
12. Measure the clearance between the L. side cover and transfer case while pushing against the L. side cover, and record the clearance.



13. Subtract the clearance measured in Step 13 from 3.5 mm (2 dummy shims) to obtain the corrected shim thickness.

Example:

- Clearance measured in Step 13:
1.57 mm
- Thickness of dummy shims:
3.5 mm

Corrected drive gear thrust shim:

3.5-1.57 mm

Thickness: 1.93 mm

DRIVE GEAR THRUST SHIM:

Part No.	Thickness
29411-PH8-000	0.48 mm (0.019 in.)
29412-PH8-000	1.57 mm (0.062 in.)
29413-PH8-000	1.63 mm (0.064 in.)
29414-PH8-000	1.69 mm (0.067 in.)
29415-PH8-000	1.75 mm (0.069 in.)
29416-PH8-000	1.81 mm (0.071 in.)
29417-PH8-000	1.87 mm (0.074 in.)
29418-PH8-000	1.93 mm (0.076 in.)
29419-PH8-000	1.99 mm (0.078 in.)


14. Remove "dummy shim" and install L. side cover.

NOTE: After the thrust shim selection check the proper backlash and tooth contact pattern. See pages 9 — 96 through 9 — 98.




Driven Gear Reassembly


1. Remove the special tool from the transfer rear cover.




2. Install the outer driven gear bearing in the transfer rear cover.




3. Press the oil seal into the transfer rear cover.



4. Coat the main and side sealing lips of the oil seal with grease.




5. Press the inner driven gear bearing on the driven gear.



6. Install the following parts in the transfer rear cover:

- Driven gear
- Transfer spacer (new spacer)
- Companion flange
- Spring washer
- Driven gear locknut

NOTE: Install the spring washer with the dished side toward the companion flange.




(cont'd)

Transfer


Driven Gear Reassembly (cont'd)

7. Temporarily install the driven gear assembly and mounting bolts in the transfer case.



8. To measure preload, tighten the locknut to the specified torque.


Torque: 120 N·m (12 kg-m, 87 lb-ft)



9. Remove the driven gear assembly from the transfer case, and measure the preload.

NOTE: Before measuring the preload, rotate the companion flange several times to assure normal bearing contact.

**Preload: 0.8–1.1 N·m
(8.0–11.0 kg-cm, 6.9–9.5 lb-in)**



NOTE: If the preload exceeds 1.1 N·m (11.0 kg-cm, 9.5 lb-in), replace the transfer spacer with a new one and readjust. Do not try to adjust the preload by loosening the locknut.

10. If the preload is less than 0.5 N·m (5 kg-cm, 4.3 lb-in), adjust by turning the lock nut in a little at a time.

NOTE: Replace the transfer spacer with a new one if the preload is still outside the above limits when the lock nut is tightened to 230 N·m (23 kg-m, 166 lb-ft)




Driven/Drive Gear Reassembly


1. Apply liquid gasket to the torque converter housing mating surface of the transfer case and install the special seal as shown. Use liquid gasket Part No. OY740-99986.

NOTE:

- Check that the mating surface are clean and dry before applying liquid gasket. Degrease the mating surfaces if necessary.
- Apply liquid gasket evenly, being careful to cover all the mating surface.
- To prevent leakage of all, apply liquid gasket to inner threads of bolt holes.
- Do not install the parts 20 minutes or more have elapsed since applying gasket. In that case, reapply liquid gasket after removing the old residue.
- Wait at least 30 minutes before filling with oil.




2. Install the transfer case on the torque converter housing.




3. Install the following parts in and on the transfer case and shaft:

- Transfer thrust shim
- Drive gear (coat with clean oil)
- O-ring (replace)
- Drive gear thrust shim
- L. side cover bolts.



4. Install the following parts:

- Driven gear thrust shim
- Driven gear assembly
- Driven gear assembly bolts



(cont'd)

Transfer


Driven/Drive Gear Reassembly (cont'd)

5. Measure the total bearing preload:
 - Rotate the companion flange several times to assure normal bearing contact.
 - Set the disengagement lever in 2WD position.
 - Measure the preload with a torque wrench.

The total bearing preload should be $0.7 - 1.0 \text{ N}\cdot\text{m}$ ($7.0 - 10.0 \text{ kg}\cdot\text{cm}$, $6.1 - 8.75 \text{ lb}\cdot\text{in}$) greater than the preload on the driven gear assembly alone (see page 9 - 94, step 9).


Example:

If the preload of the driven gear assembly alone was $0.9 \text{ N}\cdot\text{m}$ ($9 \text{ kg}\cdot\text{cm}$, $7.8 \text{ lb}\cdot\text{in}$), the total bearing preload should be between $1.6 \text{ N}\cdot\text{m}$ ($16 \text{ kg}\cdot\text{cm}$, $13.9 \text{ lb}\cdot\text{in}$), and $1.9 \text{ N}\cdot\text{m}$ ($19 \text{ kg}\cdot\text{cm}$, $16.5 \text{ lb}\cdot\text{in}$).




6. If the preload is outside the specifications, adjust it by replacing the transfer thrust shim.
 - If the total bearing preload is less than the specification, reduce the size of the transfer thrust shim.
 - If the total bearing preload is more than the specification, increase the size of the transfer thrust shim.

7. After the bearing preload has been adjusted properly, measure the gear backlash.
 - Place the disengagement lever in 2WD.




- Using a dial indicator, measure the backlash at the top of the companion flange, then rotate the companion flange 180° and measure again.

Backlash: $0.09 - 0.14 \text{ mm}$ ($0.004 - 0.006 \text{ in.}$)






- If the backlash is outside the specifications, adjust by changing the driven gear thrust shim.



8. Check for proper tooth contact after the backlash adjustment has been completed.


- Remove the driven gear assembly from the transfer case, and paint the driven gear teeth evenly with Prussian Blue.
- Reinstall the driven gear assembly in the transfer case and tighten the bolts to the specified torque.
- With the disengagement lever in 2WD, rotate the companion flange one full turn in both directions.



- Remove the driven gear assembly from the transfer case and note the tooth impression on the gear.


NOTE: Compare the tooth impression the gear with the examples below and follow the appropriate adjustment instructions.

Continue the check/adjustment procedure until the tooth contact is correct.




IMPROPER TOOTH CONTACT


TOE CONTACT




FLANK CONTACT



HEEL CONTACT




FACE CONTACT



TOE CONTACT

If the pattern shows toe contact, use a thicker drive gear thrust shim for and increase the thickness of the transfer thrust shim an equal amount.

TOE CONTACT



(cont'd)

Transfer

Driven/Drive Gear Reassembly (cont'd)

TRANSFER
THRUST SHIM

DRIVE GEAR
THRUST SHIM

DRIVEN GEAR
THRUST SHIM

HEEL CONTACT

If the pattern shows heel contact, it indicates too much backlash. To correct, reduce the thickness of the drive gear thrust shim. The thickness of the transfer thrust shim must also be reduced by the amount by which the drive gear thrust shim thickness is reduced.

NOTE: The driven gear thrust shim will have to be changed also to compensate for the change in backlash.

HEEL CONTACT

TRANSFER
THRUST SHIM

DRIVE GEAR
THRUST SHIM

DRIVEN GEAR
THRUST SHIM

FACE CONTACT

To correct face contact, use a thicker driven gear thrust shim to move the driven gear away from the drive gear. The backlash should remain within the limits.

If the backlash cannot be held within the limits (page 9-96), make correction in the same manner as for HEEL CONTACT.

FACE CONTACT



TRANSFER
THRUST SHIM

DRIVE GEAR
THRUST SHIM

DRIVEN GEAR
THRUST SHIM


FLANK CONTACT


If the pattern shows flank contact, move the driven gear in toward the drive gear by using a thinner shim for the driven gear.

The backlash must remain within the limits.

If the backlash exceeds the limits (page 9-96), make correction in the same manner as for TOE CONTACT.

FLANK CONTACT






9. When gear tooth contact is correct, install the new special seal, apply liquid gasket to the mating surfaces of the torque converter and transfer housing. Use liquid gasket part No. OY740-99986.


NOTE:

- Check that the mating surface are clean and dry before applying liquid gasket.
Degrease the mating surfaces if necessary.
- Apply liquid gasket evenly, being careful to cover all the mating surface.
- To prevent leakage of all, apply liquid gasket to inner threads of bolt holes.
- Do not install the parts 20 minutes or more have elapsed since applying gasket.
In that case, reapply liquid gasket after removing the old residue.
- Wait at least 30 minutes before filling with oil.



10. Stake the locknut into the driven gear shaft.

11. Install the thrust shim and O-ring on the driven gear assembly, then install the assembly in the transfer case.



(cont'd)

Transfer



Driven/Drive Gear Reassembly (cont'd)

12. Slide the drive gear thrust shim and drive gear onto the transfer shaft.
13. Place the transfer thrust shim and O-ring (74.5 × 2.5 mm) on the L. side cover and install the cover on the transfer case. Tighten the L. side cover attaching bolts, and then install the L. side cover protector.

NOTE:

- Coat the O-ring with oil.
- Apply liquid gasket (P/N OY740-99986) to threads of L. side cover attaching bolts.

14. Measure the total bearing preload after assembly.



Brakes

The ALB (Anti-Lock Braking)	
System	13 — 2
Differential with Viscous	
Coupling	13 — 8
The Dog Clutch and Its Mechanism	
.....	13 — 10
ALB System	
Function test	13 — 11
Dog Clutch Inspection Using	
ALB Checker	13 — 13
Dog Clutch Inspection Using	
Jumper Wires	13 — 14
Circuit Diagram (4WD)	13 — 15
Relation Between ALB Warning and Rear	
Differential Clutch Warning	13 — 16
Troubleshooting	13 — 17

NOTE : The following abbreviations are used to identify wire colors in this section.

WHT..White	ORNOrange	BLUBlue	GRYGray
YEL ..Yellow	PNKPink	GRN ..Green	LT BLU ..Light Blue
BLK ..Black	BRNBrown	REDRed	LT GRN..Light Green




Outline of Model Changes

- The 4WD × 3 channel ALB system has been adopted



Special Tool

Ref.No	Tool Number	Description	Q'ty	Remarks
①	07HAA-SG00100	ALB T-wrench	1	
②	07HAJ-SG00601	ALB checker	1	
	or			
	07508-SB00000		1	
	-07HAJ-SG00400	Adaptor	1	


The ALB (Anti-Lock Braking) SYSTEM

The Real Time Intrac System

The Real Time INTRAC (INNOVATIVE TRACTION CONTROL) System was developed by combining a three channel digital controlled ALB (Anti-Lock Brake) system with the 4WD system. This ALB system utilizes a pair of split type viscous couplings in the rear differential which ensures improved acceleration, steering and stopping.

< Starting and Acceleration >

On snow or other slippery surfaces the front wheels of a front wheel drive vehicle tend to slip when fast acceleration or start is attempted. A vehicle which has the Real Time INTRAC system incorporated has the assurance that the moment the front wheels begin to slip or spin, the turning power of the engine is transmitted to the rear wheels which ensures positive traction with a minimum of drift or slippage.




< Cruising and Driving at High Speeds >

On dry smooth surfaces the ALB system provides superior maneuverability as characterized by a front wheel drive vehicle. However when the front wheels begin to slip on wet or frozen surfaces the power from the engine is immediately transmitted to the rear wheels. This provides superior control/maneuverability regardless of the road's surface condition.



< On Slopes >

When on an incline the weight distributed to the front wheels is reduced. With the Real Time INTRAC system the corresponding power is transmitted to the rear wheels thereby providing traction for forward movement. On down grades front wheel drive and front wheel weight provide the traction for forward movement.



< Cornering on Slick Surfaces >


Front wheel cornering force is reduced when the front wheel drive vehicle is suddenly accelerated while going through a curved road. This phenomena is known as "under-steer". When this occurs the increased torque of the engine is transmitted to the rear wheels making it easier to negotiate curves. The amount of engine torque applied is dependent upon the accelerator pedal depression. The phenomena "over steer" occurs when a rear wheel drive vehicle is suddenly accelerated while going through a curved track. The Real Time INTRAC system distributes the required driving force to the rear wheels in relationship to the depression of the throttle pedal. This INTRAC system enables stable cornering free from sudden under-steering and/or over-steering.

< Tight Cornering at Low Speeds >


In part time and full time 4WD vehicles the drive trains of the front and rear wheels are connected when the center differential is locked. The locked condition makes it difficult to negotiate tight curves because the wheels are locked to turn at the same speed. In the worst case an engine stall may occur. This can be attributed to the resistance between the wheels/tires and the road surface. In the Real Time INTRAC system the viscous coupling of the rear differential eliminates such problems, and provides excellent controllability when rounding corners at medium and/or high speeds.

< Deceleration and Braking >

When a vehicle's forward speed is reduced through coasting and/or braking the power from the engine is transmitted to the rear wheels just before the wheels lock. This prevents rear wheel lock occurring before the front wheels lock. This procedure ensure a safe and positive controlled stop. This engine braking system is applied to all wheels to slow or stop the vehicle with less stress on the braking system.



< The ALB System Employed for this model >



The ALB (Anti-Lock Braking) SYSTEM




ALB (Anti-Lock Brake)

< Dog Clutch Actuation >

The dog clutch, which is not a component part of the ALB system, is positioned in front of the rear differential gear mechanism to prevent body vibrations peculiar to 4WD vehicles. (For the inner structure, see IV. transmission/differential drawing.) The ALB system is an automatic braking control unit which stabilizes the vehicle's ground travel during sudden braking operations. Prior to wheel lockage to ALB system automatically controls braking hydraulic pressure of each wheel which ensures a proper slip ratio of 10 to 25%. That is, if the wheels are about to lock, the ALB system senses this condition and reduces the braking hydraulic pressure to the front and rear wheels, hence locking is not likely to occur and automatically restores required braking hydraulic pressure. This operation is automatically repeated to prevent the wheels from locking. The ALB system, described above controls front wheel rotation and rear wheel rotation separately. This is accomplished by increased and decreased hydraulic pressure being alternately applied to the front and rear wheel braking systems. The front and rear wheels of a 4WD unit and connected by a propeller shaft. During the increasing/decreasing braking cycle the vibration mode occurs with the vibration being felt by the vehicle operator. Suppression/prevention of these vibrations is accomplished by the automatic input of braking signals to the ALB system. Actuation is automatic with the control unit switching the dog switch on/off via dual relays.

NOTE


The switching circuit and the two solenoids are also compared.




REAL TIME INTRAC OPERATION ON A SPLIT μ ROAD

Driving force and axle revolution on a split μ road.
(Right side : low μ) (Left side : high μ)

The Real Time INTRAC System



A Normal differential gear



The ALB (Anti-Lock Braking) SYSTEM


ALB (Anti-Lock Brake)

< Rear Differential Clutch Warning Lamp >

A rear differential clutch warning lamp is installed in vehicles which have the Real Time INTRAC system.


< Operational Checks During Engine Start >

1. When the ignition switch is placed to the "on" position the ALB warning light and the clutch warning lamps are visible.
2. At a preset time, after engine start, a charging system signal is transmitted to the control unit and the ALB system is activated.
3. In this state, depressing the brake pedal starts the lamp circuit check. If there is a broken wire the clutch warning lamp will not be visible. Therefore, the failure not being in the memory, it is not displayed.
4. When the stop lamp circuit is free of abnormalities the clutch system is diagnosed. When there is an abnormality the clutch warning lamp is displayed (lit) and the failure is memorized by the control unit. Diagnosis is performed by the control unit's stroke switch system and the solenoid system.



During Vehicle Operation

While driving the 4WD/2WD switching circuit of the control unit is being compared with the stroke switch operation. The comparison is performed as the stroke switch is mechanically turned on and off, corresponding with the dog clutch. If the comparison is abnormal then the clutch warning lamp remains illuminated.





NOTE

The switching circuit and the two solenoid terminals are also compared.

ALB (Anti-Lock Brake)

< Speed Sensor >

The speed sensor is of the contactless type which detects the rotational speed of the wheels. It is comprised of a permanent magnet and coil. When the gear pulsators turn the magnetic flux around the coil of the speed sensor alternates and generates voltage with a frequency in proportion to the rotational speed of the wheel. The gear pulsators are attached to the revolving portion of the wheel, (outboard joint of the drive shaft). These pulses are transmitted to the control unit which determines wheel speed.



< Control Unit >


The control unit's primary function is to control the ALB operations. Its secondary function is pump motor control, self diagnosis, etc.

(1) Main Function

By computing the output signals from the speed sensor the control unit operates the solenoid valves in the modulator to control the ALB operation. The Honda ALB system controls the front brakes independently, with the rear brakes being controlled simultaneously. When either of the two wheels turns slower than the other it is given priority to initiate the ALB function. (This method is termed "Low Select".)

(2) Sub Function

The sub function includes pump motor control, self diagnosis, etc., which are necessary to support ALB operational functions.



Differential with Viscous Coupling


CONSTRUCTION

< General >

The Real Time INTRAC system is of the torque split 4WD type with two viscous couplings located in the rear differential. This feature is the most suitable driving force available without switching the from/to front drive to the to/from 4 wheel drive. This is accomplished immediately with power being transmitted to the rear wheels according to driving conditions, road surface, load, etc.

< Construction >

The differential consists of a case (carrier), hypoid drive pinion, hypoid ring gear and a viscous coupling unit affixed to the hypoid ring gear. Additionally it has a built in system for transmitting breaking power by a dog switch and the operation thereof. The viscous coupling unit consists of a case and case plates. The case plates are engaged with the inner bore splines. The Hub Shafts (inner shafts) are serration engaged with the drive shaft. Hub plates are engaged with the hub shaft outer bore splines. In addition the case contains a high viscosity silicon oil. The hub shafts (inner shafts) and the plates are separately arranged on the right and left sides, inside the case. When there is a difference in revolution speed between the case side and the hub side, power is transmitted to the hub shafts (inner shafts) by the shearing force (resistance) of the silicon oil.



Operation

< Differential Mechanism >

Center Viscous Coupling Mechanism

When driving at a constant speed on normal road surfaces the front and rear wheels revolve at the same speed. The same speed is present at the case side and the hub side of the viscous coupling unit. This allows minimum driving force to be transmitted to the rear wheels. When the front wheels cannot transmit the driving force to the road surface, because of surface conditions, a difference in speed is produced between the case side and the hub side. This immediately transmits the driving force to the rear wheels. The driving force transmitting order is; propeller shaft, hypoid ring gear (case), case plates, hub plates, hub shaft (inner) and the drive shaft. This mechanism also permits the vehicle to be free from breaking phenomena when cornering tight corners at low speeds.

Rear Differential Mechanism


When cornering it is necessary to transmit power smoothly to allow for the difference in the speeds of the right and left wheels. The rear differential operational mechanism of the right and left hub shafts (inner shafts) permits smooth cornering characteristics, these are operated independently.

Limited Slip Differential Mechanism


When a 4WD vehicle cannot move because of surface conditions the two built in viscous couplings enable a vehicle with this mechanism to transmit power to the rear wheel which is not slipping. Power can be transmitted to the rear wheel which is not slipping. Power can be transmitted to the right rear wheel and/or the left rear wheel independently. The right/left torque split type viscous coupling minimizes the difference in speed between the right rear and left rear wheels thereby reducing the slip of the wheels of the lower friction factor. This features ensures stability.

This diagram shows the advantage of the limited slip mechanism.

Vehicle with the Real Time INTRAC system




Vehicle without the Limited Slip mechanism



Freedom from breaking phenomena when cornering tight corners at low speeds

The viscous couplings transmits power from the higher revolution side to the lower when there is a great difference in speed between the case and the hub shafts (inner). When the difference in speed is minimal the silicon oil admits the slip, this occurs when cornering a tight corner at low speeds. Difference in wheel speeds, between the front and rear or between right and left, is absorbed without problems.

Absorption of difference in revolutions when cornering a tight corner at low speeds



The Dog Clutch and Its Mechanism

CONSTRUCTION

< General >


The dog clutch is synchronized with the ALB control unit. It is used for switching the from/to 4WD to the to/from 2WD during ALB operations. (For detailed information please refer to chapter V, Chassis) The dog clutch is comprised of a solenoid switch, shift mechanism, hub mechanism and a stroke switch. The solenoid is used to operate the shift mechanism. The stroke switch sends signals indicating the clutch operating condition to the control unit.

< Operations >

1. When the control unit determines the necessity to shift from 4WD to 2WD, it sends the appropriate signal to the solenoid.
2. The solenoid then shifts the shift rod.
3. The shift fork, which is attached to the shift rod, moves the sleeve forward.
4. The action of the sleeve removes the steel balls at the rear from the groove.
5. The sleeve is further moved so that the clutch hub is moved forward to full extent by the steel balls at the front. (This movement continues until the clutch is dis-engaged.)
6. The shift fork pushes the stroke switch which sends a signal to the control unit indicating that the clutch is being dis-engaged.

NOTE

When the control unit elects to restore 4WD operation it stops the current to the solenoid so that the shift fork is pushed back by the spring.



ALB System



Function Test


NOTE:

- The ALB checker is designed to confirm proper operation of the ALB system by simulating each system function and operating condition. Before using the checker, confirm that the dash ALB warning light is not indicating some other problem with the system. The light should go on when the ignition is first turned on and then go off and stay off two seconds after the engine is started.
- The checker should be used through all modes, 1 to 5, to confirm proper operation of the system, in any one of the following situations:
 - After replacing any ALB system component.
 - After replacing or bleeding the system fluid.
 - After any body or suspension repair that may have affected the sensors or their wiring.
 - As part of P.D.I.

⚠ WARNING Disconnect the ALB checker before driving the car. A collision can result from a reduction, or complete loss, of braking ability causing severe personal injury or death.

1. With the ignition switch off, disconnect the 6-P inspection connector from the connector cover under the driver seat and connect the 6-P inspection connector to the ALB checker and adaptor.


ALB CHECKER
07508—SB00000
or
07 HAJ—SG 00601
(Without 07 HAJ—SG 00300)




ALB CHECKER
ADAPTOR
07HAJ—SG00300

NOTE: Place the vehicle on level ground with the wheels blocked, put the transmission in neutral for manual transmission models, and in P for Automatic transmission models.

2. Start the engine and release the parking brake,
3. Operate the ALB checker as follows,
 - (1) Turn the Power Switch ON.
 - (2) Turn the Mode Selector switch to "1."
 - (3) Push the Start Test switch:
 - The Busy light should come ON.
 - The dash ALB warning light should not come ON (If it comes on, follow the troubleshooting on page 13-23)



4. Turn the Mode Selector Switch further to "2".




ALB System

Function Test (cont'd)

5. Depress the brake pedal and push the Start Test switch.

The dash ALB warning light should not go on while the Busy light is ON. There should be kickback on the brake pedal. If not as described, go to troubleshooting, page 13-34.

NOTE: The operation sequence simulated by Modes 2, 3, 4, and 5



6. Turn the Mode Selector switch to 3, 4, and 5.
Perform step 5 for each of the test mode positions.

Mode 1:

Sends the simulated driving signal 0 km/h (0 mph) → 180 km/h (112.5 mph) → 0 km/h (0 mph) of each wheel to the control unit to check the control unit self diagnosis circuit. There should be NO kickback.

Mode 2:

Sends the driving signal of each wheel, then sends the lock signal of the rear left wheel to the control unit. There should be kickback.

Mode 3:

Sends the driving signal of each wheel, then sends the lock signal of the rear right wheel to the control unit. There should be kickback.

Mode 4:

Sends the driving signal of each wheel, then sends the lock signal of the front left wheel to the control unit. There should be kickback.

Mode 5:

Sends the driving signal of each wheel, then sends the lock signal of the front right wheel to the control unit. There should be kickback.

NOTE: If little or no kickback is felt from the brake pedal in modes 2-5, repeat the function test of modes 1-5 several times before beginning to troubleshoot other parts of the system.

Inspection points:

1. The ALB warning light goes ON in mode 1.
 - Check the wiring. If there is good condition, the control unit is faulty.
 - If ALB warning light goes on 120 seconds later but the power unit stops, refer to page 13 — 32.
2. There are no kickback in modes 2 through 5.
 - Faulty pressure switch (remains ON)
 - Shorted wires
 - Faulty or disconnected power unit coupler
 - Faulty power unit relay
3. Weak kickback in modes 2 through 5.
 - Bleed high pressure circuits.
4. Power unit stops in mode 1 but it does not stop and there are no kickback in modes 2 through 5.
 - Brake fluid leakage
 - Bleed power unit
 - Clogged power unit outlet
 - Clogged or deteriorated power unit hose


Dog Clutch Inspection Using ALB Checker

Use the ALB checker to inspect ALB operation.


1. Check that there are no problems or abnormalities with operation of the rear differential clutch warning light following O'wners Manual instructions.
2. Switch off the engine.
3. Block the front wheels, raise the rear of the car and support on safety stands.
4. Set the gear shift lever to neutral.
5. Short-circuit the stop switch terminals.

NOTE: Although it is acceptable for another mechanic to step on the brake pedal instead of performing the above, pressing down to hard on the pedal may make it impossible to check the rotation of the rear wheels mentioned below.

6. With the ignition switch off, disconnect the 6-P inspection connector from the connector cover under the driver seat and connect the 6-P connector to the ALB checker and adaptor.




7. Start the engine and release the parking brake.
8. Turn the checker Power switch on.
9. Turn the mode selector Switch to 4 or 5.
10. Push the Start test switch.



11. Check that the rear wheels can be rotated by hand while sound actuation of the solenoid is heard (kickback is taking place).
If the wheels cannot be rotated, follow the instructions for troubleshooting.

WARNING Disconnect the ALB checker before driving the vehicle. A collision can result from reduction or complete loss of braking function causing personal injury or death.

CAUTION: Raise the rear wheels, and support it with properly positioned safety stands.




ALB System

Dog Clutch Inspection Using Jumper Wires


CAUTION : In order to protect the solenoids inside the rear differential from damage do not keep the ignition switch on for more than 5 minutes and do not keep the red/yellow wire (pulling solenoid) and black wire connected for more than 5 seconds.

1. With the ignition switch off, disconnect the 4-P inspection connector (PNK) from the connector cover under the driver's seat, and connect the RED/GREEN wire (holging solenoid) and BLK wire using jumper wire, and connect the circuit tester Voltage tester) to the BLU/GRN wire (Stroke switch (+) and BLK wire (-).




View from wire harness side

2. Block the front wheels, raise the rear wheels and support it on safety stands.
3. Confirm that the selector bolt of the rear differential is set to 4WD.




4. Turn the ignition switch on.
5. Confirm that the circuit tester indicates the battery voltage.
 - If it is OV, check the strock switch.
6. Use the different jumper wire to connect the RED/YEL wire (pulling solenoid) and BLK wire for and instant (less than 5 second).




View from wire harness side

7. Confirm that the circuit tester indicates OV and that the rear wheels can be rotated by hand.
 - If the rear wheels cannot be rotated, check for an open in the rerated wire harness or solenoid valve.
 - If the rear wheels can be rotated but the tester does not indicate OV, check the stroke switch.

CAUTION : Raise the rear wheels, and support it with property positiond safety stands.



Circuit Diagram (4 WD)



Relation Between ALB Warning and Rear Differential Clutch Warning

In the table which follows, "clutch" refer to the "rear differential clutch."

CAUTION :

- If there is no indication otherwise in the Troubleshooting Flowchart, turn ignition switch off.
- Measurement of the internal impedance of the control unit should be performed with the ignition switch turned off and within 5 seconds.

Diagnosis of malfunction	Action as soon as malfunction is detected	Follow-up action
ALB system: Normal Clutch system: Defective	<ul style="list-style-type: none"> • Clutch warning light:lit • Turn clutch relay off (switch to 4WD). • Note problem code. 	<ul style="list-style-type: none"> • Stop clutch control and clutch diagnostics. • Continue ALB control operation normally with 4WD mode.
ALB system: Defective during 4WD mode Clutch system: Normal	<ul style="list-style-type: none"> • ALB warning light:lit • Turn failsafe relay off. • Note problem code 	<ul style="list-style-type: none"> • Stop ALB control. • Stop clutch control and clutch diagnostics.
ALB system: Defective during ALB operation in 2WD mode Clutch system: Normal	<ul style="list-style-type: none"> • ALB warning light:lit • Turn failsafe relay off. 	<ul style="list-style-type: none"> • Stop ALB control. • Maintain 2WD mode until conditions permit switching from 2WD to 4WD mode. • Once conditions permit,switch from 2WD to 4WD mode and stop clutch control and clutch diagnostics.
ALB system: Defective during ALB operation in 2WD mode ↓ Clutch system: Defective during 2WD mode	<ul style="list-style-type: none"> • ALB warning light:lit • Turn failsafe relay off • Note problem code (ALB system). ↓ <ul style="list-style-type: none"> • Clutch warning light:lit • Turn clutch relay off (switch to 4WD). • Note problem code (clutch system). 	<ul style="list-style-type: none"> • Stop ALB control. ↓ <ul style="list-style-type: none"> • Stop clutch control and clutch diagnostics.
Clutch system: Defective ALB system: Defective during 2WD mode	<ul style="list-style-type: none"> • Clutch warning light:lit • Turn clutch relay off (switch to 4WD). • Note problem code. ↓ <ul style="list-style-type: none"> • ALB warning light:lit • Turn failsafe relay off. • Note problem code. 	<ul style="list-style-type: none"> • Stop clutch control and clutch diagnostics. • Continue ALB control operation normally with 4WD mode. ↓ <ul style="list-style-type: none"> • Stop ALB control.

Troubleshooting

ALB Warning Light


Temporary Driving Conditions:

1. The ALB warning light will come on and the control unit memorizes the problem under certain conditions.

NOTE: Problem codes explained on pages 13-24 and 13-25.

- The tire(s) adhesion is lost due to excessive cornering speed.
Problem codes: 4-4, 4-8, 4-12.
- The vehicle loses traction when starting from a stuck condition on a muddy, snowy, or sandy road.
Problem code: 5.
- When the parking brake is applied for more than 30 seconds while the vehicle is being driven.
Problem code: 2.
- The vehicle is driven on extremely rough road.

The ALB system is OK, if the ALB warning light goes off after the engine is restarted.



2. If you receive a customer's report that the ALB warning light sometimes comes on, check the System using the ALB checker to confirm whether there is any trouble in the system.
See page 13 - 11.
3. The ALB warning light will come on and the LED (see page 13 — 23) will display a problem code when there is insufficient battery voltage to the control unit. An example would be when the battery is so weak that the car must be Jump-started.
After the battery is sufficiently recharged, the ALB warning light will work normally after the engine is stopped and restarted.

However, after recharging the battery, the LED problem code must be cleared from the control unit's memory by disconnecting the ALB B2 fuse (15A) for at least 3 seconds.

Warning Light Circuit:

1. The ALB warning light does not go on when the ignition switch is turned on.
Check the following items. If they are OK, check the control unit connectors.
If not loose or disconnected, install a known-good control unit and recheck:
 - Blown warning bulb.
 - Open circuit in YEL lead between No. 1 fuse (10A) and combination meter.
 - Open circuit BLU/RED lead between combination meter and control unit.
 - Loose component grounding of the control unit to the body.
2. The ALB warning light remains ON or after the engine is started, however the LED on the control unit does not blink any code or sub-code, check for the following:
 - Loose or poor connection of the wire harness at the control unit.
 - Faulty ALB B2 fuse (15A).
 - Open circuit in WHT lead between ALB B2 fuse (15A) and control unit.
 - Short circuit in BLU/RED lead between combination meter and control unit.
 - Open circuit in WHT/BLU lead between alternator and control unit (CHG14).

If the problem is not found substitute a known-good control unit and recheck whether the warning light remains ON.


Troubleshooting

Rear Differential Clutch Warning Light


1. The rear differential clutch (below : "clutch") warning light does not light even when the ignition switch is turned on.

NOTE :

The clutch warning light is supposed to light when the ignition switch is turned on to check the bulb.



View from wire harness side



From clutch warning light.

2. The rear differential clutch (below : "clutch") warning light remains on even when the brake pedal is pressed after the engine is started.


After the engine is started and a set period of time has elapsed, the clutch can be tested by starting the ALB control unit (below : control unit)

The clutch warning light comes on when the ignition switch is turned on, before engine starts.

When the brake pedal is depressed to change the input voltage to HI, the control unit tests the monitor and stroke switch circuits. If there is no HI input voltage, the clutch warning light remains on (no problem code is stored in the memory) and the next test is not carried out.

Immediately after the engine starts, as no signal to switch from 4WD to 2WD is being output, the relay does not operate and the monitor system is normally at LO level. If the relay closes, battery voltage is applied to the monitor terminal, causing it to switch to HI level and the clutch warning light remains on (the problem code is stored in the memory). Also, it switches to HI level if there is an open circuit between the solenoid ground and the monitor terminal.

The stroke switch is on during 4WD operation, and HI level signal is present at the terminal. If there is an open circuit between the stroke switch and the control unit, the clutch warning light remains on (the problem code is stored in the memory). The stroke switch is operated mechanically by the clutch mechanism. Therefore, if the solenoid turns on when the relay is closed (2WD), the switch turns off and the clutch warning light remains on (no problem code is stored in the memory).





Troubleshooting

Rear Differential Clutch Warning Light (cont'd)




These tests are divided into three categories, depending on the problem code displayed.

- (1) No problem code
- (2) Problem codes 1 — 2, 1 — 4 and 1 — 6
- (3) Problem code 1 — 1

- (1) No problem code



(2) Problem codes 1 — 2, 1 — 4 and 1 — 6



Troubleshooting

Rear Differential Clutch Warning Light (cont'd)

(3) Problem code 1 — 1

Disconnect the 2P coupler from the stroke switch.

Check the stroke switch.

Is it OK ?

NO

Faulty stroke switch

YES

Measure the resistance between wire harness terminal A and body ground.

* By measuring the internal impedance of the control unit, one can check for an open circuit.
The reference value for a normal unit is 1 k Ω (use a digital multimeter).

Is there continuity ?

NO

< ∞ >
Open circuit between stroke switch and control unit.

YES

Turn the ignition switch on.

Measure the voltage between terminal B (positive) and body ground.



Is there battery voltage ?

NO

Open circuit in GRN/BLK (one portion is not colored) wire between stroke switch and control unit.


YES

Faulty control unit.



Comes On And Remains On While Running

1. Stop the engine.
2. Turn the ignition switch on and make sure that the ALB warning light comes on.
3. Restart the engine and check the ALB warning light.
 - There is no problem in the ALB system, if the ALB warning light goes off.
 - Go to step 4, if the ALB warning light remains on.
4. Stop the engine.
5. Remove the inspection hole lid on the right of the front console.
6. Turn the ignition switch on, but do not start the engine.
7. Record the blinking frequency of the LED on the control unit. The blinking frequency indicates the problem code.































NOTE:

- The control unit can indicate three problem codes (one, two or three problems).
- If the LED does not light, see Troubleshooting of Warning Light Circuit page 13-28, except alternator signal (WHT/BLU).
- If you miscount the blinking frequency, turn the ignition switch off, then turn on to blink the LED again.
- The LED lights faintly after starting the engine as the control unit uses the LED circuit to intercommunicate between its internal computers.
- After the repair is completed, disconnect the ALB B2 fuse for at least 3 seconds to erase the control unit's memory. Then turn the ignition key on again and recheck.
- The memory is erased if the connector is disconnected from the control unit or the control unit is removed from the body.

Troubleshooting

Symptom-to-System Chart

PROBLEM CODE		PROBLEMATIC COMPONENT/ SYSTEM	AFFECTED				See page	OTHER COMPONENT	See page
MAIN CODE	SUB CODE		FRONT RIGHT	FRONT LEFT	REAR RIGHT	REAR LEFT			
	—	Hydraulic Controlled Component	—	—	—	—	13 — 26	-ALB MAIN fuse -Motor relay -Pressure Switch -Accumulator -Modulator	13 — 29
	—	Parking brake switch-related problem	—	—	—	—	13-35	Brake fluid level switch BRAKE light	
		Front fail safe relay	—	—	—	—	13 — 38 (Function Test)		
		Rear fail safe relay	—	—	—	—			
		Pulser (s)	○				—		
				○					
					○	○			
		Speed sensor(s)			○		13 — 35	Modulator	
						○			
					○	○			
 or  or 		Speed sensor	○				13 — 35		
				○					
					○				
						○			
		Front solenoid related problem (Open)	IN				13 — 37		
			OUT					Front R speed sensor	13 — 36
			BOTH						
				IN					
				OUT				Front L speed sensor	13-37
				BOTH					
		Front fail safe relay	BOTH	BOTH			13 — 38	Solenoids misconnected	

PROBLEM CODE		PROBLEMATIC COMPONENT/ SYSTEM	AFFECTED			See page	OTHER COMPONENT	See page
MAIN CODE	SUB CODE		FRONT RIGHT	FRONT LEFT	REAR			
<div>9</div>	—	Solenoid related problem (Open)			IN	13 — 40	Rear speed sensors	13 — 36
<div>10</div>	—				OUT			
<div>11</div>	—				BOTH	13 — 41	Rear fail safe relay	13 — 38
<div>11</div>	<div>3</div>		BOTH		BOTH	—		
	<div>12</div>			BOTH	BOTH			
	<div>15</div>		BOTH	BOTH	BOTH			
<div>12</div>	<div>1</div>	Solenoid related problem (Short)	IN			13 — 43		
	<div>2</div>		OUT					
	<div>3</div>		BOTH			13 — 44	ALB B3 fuse	
	<div>4</div>	Power supply problem		IN		13 — 43		
	<div>8</div>			OUT				
	<div>12</div>			BOTH		13 — 45	ALB B1 fuse	
	<div>15</div>		BOTH	BOTH		—	ALB B3 and/or ALB B1 fuse(s)	
<div>13</div>	—	Solenoid related problem (Short)			IN	13 — 46		
<div>14</div>	—				OUT			
<div>15</div>	—				BOTH		ALB B3 fuse	
<div>15</div>	<div>3</div>		BOTH		BOTH			
	<div>12</div>			BOTH	BOTH		ALB B1 fuse	
			LED stays ON:		BOTH		BOTH	

NOTE: The control unit can display a number of sub-codes other than those listed. Such sub-codes indicate unlikely combinations of multiple component failures, or more likely, a problem in a wire or connector common to a group of components. To troubleshoot, refer to the procedures for other sub-codes with the same main code.

Troubleshooting

Flowchart



Problem Code 1: Hydraulic Controlled Components.

NOTE: The LED does not blink when the following failures occur.



- The contact points of the motor relay remain closed (The motor runs continuously even after the ignition key is removed).
- YEL/RED lead is shorted or the control unit is internally shorted (The motor stops when the ignition switch is turned off).

Pre test steps:


- Check No. 40 Fuse.
- Check all brake system hoses and pipes (low and high pressure) for signs of leaking, bending or kinking.
- Check reservoir fluid level, and if necessary, fill to the MAX level.



(From page 13-26)



View from wire side.



View from terminal side.

CAUTION: If the motor runs disconnect the jumper wire immediately.

(cont'd)

Troubleshooting

Flowchart (cont'd)

(From page 13-33)

Does the pump motor run with an increasingly loud, raspy sound? NO

Pump runs with a constant soft sound:
Bleed air from ALB system using ALB checker and bleeder T-wrench (see page 13-35) and check the pump sound again.

YES

Does the pump motor stop after about 60 seconds? NO

Pump stops about 120 seconds: faulty pressure switch (open).


YES

Does the reservoir fluid level go down, and are there no bubbles in the modulator reservoir tank? NO

- If level stays the same and there are bubbles in the modulator reservoir tank, check the accumulator fluid quantity by bleeding the high pressure line with the ALB T-wrench:
 - If over 160 cc (upper limit). faulty accumulator
 - If over 115 cc : 4 mm below upper line (LOWER LIMIT) Modulator inlet solenoid leak or accumulator leak.
- If level goes up: faulty modulator assembly.

YES

System is OK; recheck pump motor, to confirm no intermittent problem.



NOTE: The fluid enters the reservoir under pressure; wait 1 or 2 minutes for air bubbles to disappear and level to stabilize.

(From page 13-27)

Measure voltage between the WHT/RED terminal (+) and body ground (-).

Is there battery voltage?

NO

Repair open in WHT/RED wire between the fuse and pump motor relay.

YES

Measure voltage between the WHT/BLU terminal (+) of the pump motor and body ground (-).


Is there battery voltage?

NO

Repair open in WHT/BLU wire between motor relay and pump motor, or open in BLK wire between pump motor and ground or poor ground

YES

Replace the pump motor.



View from terminal side.



View from terminal side.

Air Bleeding with ALB checker

NOTE : Do not depress the brake pedal while using the ALB checker to bleed air from the system.

1. Fill the modulator reservoir with brake fluid up to the MAX level.
2. Disconnect the 6P coupler (PNK) from the cover mounted in under the driver seat and connect it to the ALB checker.

CAUTION : Place the car on level ground with the wheels blocked. Shift the transmission to P or Neutral.

3. Start the engine.
4. Release the parking brake.
5. Turn the power switch of ALB checker on.
6. Turn the mode selector switch to 1.
7. Press the start switch.
8. Make sure that the motor runs.
9. Wait for the motor to stop.
10. Turn the mode switch to 2.

11. Press the start switch.

12. Brake fluid in the reservoir will bubble briskly for 20 seconds after the switch is pressed. Wait for 4 to 5 minutes until the brake fluid stops bubbling.

13. Turn the mode switch to 6.

14. Repeat steps 11 and 12.

15. Repeat steps 10 through 14 two or three times.

16. Fill the reservoir with brake fluid up to the MAX level.

17. Install the cap.

18. Check the ALB function in all modes (page 13 — 11). There should be kickback in modes 2 through 6.

CAUTION : If the kickback is weak, re-bleed air from the system.

Troubleshooting


Flowchart (cont'd)

When vehicle is running, the rear differential clutch (below : "clutch") warning light comes on and remains on.


When the car is running, the output circuit is constantly being compared with the monitor system and stroke switch system. If an abnormality is detected, the clutch warning light comes on and a problem code is stored in memory.


Reasons for warning during 4WD operation.

- Stuck relay or break in connection between solenoid and monitor terminal.
- Bad connection in stroke switch system or mechanical failure in the clutch. Reasons for warning during 2WD operation :
- Open circuit between holding solenoid and monitor terminal.
- Stuck pulling solenoid or open circuit between pulling solenoid and monitor (pulling circuit operates only in the split second when switching from 4WD to 2WD operation. 4WD operation then commences immediately.)
- Stuck stroke switch or clutch mechanical connection.



Problem codes : 1 — 2 (holding), 1 — 4 (pulling) and 1 — 6 (both)





Troubleshooting

Flowchart (cont'd)

(From page 13-31)

Turn ignition switch off.

Disconnect the 4P coupler from the solenoid.

Check solenoid.

Check for continuity between the BLK terminal of the wire harness and the body ground.

Is there continuity ?

NO

Open circuit in wire.

Faulty ground.

YES

Disconnect the 13P coupler from the control unit.

Check for continuity in the BLU/BLK wire between the holding relay and the control unit.

Is there continuity ?

NO

Open circuit in wire.

YES

Check for an open circuit between the RED/GRN terminal of the holding relay coupler and the body ground.

Is there open circuit ?

NO

< 0 Ω

There is short circuit between the holding relay and the control unit.

YES

Check for continuity in the RED/GRN wire between the holding relay and the control unit.

Is there continuity ?

NO

Open circuit in wire.

YES

Check for continuity in the BLU/RED, BLU/ORN wire between the pulling and the control unit.



Is there continuity ?

NO


Open circuit in wire.

YES

(To page 13-33)



Pulling (PNK)



(From page 13-32)

Check for an open circuit between the RED/YEL terminal of the coupler for the pulling relay and the body ground.

Is there open circuit ?

NO

<0Ω>

There is short circuit in the RED/YEL wire between the pulling relay and the control unit.

YES

Check for continuity in the RED/YEL wire between the pulling relay and the control unit.

Is there continuity ?

NO

Open circuit in wire.

YES

Check for continuity in the BLU/BLK wire between the solenoid and the control unit.

Is there continuity ?

NO

Open circuit in wire.

YES

Check for continuity in the BLU/RED wire between the solenoid and the control unit.

Is there continuity ?

NO


Open circuit in wire.

YES

Faulty control unit.

Pulling (PNK)


To control unit



View from terminal side

To holding solenoid (monitor)


View from wire side



From pulling relay

To pulling solenoid (monitor)

To pulling solenoid



To holding solenoid

View from wire side

Troubleshooting

Flowchart (cont'd)

Problem code : 1 — 1 (stroke switch system)

Disconnect the 2 P coupler from the stroke switch and the wire harness.

Check the stroke switch.

Is it OK ?

NO

Faulty stroke switch.

YES

Measure resistance between wire harness terminal A and the body ground.

* By measuring the internal impedance of the control unit, one can check for an open circuit.
The reference value for a normal unit is 1 k Ω (use a digital multimeter).

Is there continuity ?

NO

< ∞ >
Open circuit between stroke switch and control unit.

YES

Turn ignition switch on.

Measure voltage between wire harness B terminal (+) and body ground.

Is there battery voltage ?


NO

Open circuit in BLK/YEL (one portion is not colored) wire between No.18 fuse and stroke switch.


YES

Faulty control unit.

View from terminal side




From stroke switch



View from wire side

From fuse No. 18



View from terminal side

Problem code2: Parking Brake Switch Related Problem



If the parking brake has been released, the following items are possible causes. If they are OK, check the control unit connectors for good connection. If not loose or disconnected, substitute a known-good control unit and recheck.

NOTE : Before Troubleshooting Problem Code 2, remove the ALB 2 fuse for three seconds to clear the control unit's memory, then test drive the car.

If the ALB warning light and LED stay off, the probability is that the car was driving with the parking brake applied.

- The parking brake is applied for more than 30 seconds while driving.
- The brake fluid level in the master cylinder is too low.
- GRN/RED lead is shorted between the **BRAKE** warning light and parking brake switch.
- GRN/RED lead is shorted between the **BRAKE** warning light and brake fluid level switch.
- The **BRAKE** warning light is blown.
- GRN/RED has an open between the **BRAKE** warning light and parking brake.
- GRN/RED has an open between the parking brake switch and control unit.

Problem code 4-4 to 4-12: Rear Speed Sensor



(To page 13-36)

Troubleshooting

Flowchart (cont'd)

(From page 13-35)

Connect ALB checker to inspection connector.

Check ALB function in MODE 2 and 3.


Does it work properly?

NO

Faulty the modulator.

YES

Faulty the control unit.



BLU/YEL : Rear Right sensor \ominus

GRN/YEL : Rear Right sensor \oplus

GRY : Rear Left sensor \ominus
View from wire side.

LT BLU : Rear Left sensor \oplus

Problem Code 5-1 to 7-8: Speed Sensor

Disconnect wire harness from speed sensor.

Check for resistance between sensor terminals.

Is there 1,000-1,500 Ω ?

NO

Faulty the speed sensor.

YES


Disconnect the 21P connector from the control unit.

Check the each wires for continuity between the sensor and control unit:


GRN/BLK: Front Right Positive
GRN/BLU: Front Left Positive
GRN/YEL: Rear Right Positive
LT BLU: Rear Left Positive
GRN: Front Right Negative
BRN: Front Left Negative
BLU/YEL: Rear Right Negative
GRY: Rear Left Negative

(To page 13-37)


FRONT RIGHT




FRONT LEFT



REAR RIGHT



REAR LEFT




BRN : FL \ominus

GRN : FR \ominus

GRN/BLU : FL \oplus

GRN/BLK : FR \oplus




BLU/YEL : RR \ominus

GRY : RL \ominus

GRN/YEL : RR \oplus


LT BLU : RL \oplus

View from wire side.



Problem Code 8-1 to 8-12: Front Solenoid Related Problem

NOTE: Problem Code 8-2 or 8-8, also perform troubleshooting of Problem Code 5-1 to 7-8 (page 13-36).



Troubleshooting

Flowchart (cont'd)

(From page 13-37)

Is there continuity?

NO

Repair open in wire:
RED/BLK: Front Right Inlet
YEL/BLK: Front Right Outlet
RED/BLU: Front Left Inlet
YEL/BLU: Front Left Outlet

YES

Faulty the control unit.

Problem 8-15: Front Fail Safe Relay Circuit

Remove front fail safe relay.

Check relay function.

* Check for continuity between terminals ③ and ④. There should be no continuity. Connect a 12 V battery across terminals ① and ②. There should be continuity between terminals ③ and ④.

Does it work properly?

NO

Faulty the front fail safe relay.

YES

Check for continuity between BLK lead and body ground.

Is there continuity?

NO

Repair open in BLK wire between the fail safe relay and ground or poor ground

YES

Turn ignition switch ON.

Check for voltage between BLK/YEL lead (+) and body ground (-).

Is battery voltage available?

NO

Repair open in BLK/YEL wire between the fail safe relay and 18(10 A) fuse.




YES

Turn ignition switch OFF.


Disconnect the 3P connectors from the front solenoids.

Check for continuity in BRN/BLK lead between fail safe relay and solenoids.


(To page 13-39)




View from terminal side.




BRN/BLK: to FAIL SAFE RELAY



BRN/BLK: to FAIL SAFE RELAY



View from terminal side.



Troubleshooting


Flowchart (cont'd)

Problem Code 9 or 10: Rear Solenoid Related Problem

NOTE: Problem Code 10, also perform troubleshooting of Problem Code 5-1 to 7-8 (page 13-36).

Disconnect wire harness from rear solenoid.

Check for resistance between RED and BLK terminals of rear solenoid.



View from terminal side.

Is there 1-3 Ω ? **NO** Faulty solenoid.

YES


Check for resistance between YEL and BLK terminals of rear solenoid.

Is there 1-3 Ω ? **NO** Faulty solenoid.

YES

Disconnect the 21P connector from the control unit.


Check for continuity between control unit and rear solenoid:
RED/WHT: Rear Inlet
YEL/WHT: Rear Outlet



View from wire side.

RED/WHT: from REAR IN SOL.

YEL/WHT: from REAR OUT SOL.



View from wire side.


Is there continuity? **NO** Repair open in the wire between the rear solenoid and control unit
RED/WHT: Rear Inlet
YEL/WHT: Rear Outlet

YES

Faulty the control unit.

Problem Code 11: Rear Fail Safe Relay Circuit

NOTE: Also perform Troubleshooting of Problem Code 9 or 10 (page 13-40).



Troubleshooting

Flowchart (cont'd)

(From page 13-41)

Disconnect the 21P connector from the control unit.

Check for continuity in YEL/GRN lead between fail safe relay and control unit.

Is there continuity?

NO
Repair open in YEL/GRN wire between the relay and control unit.

YES

Check for continuity between control unit and rear solenoid.
RED/WHT: Rear Inlet
YEL/WHT: Rear Outlet


Is there continuity:

NO
Repair open in wire between the solenoid and control unit.
RED/WHT: Rear Inlet
YEL/WHT: Rear Outlet

YES

Faulty the control unit.


PINK CONNECTOR



YEL/GRN:
to CONTROL UNIT

View from terminal side.

YEL/WHT:
to REAR
OUT SOL.




RED/WHT:
to REAR
IN SOL.

View from terminal side.

RED/WHT: from REAR IN SOL.






YEL/WHT: from REAR OUT SOL.



YEL/GRN:
from FAIL SAFE RELAY

View from wire side.



Problem Code 12-1, 12-2, 12-4 or 12-8: Front Solenoid



Troubleshooting


Flowchart (cont'd)

Problem Code 12-3: Front Right Solenoid and/or Power Supply






View from terminal side.

View from wire side.



Problem Code 12-12: Front left Solenoid and/or Power Supply Problem



Troubleshooting

Flowchart (cont'd)

Problem Code 13 or 14: Rear Solenoid Related Problem

Disconnect wire harness from rear solenoid.

Check for resistance between RED and BLK terminals of rear solenoid.

Is there 1—3 Ω ?

NO

Faulty solenoid.

YES

Check for resistance between YEL and BLK terminals of rear solenoid.

Is there 1—3 Ω ?

NO

Faulty solenoid.

YES

Disconnect the 21P connector from the control unit.

Check for continuity between wire harness and body ground.
RED/WHT: Rear Inlet
YEL/WHT: Rear Outlet


Is there continuity?

YES


Repair short in wire between the solenoid and control unit.
RED/WHT: Rear Inlet
YEL/WHT: Rear Outlet

NO

Faulty the control unit.




View from Terminal side.



View from wire side.


The ALB warning light comes on while vehicle is running, but the problem code could not be read from memory by following the prescribed procedure.



Troubleshooting

Flowchart (cont'd)

The rear differential clutch warning light comes on while vehicle is running, but the problem code could not be read from memory by following the prescribed procedure.



* By measuring the internal impedance of the control unit, one can check for a short circuit.

The reference value for a normal unit is open or 300 kΩ (use a digital multimeter, value differs depending on polarity).

Body

Dashboard..... 14 — 2



Outline of Model change

The instrument panel has been changed.


Dashboard

Instrument Panel Replacement


4D :

INSTRUMENT PANEL

Remove the 4 screws, carefully pull out the instrument panel and disconnect the connectors.



3/5D :



Heater and Air Conditioner

Air Conditioner15 — 1

Outline of Model Changes

- The pressure plate of the compressor has been changed.
- “Sanden” compressor has been adopted for some types.



Air Conditioner

Special Tools	15 — 2
Illustrated Index	15 — 3
Wire Harness Routing	15 — 4
Service Tips	15 — 5

Compressor

Description	15 — 6
Troubleshooting	15 — 8

MATSUSHITA :

Replacement	15 — 9
Clutch Inspection	15 — 12
Clutch Overhaul	15 — 13
Thermal Protector Inspection....	15 — 15
Thermal Protector Replacement	15 — 15
Shaft Seal Replacement	15 — 16

SANDEN :

Replacement	15 — 18
Thermal Protector Inspection....	15 — 20
Thermal Protector Replacement	15 — 20
Clutch Inspection	15 — 22
Clutch Overhaul	15 — 23
Shaft Seal Replacement	15 — 26
Shaft Bearing Replacement	15 — 28


System Charging

System Evacuation	15 — 30
Leak Test	15 — 31
Charging Procedure	15 — 32
Supplement	15 — 33




Special Tools


Ref. No.	Tool Number	Description	Q'ty	Page Reference
①	07HAF-SF10300	SEAL SEAT REMOVER	1	15-16
②	07HAF-SF10400	SEAL REMOVER/INSTALLER	1	15-16
③	07925-6920001	A/C CLUTCH HOLDER	1	15-23, 26
④	07935-805003	FLY WHEEL PULLER	1	15-23
⑤	07JAC-SH20100	A/C PULLEY PULLER	1	15-24
⑥	07JAC-SH20300	SHAFT RING REMOVER	1	15-25, 28
⑦	07965-6340100	BEARING DRIVER	1	15-28
⑧	07947-6340500	DRIVER ATTACHMENT	1	15-29




①




②




③




④



⑤



⑥



⑦



⑧

Air Conditioner

Illustrated Index



〈LHD〉

A/C HIGH SIDE ADAPTER

The A/C high side charging fitting's O.D. size is reduced from 7/16" to 3/8" to prevent you from accidentally connecting the low side hose to the high side fitting. Consequently, you'll need an adapter for the existing hose on your charging station.

DUAL PRESSURE SWITCH

When the refrigerant pressure is below 215 kPa (33 psi) due to refrigerant leakage or above 2350 kPa (340 psi) due to the coolant blockage the dual pressure switch opens the circuit to the A/C control unit and stops the air conditioner to protect the compressor.

EVAPORATOR

As refrigerant circulates, heat is absorbed from the surrounding passenger compartment air.

SIGHT GLASS

CONDENSER

Dissipates the heat which was absorbed by the refrigerant.

RECEIVER AND FILTER/DRYER


Serves as a reservoir which filters and removes moisture from the refrigerant.

COMPRESSOR

Compresses the refrigerant and then forces it through the condenser.

There are two types:


1. **MATSUSHITA**, Replacement, page 15-9
2. **SANDEN**, Replacement, page 15-18



Air Conditioner

Wire Harness Routing

(LHD)



Air Conditioner

Service Tips



CAUTION:

1. Always disconnect the negative cable from the battery whenever replacing air conditioner parts.
2. Keep moisture and dust out of the system. When disconnecting any lines, plug or cap the fittings immediately; don't remove the caps or plugs until just before the lines are reconnected.
3. Before connecting any hose or line, apply a few drops of refrigerant oil to the seat of the O-ring or flare nut.
4. When tightening or loosening a fitting, use a second wrench to support the matching fitting.
5. When discharging the system, don't let refrigerant escape too fast; it will draw the compressor oil out of the system.

6. Add refrigerant oil after replacing the following parts:

Condenser	10 cc (1/3 fl oz)
Evaporator	30 cc (1 fl oz)
Line or hose	10 cc (1/3 fl oz)
Receiver	10 cc (1/3 fl oz)
Compressor	


On compressor replacement, subtract the volume of oil drained from the removed compressor from 130cc (4.4 fl oz) or 120 cc (4 fl oz), and drain the calculated volume of oil from the new compressor:

130 cc (4.4 fl oz) — Volume of removed compressor = Draining volume (Matsushita)

120 cc (4 fl oz) — Volume of removed compressor = Draining volume (Sanden)

7. Torque specifications

① Suction hose evaporator side	32 N·m (3.2 kg-m, 23 lb-ft)
② Receiver pipe C evaporator side	17 N·m (1.7 kg-m, 12 lb-ft)
③ Receiver pipe C to Receiver pipe B	17 N·m (1.7 kg-m, 12 lb-ft)
④ Receiver pipe B to Receiver pipe A	17 N·m (1.7 kg-m, 12 lb-ft)
⑤ Condenser pipe to Condenser	17 N·m (1.7 kg-m, 12 lb-ft)
⑥ Discharge hose to Condenser	22 N·m (2.2 kg-m, 16 lb-ft)
⑦ Compressor hose mounting bolts	30 N·m (3.0 kg-m, 22 lb-ft)
⑧ Receiver tank	17 N·m (1.7 kg-m, 12 lb-ft)
⑨ Compressor bracket mounting bolts	48 N·m (4.8 kg-m, 35 lb-ft)
⑩ Compressor mounting bolts	25 N·m (2.5 kg-m, 18 lb-ft)



⚠ WARNING


When handling refrigerant (R-12):

- Always wear eye protection.
- Do not let refrigerant get on your skin or in your eyes. If it does:
 - Do not rub your eyes or skin.
 - Splash large quantities of cool water in your eyes or on your skin.
 - Rush to a physician or hospital for immediate treatment. Do not attempt to treat it yourself.
- Keep refrigerant containers (cans of R-12) stored below 40°C (100°F).
- Do not handle or discharge refrigerant in an enclosed area near an open flame; it may ignite and produce a poisonous gas.
- The ozone is a fragile layer surrounding the earth which acts as a shield against the sun's ultraviolet radiation. Chlorine from chemicals called Chlorofluorocarbons (CFCs) destroy the ozone in the stratosphere. Automotive air conditioning systems currently use Chlorofluorocarbons as the refrigerant. Auto air conditioning service equipment has been developed to minimize the release of CFCs to the atmosphere. All service procedures should be performed using this equipment and the manufactures instructions.


Compressor

Description (Matsushita)

This compressor is a three-vane, rotary type and consists of three vanes that come out of the rotor to the cylinder wall, reed valve that prevents backflow, and magnetic clutch. A thermal protector is installed on this compressor.




Compressor



Description (Sanden)

This compressor is the spiral type. Refrigerant is compressed between a fixed spiral assembly and an orbiting spiral assembly. A thermal protector is installed on this compressor.




Compressor

Troubleshooting


NOTE: Performance Test on page 22-50.

TEST RESULTS	RELATED SYMPTOMS	PROBABLE CAUSE	REMEDY
Discharge (high) pressure abnormally high	After stopping compressor, pressure drops to about 196 kPa (28 psi) quickly, and then falls gradually	Air in system	Evacuate system; then re-charge Evacuation: page 15–30 Recharging: 15–32
	No bubbles in sight glass when condenser is cooled by water	Excessive refrigerant in system	Discharge refrigerant as required
	Reduced or no air flow through condenser.	<ul style="list-style-type: none"> • Clogged condenser or radiator fins • Condenser or radiator fan not working properly 	<ul style="list-style-type: none"> • Clean • Check voltage and fan rpm
	Line to condenser is excessively hot	Restricted flow of refrigerant in system	Expansion valve
Discharge pressure abnormally low	Excessive bubbles in sight glass; condenser is not hot	Insufficient refrigerant in system	<ul style="list-style-type: none"> • Charge system • Check for leak
	High and low pressures are balanced soon after stopping compressor	<ul style="list-style-type: none"> • Faulty compressor discharge or inlet valve • Faulty compressor seal 	Replace compressor
	Outlet of expansion valve is not frosted, low pressure gauge indicates vacuum	<ul style="list-style-type: none"> • Faulty expansion valve 	Repair or Replace
Suction (low) pressure abnormally low	Excessive bubbles in sight glass; condenser is not hot Expansion valve is not frosted and low pressure line is not cold. Low pressure gauge indicates vacuum.	Insufficient refrigerant <ul style="list-style-type: none"> • Frozen expansion valve • Faulty expansion valve 	Check for leaks. Charge as required. Replace expansion valve
	Discharge temperature is low and the air flow from vents is restricted	Frozen evaporator	Run the fan with compressor off then check the thermostat and capillary tube.
	Expansion valve frosted	Clogged expansion valve	Clean or Replace
	Receiver dryer is cool (should be warm during operation)	Clogged receiver dryer	Replace
Suction pressure abnormally high	Low pressure hose and check joint are cooler than around evaporator	<ul style="list-style-type: none"> • Expansion valve open too long • Loose expansion valve 	Repair or Replace
	Suction pressure is lowered when condenser is cooled by water	Excessive refrigerant in system	Discharge refrigerant as necessary
	High and low pressure are equalized as soon as the compressor is stopped	<ul style="list-style-type: none"> • Faulty gasket • Faulty high pressure valve • Foreign particle stuck in high pressure valve 	Replace compressor
Suction and discharge pressures abnormally high	Reduced air flow through condenser	<ul style="list-style-type: none"> • Clogged condenser or radiator fins • Condenser or radiator fan not working properly 	<ul style="list-style-type: none"> • Clean condenser and radiator • Check voltage and fan rpm
	No bubbles in sight glass when condenser is cooled by water	Excessive refrigerant in system	Discharge refrigerant as necessary.
Suction and discharge pressure abnormally low	Low pressure hose and metal end areas are cooler than evaporator	Clogged or kinked low pressure hose parts	Repair or Replace
	Temperature around expansion valve is too low compared with that around receiver—driver.	Clogged high pressure line	Repair or Replace
Refrigerant leaks	Compressor clutch is dirty	Compressor shaft seal leaking	Replace compressor shaft seal
	Compressor bolt(s) are dirty	Leaking around bolt(s)	Replace compressor
	Compressor gasket is wet with oil	Gasket leaking	Replace compressor



Replacement (Matsushita)


1. If the compressor is marginally operable, run the engine at idle speed and turn on the air conditioner fan a few minutes, then shut the engine off and disconnect the battery negative terminal.
2. Discharge the refrigerant very slowly from the system
3. Remove the mounting bolts (2) the power steering pump belt, and the power steering pump.




4. Disconnect the suction and discharge hoses from the compressor.

CAUTION:


Cap the open fittings immediately to keep moisture and dirt out of the system.



5. Disconnect the compressor connector and the clamp.



6. Loosen the adjusting bolt and lock nut, then remove the compressor belt.




(cont'd)

Compressor (Matsushita)

Replacement (cont'd)


7. Remove the compressor mounting bolts (4) and compressor. Rest the compressor on the front beam.



COMPRESSOR MOUNTING BOLTS
25 N·m (2.5 kg-m , 18 lb-ft)

8. Remove the mounting bolts (4) and compressor bracket with idle pulley.

ALL TORQUE:
48 N·m (4.8 kg-m , 35 lb-ft)



9. Remove the compressor.

10. Install in the reverse order of removal and:


- If a new compressor is installed, calculate the amount of refrigerant to be drained through the suction fitting on the compressor:
150 cc (5 fl oz.) minus contents of old compressor, equals amount to drain from new compressor.
- Adjust the compressor belt and the power steering belt.

NOTE:

Measure the deflection when 98 N (10 kg, 22 lb) force is applied between the pulleys.

Compressor belt Adjustment.
9—11 mm (0.4—0.4 in)

When new belt is installed:
7—9 mm (0.3—0.4 in)




- Charge the system.
- Test the performance.



11. Power steering belt adjustment.
9—12 mm (0.4—0.5 in)

When new belt is installed:
7—10 mm (0.3—0.4 in)




Compressor (Matsushita)

Clutch Inspection

- Check pulley bearing play and drag by rotating the pulley by hand. Replace the pulley with a new one if it is noisy or has excessive play/drag.


ROTOR PULLEY



- Check resistance of the field coil:

Field Coil Resistance:
 3.33 ± 0.17 ohm at 20°C (68°F)


If resistance is not within specifications, replace the coil.



- Measure the clearance between the pulley and pressure plate. If the clearance is not within specified limits, the pressure plate must be removed and shims added or removed as required.

CLEARANCE: 0.4—0.6 mm (0.016 — 0.02 in)

CREARANCE=A(CLUTCH OFF)—B(CLUTCH ON)




NOTE:

The shims are available in two sizes: 0.2 mm and 0.5 mm of thickness.




Clutch Overhaul


1. Remove the center bolt and washers.




2. Remove the pressure plate and shim(s) taking care not to lose the shims.



3. Use circlip pliers to remove the circlip.




4. Remove the pulley from the shaft using a 2 or 3 jaw puller.
5. Check the pulley, replace the assembly if the pulley is damaged or deformed.



Compressor (Matsushita)

Clutch Overhaul (cont'd)


6. Disconnect the field coil connector and remove the screws (3) and field coil.




7. Install in the reverse order of removal and:

- Install the field coil with the wire side facing up (see above).
- Clean the pulley and compressor sliding surfaces with non-petroleum solvent.
- Check the pulley bearings for excessive play.

- Make sure the circlip is fitted to the groove properly.



- Apply locking agent to the thread of the center bolt and tighten it securely.
- Make sure that the pulley turns smoothly.






Thermal Protector Inspection

Check for continuity between the 1 and 3 terminals of the compressor connector.


There should be continuity.

- If no continuity, replace the thermal protector.



Thermal Protector Replacement


1. Remove the pressure plate and field coil (page 22-29).
2. Pull the rubber cap out from the thermal protector.
3. Remove the screws and wire clips.
4. Remove the circlip and thermal protector.



5. Install in the reverse order of removal.

NOTE:

- Replace the O-rings with new ones.
- Set the new O-rings in place as shown.



Compressor (Matsushita)

Shaft Seal Replacement

NOTE:


Make sure that the suction and discharge joints are plugged with the caps.

1. Remove the pressure plate.

NOTE:

Removal of the clutch pulley and coil is not necessary.

2. Remove the felt seal and circlip.




3. Remove the shim(s).


NOTE:

After removing, place shim(s) safely in a parts rack.

4. Insert the special tool into the compressor aligning the cutout of the remover with the groove of the seal seat.
5. Rotate the special tool counterclockwise to make sure that the cutout is engaged with the seal seat.
6. Pull out the seal seat.



7. Insert the special tool into the compressor aligning the cutout of the remover with the metal pawl of the seal case.
8. Rotate the special tool counter clock wise to make sure that the cutout is engaged with the metal pawl.



9. Withdraw the remover.
10. Lay down the compressor and clean the shaft seal contacting face of the compressor with cleaning solvent.

CAUTION:

- Keep the cleaning solvent and dirt out of the compressor.
- Do not use any cloth for cleaning, clean only by rinsing with solvent.
- Do not spill the refrigerant oil from the compressor. Refill the same amount of the oil if the oil is spilled out.

11. Clean the new shaft seal thoroughly with cleaning solvent.
12. Lubricate the shaft seal with refrigerant oil (SUNISO 5GS or equivalent) and install it on the shaft seal remover.

NOTE:


- Use only clean refrigerant oil.
- Do not touch the sealing surfaces of the shaft seal after lubricating.



13. Liberally lubricate the compressor shaft with refrigerant oil.

14. Install the shaft seal onto the compressor shaft aligning the seal case flats with the shaft flats.

**SEAL REMOVER/INSTALLER
(07 HAF-SF 10400)**



15. Clean the seal seat with cleaning solvent, then lubricate the seal seat with refrigerant oil (SUNISO 5GS or equivalent).

NOTE:

- Use only clean refrigerant oil.
- Do not touch the sealing surface of the seal plate after lubricated.

16. First slide the seal seat into the compressor by hand as far as possible.

17. Press the seal seat with the grip side of the remover.

18. Install the circlip with its chamfered edge inside.

19. Press the circlip with the grip side of the remover, then install the felt seal.


20. Install the shim(s).

21. Install the pressure plate. Measure the clearance between the pulley and pressure plate all the way around. If the clearance is not within the specified limits, [0.4 – 0.6mm (0.016 – 0.02 in)] shims must be added or removed as required.

Compressor (Sanden)

Replacement

1. If the compressor is marginally operable, run the engine at idle speed and turn on the air conditioner fan a few minutes, then shut the engine off and disconnect the battery negative terminal.
2. Discharge the refrigerant very slowly from the system
3. Remove the two mounting bolts, the power steering pump belt, and the power steering pump.




4. Disconnect the suction and discharge hoses from the compressor.


CAUTION:

Cap the open fittings immediately to keep moisture and dirt out of the system.


30 N·m (3.0 kg-m, 22 lb-ft)



5. Disconnect the compressor connector and the clamp.




6. Loosen the lock nut and adjusting bolt, then remove the compressor belt.



(cont'd)




7. Remove the four compressor mounting bolts and compressor. Rest the compressor on the front beam.



MOUNTING BOLTS

25 N·m (2.5 kg-m , 18 lb-ft)

8. Remove the four mounting bolts and compressor bracket with idle pulley.



MOUNTING BOLTS

48 N·m (4.8 kg-m , 35 lb-ft)

9. Remove the compressor.

10. Install in the reverse order of removal and:


- If a new compressor is installed, calculate the refrigerant oil as below and drain through the suction fitting on the compressor:
120 cc (4 fl oz) minus contents of old compressor, equals amount to drain from new compressor.
- Adjust the belt
- Charge the system
- Test the performance

Compressor (Sanden)

Thermal Protector Inspection


Check for continuity between A and B terminals of the thermal protector connector. There should be continuity.

- If no continuity, replace the thermal protector.




Thermal Protector Replacement

1. Remove the bolt, pressure plate and the wire clip.




2. Disconnect the thermal protector and field coil connector, then remove the thermal protector.

THERMAL PROTECTOR







3. Remove the old silicon sealant from the cup of thermal protector.



4. Lubricate the new thermal protector with silicon sealant, then install the thermal protector into compressor.



5. Connect the thermal protector wire, then install the wire with the pressure plate and the wire clip.




- Make sure that the thermal protector has continuity.

Compressor (Sanden)

Clutch Inspection

- Check pulley bearing play and drag by rotating the pulley by hand. Replace the pulley with a new one if it is noisy or has excessive play or drag.




- Check resistance of the field coil:

Field Coil Resistance:


3.58 ± 0.15 ohm at 20°C (68°F)

If resistance is not within specifications, replace the coil.




- Measure the clearance between the rotor pulley and armature plate all the way around. If the clearance is not within specified limits, the pressure plate must be removed and shims added or removed as required.


CLEARANCE: 0.35—0.65 mm (0.014—0.026 in)



NOTE:


The shims are available in four sizes: 0.1 mm, 0.2 mm, 0.4 mm and 0.5 mm of thickness.






Clutch Overhaul


1. Use an A/C clutch holder to assist removing the center bolt.




2. Remove the armature plate. (If you can't by hand, use a puller.)



3. Remove the two shims, taking care not to lose them.



4. Use snap ring pliers to remove the snap ring.




(cont'd)


Compressor (Sanden)

Clutch Overhaul (cont'd)


5. Remove the clutch rotor using the special tool.



6. Remove the screw and disconnect the wire.




7. Remove the snap ring B using snap ring pliers and remove the field coil.






★Installation

8. Fit the lug of field coil on the slot of front boss.




9. Install the snap ring B and wire.




10. Press rotor pulley onto field coil with shaft ring remover.

CAUTION:
Maximum press load: 1.5 tons.




11. Secure the rotor pulley with the snap ring.



Compressor (Sanden)

Clutch Overhaul (cont'd)


12. Set the armature plate onto rotor pulley with shims(2).



13. Use A/C clutch holder to secure armature plate while tightening bolt.

12 N·m (1.2 kg·m, 9 lb·ft)

A/C CLUTCH HOLDER
07925-6920001




Make sure that the rotor pulley turns smoothly.

Shaft Seal Replacement


NOTE:

Make sure that the suction and discharge joints are plugged with the caps.

1. Remove the armature, rotor pulley and field coil, then remove the four bolts.




2. Remove the front boss and O-ring.






3. Remove the shaft seal.



4. Remove the felt ring and seal plate from the front boss.




5. Clean the new shaft seal thoroughly with cleaning solvent.
6. Lubricate the shaft seal with refrigerant oil (SUNISO 5GS)

NOTE:

- Use only clean refrigerant oil.
- Do not touch the sealing surfaces of the shaft seal after Lubricating.
- Liberally lubricate the compressor shaft with refrigerant oil.

7. Install the shaft seal onto the compressor shaft aligning the seal case flats with the shaft flats.




Compressor (Sanden)

Shaft Seal Replacement (cont'd)

8. Install the felt ring and seal plate into the front boss.


NOTE:

- Clean the seal with cleaning solvent, then lubricate the seal seat with refrigerant oil (SUNISO 5GS).
- Use only clean refrigerant oil.
- Do not touch the sealing surface of the seal plate after lubricated.



9. Set the O-ring into the front end plate and install the front boss with 4 bolts.


14 N·m (1.4 kg-m, 10 lb-ft)




10. Install the field coil.

Shaft Bearing Replacement

1. Remove armature plate, rotor pulley and field coil.
2. Remove front boss, seal plate and felt ring.
3. Set the front boss onto shaft ring remover.



4. Use Bearing Driver with a hydraulic press to remove the bearing.






5. Install the shaft seal, seal plate and felt ring.
6. Install the front boss onto compressor.
7. Install the bearing using the driver attachment and a hydraulic press. Center the tool on the bearing before pressing. Recheck tool centering as soon as the press first contacts the attachment.

CAUTION:

Maximum press load: 0.4 tons.



8. Install the field coil, rotor pulley and armature plate.

System Charging

System Evacuation

The following are the procedures to be adhered to when servicing air conditioners to reduce the amount of Freon R-12 into the atmosphere.


1. When an A/C System has been opened to the atmosphere, such as during installation or repair, it must be evacuated using a vacuum pump. (If the system has been open for several days, the receiver/dryer should be replaced).
2. Connect a gauge, pump and refrigerant containers (cans of R-12) as shown.
NOTE: Do not open the cans.
3. Start the pump, then open the both pressure valves, both pressure stop valves and evacuation valve (2 valve gauge: evacuation stop valve). Run the pump about 15 minutes. Close the both pressure valves

and evacuation valve (2 valve gauge: evacuation stop valve) and stop the pump. The low gauge should indicate above 700 mmHg (27 in-Hg) and remain steady with the valves closed.


NOTE: If low pressure does not reach more than 700 mmHg (27 in-Hg) in 15 minutes, there is probably a leak in the system. Check for leaks, and repair (see Leak Test).


4. If there are no leaks open the valves and continue pumping for at least another 15 minutes, then close both valves, stop the pump.

3 VALVE GAUGE



2 VALVE GAUGE





Leak Test

The following are the procedures to be adhered to when servicing air conditioners to reduce the amount of R-12 into the atmosphere.

▲ WARNING

When handling refrigerant (R-12):


- Always wear eye protection.
- Do not let refrigerant get on your skin or in your eyes. If it does:
 - Do not rub your eyes or skin.
 - Splash large quantities of cool water in your eyes or on your skin.
 - Rush to a physician or hospital for immediate ment. Do not attempt to treat it yourself.
- Keep refrigerant containers (cans of R-12) stored below 40°C (100°F).
- Keep away from open flame. Refrigerant, although non-flammable, will produce poisonous gas if burned.
- Work in well-ventilated area. Refrigerant evaporates quickly, and can force all the air out of a small, enclosed area.

NOTE: Check for leaks after evacuation.


1. Close the evacuation valve (2 valve gauge; evacuation stop valve).

2. Open the cans.
3. Open high pressure valve to charge the system to about 100 kpa (14 psi), then close the supply valve. NOTE: Particularly check for leaks around the compressor, condenser, and receiver-driver.
5. If you find any leaks, tighten the joint nuts and to the specified torque.
6. Recheck the system for leaks using a leak detector.
7. If you find leaks that require the system to be opened (to repair or replace hoses, fittings, etc.), release any charge in the system.
8. After checking and repairing leaks, the system must be evacuated (see System Evacuation on page 15-81).

3 VALVE GAUGE



2 VALVE GAUGE



System Charging

Charging Procedures

The following are the procedures to be adhered to when servicing air conditioners to reduce the amount of from R-12 into the atmosphere.

▲WARNING When handling refrigerant (R-12):

- Always wear eye protection.
- Donot let refrigerant get on your skin or in your eyes. If it does:
 - Do not rub your eyes or skin.
 - Splash large quantities of cool water in your eyes or on your skin.
 - Rush to a physician or hospital for immediate ment. Do not attempt to treat it yourself.
- Keep refrigerant containers (cans of R-12) stored below 40°C (100°F).
- Keep away from open flame. Refrigerant, although non-flammable, will produce poisonous gas if burned.
- Work in well-ventilated area. Refrigerant evaporates quickly, and can force all the air out of a small, enclosed area.

CAUTION: Do not overcharge the system; the compressor will be damaged.


1. After leak test, check that the high pressure valve is closed and start the engine.
NOTE: Run the engine balow 1500 rpm.

2. Open the front door.
Turn the A/C switch on.
Turn the air mix dial (lever) to COOL.
Turn the function control switch (lever) on
Turn the heater fan switch on "E" (MAX).
3. Open the low pressure valve and charge with ant.


▲WARNING

- Do not open the high gauge valve.
 - Do not turn the cans upside down.
4. Charge the system with refrigerant capacity.
Refrigerant capacity: 900 ± 50 g (32 ± 2 oz)
 5. When fully charged, close the low pressure valve and the refrigerant cans. Check the system.
 6. Close the high pressure stop valve.
 7. Open the low pressure valve and gradually open the high pressure valve. When both pressure gauge are the same, close the low pressure stop valve and stop the engine.
 8. Disconnect the charge hose quickly.
 9. Check the system for leaks using a leak detector.
NOTE: Particularly check for leaks around the compressor, condenser, and receiver-dryer.

3 VALVE GAUGE




2 VALVE GAUGE



System Charging

Supplement



The following are the procedures to be adhered to when servicing air conditioners to reduce the amount of from R-12 into the atmosphere.

▲ WARNING When handling refrigerant (R-12):

- Always wear eye protection.
- Do not let refrigerant get on your skin or in your eyes. If it does:
 - Do not rub your eyes or skin.
 - Splash large quantities of cool water in your eyes or on your skin.
 - Rush to a physician or hospital for immediate ment. Do not attempt to treat it yourself.
- Keep refrigerant containers (cans of R-12) stored below 40°C (100°F).
- Keep away from open flame. Refrigerant, although non-flammable, will produce poisonous gas if burned.
- Work in well-ventilated area. Refrigerant evaporates quickly, and can force all the air out of a small, enclosed area.

CAUTION: Do not overcharge the system; the compressor will be damaged.

1. Connect the gauge as shown, close both pressure stop valves. Purge air from the charge hose A, then loosen the stop valve connector.
2. Attach a pump and refrigerant containers (can: 250 g x 2) as shown.
- NOTE: Do not open cans.
3. Open both pressure valves and evacuation valve (2 valve gauge: evacuation stop valve), start the pump. The low gauge should indicate above 700 mmHg (27 in-Hg), then run the pump about 1 minute.

4. Close both pressure valves and evacuation valve (2 valve gauge: evacuation stop valve). Open both pressure stop valve.
5. Start the engine and turn on A/C switch.
6. Stop the engine and check for leaks using a leak detector.

NOTE: Particularly check for leaks around the compressor, condenser, and receiver-dryer.

7. Test the system using the pressure test and inspection data.

Test condition:

- Start the engine.
- Turn the air mix dial (lever) to COOL.
- Turn the function control switch (lever) on
- Turn the recirculation control switch on
- Turn the heater fan switch on "E" (MAX).


If there is insufficient refrigerant in system, continue to charge system.

8. Open one or two cans, open the low pressure gauge. Charge the system until there are no bubbles in the sight glass.


▲ WARNING

- Do not open the high gauge valve.
 - Do not turn the cans upside down.
9. After adding supplemental refrigerant, close the pressure stop valve. Open the low pressure valve and gradually open the high pressure valve. When pressure gauge read same, close the low pressure stop valve and stop the engine.
 10. Disconnect the charge hose quickly.
 11. Check the system for leaks using a leak detector.

3 VALVE GAUGE



2 VALVE GAUGE



Electrical

Fuses

Main Fuse Box	16 — 2
ALB Fuse Box.....	16 — 3
Dash Fuse Box	16 — 4
Power Distribution	16 — 8
Ground Distribution	16 — 15

Gauge Assembly

Gauge / Indicator Location Index ..	16 — 22
Circuit Diagram	16 — 24

Shift Lever Position Indicator System

Component Location Index.....	16 — 32
Circuit Diagram	16 — 34

Lighting System

Circuit Diagram	16 — 40
Rear Fog Light	16 — 45

Dashlight Brightness Control System

Component Location Index.....	16 — 46
Circuit Diagram	16 — 46

Turn Signal / Hazard Flasher System

Component Location Index.....	16 — 49
Circuit Diagram	16 — 50

Rear Window Defogger

Component Location Index.....	16 — 53
Circuit Diagram	16 — 54

Headlight Adjuster

Circuit Diagram	16 — 58
-----------------------	---------

Outline of Model Changes


- The lighting, turn signal / hazard flasher, rear fog light and rear window defogger systems have been modified.
- The gauge assembly has been changed.
- The shift lever position indicator system has been adopted.
- The dashlight brightness control system has been modified to KQ model only.



Fuses


Main Fuse Box

NOTE: Main fuse box is located right side, engine compartment.





ALB Fuse Box





ALB CLUTCH MAIN (30 A)
ALB CLUTCH SUB (7.5 A)
ALB CLUTCH MONITER (7.5 A) } With 4 WD-ALB only


Fuses

Dash Fuse Box (LHD)

NOTE: Dash fuse box is located left side, under dash.




- No.19(30 A)FUSE : Blower motor
- No.20(20 A)FUSE : Front passengers bower window
- No.21(20 A)FUSE : Drivers power window
- No.22(20 A)FUSE : Right rear power window
- No.23(20 A)FUSE : Left rear power window
- No.24(15 A)FUSE : Seat heaters-KS, KW(Finland, Norway)models
- No.25(15 A)FUSE : Dower door lock-KS, KW(Finland, Norway)models
- No.26(15 A)FUSE : Radiator fan-4 WD-AT(Electronic control)



Fuses


Dash Fuse Box (RHD)

NOTE: Dash fuse box is located right side, under dash.




- * : SPAER FUSE
- : Not used
- < > : KE model only
- < > : With power door lock



- No. 19(30 A) FUSE : Blower motor
- No. 20(20 A) FUSE : Driver's power window
- No. 21(20 A) FUSE : Front passenger's power window
- No. 22(20 A) FUSE : R. Rear power window
- No. 23(20 A) FUSE : L. Rear power window



Power Distribution

Circuit Identification






Power Distribution

Circuit Identification (cont'd)


Except European model :

No.33(40A) FUSE
From page 16-8






KG,KF,KB and KW (Except Finland,Norway)models :



Power Distribution

Circuit Identification (cont'd)


With Daytime Running Light :






With Dim-Dip Headlight :

No.33(60A) FUSE
From page 16-8




Power Distribution

Circuit Identification (cont'd)



Ground Distribution

Circuit Identification




- A : Battery ground wire
- B : Engine ground wire
- C : Engine wire harness
- D : Main wire harness

Ground Distribution

Circuit Identification (cont'd)

RHD :



※ : Carbureted engine

[C] : Engine wire harness

[D] : Main wire harness

[E] : Front Passenger's door wire harness


[F] : Roof wire

[G] : Dashboard wire harness

[J] : Rear wire harness



RHD :



※ : Carbureted engine


[D] : Main wire harness

[H] : Driver's door wire harness

Ground Distribution

Circuit Identification (cont'd)


LHD :



- ※ : Carbureted engine
- [C] : Engine wire harness
- [D] : Main wire harness




LHD :





- ※ : Carbureted engine
 [D] : Main wire harness
 [F] : Roof wires
 [G] : Dashboard wire harness
 [H] : Driver's door wire harness

Ground Distribution



- | | | |
|-----------------------------------|--------------------------------------|---------------------------------|
| I : A/C wire harness | L : Right seat heater wires | O : Hatch wires |
| J : Rear wire harness | M : Fuel tank wires | Q : Rear fog light wires |
| K : Left seat heater wires | N : License plate light wires | |




J : Rear wire harness	M : Fuel tank wires	P : Rear defogger sub cord
K : Left seat heater wires	N : License plate light wires	
L : Right seat heater wires	G : Dashboard wire harness	

Gauge Assembly

Gauge / Indicator Location Index (With Tachometer)


- Gauge Assembly
- Removal, page 16-30
- Disassembly, page 16-28







— (With Tachometer)

- Gauge Assembly
Removal, page 16-30
Disassembly, page 16-29




Circuit Diagram






Gauge Assembly

Bulb Locations (With Tachometer)






Gauge Assembly

Disassembly (With Tachometer)

NOTE :

- Handle the terminals and printed circuits carefully to avoid damaging them.
- Gauge assembly manufactured by Nippon Seiki is show below.






(Without Tachometer)

NOTE :

- Handle the terminals and printed circuits carefully to avoid damaging them.
- Gauge assembly manufactured by Nippon Seiki is shown below.




Gauge Assembly


Removal

1. Remove the dashboard lower panel.
2. Remove the 4 screws, then remove the instrument panel from the dashboard.


4D :




2D H/B and 5D :



3. Remove the caps and 2 screws, then remove the gauge visor from the dashboard (4D only).




4. Remove the 4 screws, then remove the gauge assembly half-way and disconnect the speedometer cable and connectors.






Speed Pulser Test

1. Remove the gauge assembly from the dashboard, then turn it over.
2. Break the lead off a pencil tip then insert the pencil into the speedometer cable connector socket and turn it. Connect an ohmmeter between the A and B terminals. There should be continuity 4 times between the A and B terminals per revolution.



Shift Lever Position Indicator

Component Location Index





Discription

S₄ Indicator :

The "S₄" indicator light will remain on for about 2 seconds after the ignition switch has been turned on to show that the system circuit is functioning.


The shift lever position indicator is dimmed by the dimming circuit with the lighting switch on.

In the "S₄" mode, which can be selected by the "S₄" switch, the A/T control unit applies voltage to the "D 10" terminal of the shift lever position indicator to light up the "S₄" indicator.

The "S₄" indicator also functions as the warning indicator for the A/T control system. If some malfunction occurs in the A/T control system, the A/T control unit applies voltage to the "D 10" terminal of the shift lever position indicator to make the "S₄" indicator flash. The flashing "S₄" indicator informs the driver of some malfunction in the A/T control system. When the "S₄" indicator functions as the warning indicator, the A/T control unit sends a cancelling signal to the "D 12" terminal of the shift lever position indicator so that the "S₄" indicator light is not dimmed.


Shift Lever Position Indicator

Circuit Diagram (AT Electronic Control Type)



Shift Lever Position Indicator



(Expect AT Electronic Control Type)



Shift Lever Position Indicator

Indicator Input Test

Remove the gauge assembly from the dashboard and disconnect the 14-P connector from the indicator.
Make the following input tests at the harness pins.
If all tests prove OK, yet the indicator still fails to work, replace the indicator assembly.



View from wire side



No.	Wire	Test condition	Test:desired result	Possible cause(if result is not obtained)
1	BLK	Under all conditions.	Check for continuity to ground: should be continuity.	<ul style="list-style-type: none"> • Poor ground(G201,G401). • An open in the wire.
2	YEL	Ignition switch ON.	Check for voltage to ground: should be battery voltage.	<ul style="list-style-type: none"> • Blown NO.1(10A)fuse. • An open in the wire.
3	GRN/WHT	Shift lever position in P.	Check for continuity to ground:should be continuity.	<ul style="list-style-type: none"> • Faulty shift position console switch. • Poor ground(G511 or G561) • An open in the wire.
	GRN/RED	Shift lever position in R.		
	GRN ²	Shift lever position in N.		
	GRN/BLK	Shift lever position in D ₄ or D		
	GRN/BLU	Shift lever position in D ₃ or S		
	GRN/YEL	Shift lever position in 2.		
4	RED/BLK	Lighting switch ON.	Check for voltage to ground: should be battery voltage.	<ul style="list-style-type: none"> • Faulty Lighting switch. • An open in the wire.
* ¹ 5	RED/BLK and RED ₁	Lighting switch ON and dashlight brightness control dial on full bright.	Check for voltage between RED/BLK and RED ₁ terminals: should be battery voltage.	<ul style="list-style-type: none"> • Faulty dashlight brightness control system. • An open in the wire.
6	GRN ¹	Ignition switch ON.	Check for voltage to ground: should be about 5V.	<ul style="list-style-type: none"> • Faulty PGM-FI system. • An open in the wire.
* ² 7	YEL/RED	Ignition switch ON, shift lever position in S and S ₄ switch ON.	Check for voltage to ground: should be about 5V.	<ul style="list-style-type: none"> • Faulty S₄ switch. • Faulty AT control system. • An open in the wire.
* ² 8	RED/YEL	Ignition switch ON, shift lever position 2 and LOW switch ON.	Check for voltage to ground: should be battery voltage.	<ul style="list-style-type: none"> • Faulty LOW switch. • Faulty AT control system.


*¹ KQ model only

*² 4WD-AT only

Shift Lever Position Indicator

Console switch test

1. Remove the center console, then disconnect the 10-P and 2-P connectors from the console switch.
2. Check for continuity between the terminals in each switch position according to the tables.



Shift Position Console switch

Back up
Light Switch


Neutral
Safety Switch

Terminal Position	7	8	9	10	5	4	6	2	3	11	12
2	○	○									
D ₃ or S	○		○								
D ₄ or D	○			○							
N	○				○					○	○
R	○					○		○	○		
P	○						○			○	○



Shift Position Console Switch Replacement

1. Remove the console, then disconnect the 10-P and 2-P connectors from the console switch.
2. Remove the 2 console switch mounting bolts.




3. Position the switch slider to "Neutral" as shown above.
4. Shift the select lever to "Neutral", then slip the console switch into position.
5. Attach the switch with the 2 bolts.
6. Test the console switch with P and N position of shift lever (see page 16-38).

NOTE: The engine should start when the shift lever is in the N position in the range of free play.

7. Connect the 10-P and 2-P connectors, clamp the harness and install the console.

Lighting System


Circuit Diagram (KQ, KT, KT and KP models)



() : RHD




(KG, KF, KB, KW and KX models)



Lighting System

Circuit Diagram (With Daytime Light)






Lighting System


Lighting/Turn Signal Switch Test

1. Remove the column covers.
2. Disconnect the 7-P and 4-P connectors from the switch.
3. Check for continuity between the terminals in each switch position according to the tables.

LHD:



RHD:



Lighting/Dimmer/Passing Switch

Terminal		D	E	F	G	I	J
Position							
Lighting switch	OFF						
	⌘	○	○				
	⌘				○	○	
Dimmer switch *	LOW			○		○	
	HIGH					○	○
Passing switch	OFF						
	ON					○	○

*: With lighting switch position in (⌘)

Turn Signal Switch

Terminal		A	B	C
Position				
LHD:	R	○		○
	NEUTRAL			
	L	○	○	
RHD:	R	○	○	
	NEUTRAL			
	L	○		○




Rear Fog Light Switch Removal


1. Remove the caps, then remove the 4 screws from the instrument panel (2 DH/B, 5 D).
2. Remove the 4 screws from the instrument panel (4 D).
3. Remove the instrument panel from the dashboard.
4. Disconnect the 10-P connector from the switch.
5. Remove the switch from the instrument panel.

NOTE : LHD type shown, RHD type similar.


2 DHB 5 D :



4 D :






6. Turn the socket 45° counter clock wise sockets to remove it.



Rear Fog Light Switch Test


1. Remove the switch from the instrument panel.
2. Check for continuity between the terminals according to the table.

Terminal	A	B	C	D	E
Position					
ON	○	○	○	○	○
OFF					




Dashlight Brightness Control (KQ model only)

Component Location Index



Circuit Diagram







Control Unit Input Test

Remove the center console and disconnect the 6-P connector from the control unit.

Make the following input tests at the harness pins. If all tests prove OK, yet the dash lights still cannot be controlled, check the connector for a good connection. If OK, substitute a known-good control unit and recheck.



View from wire side


No.	Wire	Test condition	Test: desired result	Possible cause (if result is not obtained)
1	BLK	Under all conditions.	Check for continuity to ground: should be continuity.	<ul style="list-style-type: none"> • Poor ground (G201 G401). • An open in the wire.
2	RED/BLK	Lighting switch ON.	Check for voltage to ground: should be battery voltage.	<ul style="list-style-type: none"> • Blown No. 8 (10A) • Faulty lighting switch. • An open in the wire.
3	RED	Lighting switch ON.	Attach to ground Dash lights should come on full bright.	<ul style="list-style-type: none"> • An open in the RED/BLK or RED wire.
4	RED/GRN or RED/WHT	Adjusting dial rotated.	Check for resistance between the RED/GRN and RED/WHT terminals: should be 8–12 kΩ at all time.	<ul style="list-style-type: none"> • Faulty controller. • An open in the wires.
5	RED/BLU and RED/WHT	Adjusting dial rotated.	Check for resistance between the RED/BLU and RED/WHT terminals: should vary from 0 to 10,000 ohms as the dial is rotated.	

Dashlight Brightness Control (KQ model only)


Controller Removal

1. Remove the caps, then remove the 4 screws from the instrument panel (3 D, 5 D).
2. Remove the 4 screws from the instrument panel (4 D).
3. Remove the instrument panel from the dashboard.
4. Disconnect the 3-P connector from the controller.

2 D H/B, 5 D :



4 D :





Controller Test

1. Remove the instrument panel from the dashboard.
2. Measure resistance between the A and C terminals.

Resistance : 8,000-12,000 ohms

NOTE : Resistance will vary slightly with temperature.


3. Measure resistance between the B and C terminals while rotating the adjusting dial. Resistance should vary from 0 to 10,000 ohms as the dial is rotated.



Turn Signal / Hazard Flasher System



Component Location Index



└ Circuit Diagram

MAIN FUSE BOX

BATTERY (+)

No.31 (60A) No.32 (60A) No.34 (10A)

WHT/BLK

IGNITION SWITCH

BAT-A IG1

BLK/YEL

DASH FUSE BOX

No.1 (10A)

WHT/GRN

HAZARD WARNING LIGHT (1.4W) (European model only)

WHT/GRN

YEL

RED/BLK

DASHLIGHT LIGHTING SWITCH

GRN/BLU

GRN/YEL

HAZARD SWITCH

ON L. R. OFF

HAZARD LIGHT (0.84W)

TURN SIGNAL SWITCH

A L R B C

GRN/RED

GRN/WHT

TURN SIGNAL/HAZARD RELAY

L B E

GRN/RED

GRN/BLU

GRN/YEL

INDECATORS (1.4W x 2)

L.TURN SIGNAL LIGHT

REAR (21W) SIDE (5W) FRONT (21W)

BLK

BLK

BLK

BLK

(LHD)

R.TURN SIGNAL LIGHT

FRONT (21W) SIDE (5W) REAR (21W)

BLK

BLK

BLK

BLK

(RHD)

DASHLIGHT BRIGHTNESS CONTROLLER (KQ model)

RED

BLK

Without DASHLIGHT BRIGHTNESS CONTROL

2D H/B,5D : G511 4D : G561 LHD : G301,G401 RHD : G301

LHD : G201 RHD : G201,G401 2D H/B,5D : G511 4D : G561 LHD : G301,G401 RHD : G201,G401




Turn Signal/Hazard Relay Input Test

Remove the dashboard lower panel, then remove the turn signal /hazard relay from the dash fuse box.

Make the following input tests at the relay holder pins.

If all tests prove OK, but the relay fails to work, replace the turn signal/hazard relay.



No.	Terminal	Test condition	Test: desired result	Possible cause (if result is not obtained)
1	E	Under all conditions.	Check for continuity to ground: should be continuity.	<ul style="list-style-type: none"> • Poor ground (G301, G401 (G201, G401)) • An open in the BLK wire.
2	B	Ignition switch ON.	Check for voltage to ground: should be battery voltage.	<ul style="list-style-type: none"> • Blown No.1 (10A) fuse. • An open in the YEL or GRN/WHT wire. • Faulty hazard switch.
3	B and L	Hazard switch ON and connect the B terminal to the L terminal.	Hazard lights should come on.	<ul style="list-style-type: none"> • Blown No.34 (10A) fuse. • Blown bulb. • Poor ground. • Faulty hazard switch. • An open in the WHT/GRN, GRN/RED, GRN/YEL or GRN/BLU wire.
		Ignition switch ON and turn signal switch in R or L and connect the B terminal to the L terminal.	R or L side turn lights should come on.	<ul style="list-style-type: none"> • Faulty turn signal switch.



(): RHD

Turn Signal / Hazard Flasher System

Hazard Switch Test

- 1. Remove the hazard switch
- 2. Check for continuity between the terminals in each switch position according to the table.

Terminal Position	A	B	C	D	E	F	G
OFF							
ON							




C*.....European model only

Rear Window Defogger




Component Location Index



Rear Window Defogger

Circuit Diagram

NOTE : Several different wires have the same color. They have been given a number suffix to distinguish them (for example BLK/GRN1 and BLK/GRN2 are not the same).





Troubleshooting

NOTE: The numbers in the table show the troubleshooting sequence.

Symptom	Item to be inspected							
	Blown indicator light bulb	Blown No. 18 (10A) fuse (in the dash fuse box)	Blown No. 36 (20A) fuse (in the main fuse box)	Defogger switch	Function test	Defogger relay	Repair defogger wire	
Defogger operates, but indicator light does not go on.	1							
Defogger does not operate and indicator light does not go on.		1		2			G301, G401 [G201, G401]	BLK/YEL or BLK/GRN ¹
Defogger does not operate, but indicator light goes on.			1		2	3	2D H/B, 5D : G511 4D: G821	YEL/GRN or BLK/GRN ²
Broken defogger wire							1	


[] : RHD

Rear Window Defogger

Function Test

CAUTION: Be careful not to scratch or damage the defogger wires with the tester probe end.

1. Check for voltage between the positive terminal and body ground with the ignition switch and the defogger switch ON.
There should be battery voltage.
 - If there is no voltage, check for:
 - Faulty defogger relay.
 - An open in the BLK, BLK/GRN² or YEL/GRN wire.
 - If there is battery voltage, go to step 2.




[] : 4 D (LHD)

2. Check for continuity between the negative terminal and body ground.
If no continuity, check for open in the defogger ground wire.
3. Lightly touch the voltmeter positive probe to the center of each defogger wire, and the negative probe to the negative terminal.
There should be approximately 6 V with the ignition switch and the defogger switch ON.
 - If the voltage is as specified, the defogger wire is OK.
 - If there is battery voltage, the defogger wire is broken in the negative side from the center.
 - If there is no voltage, the defogger wire is broken in positive side from the center.

Defogger Wire Repair


NOTE: Repair section must be no longer than one inch.

1. Lightly rub area around the break with the fine steel wool, then clean with alcohol.
2. Carefully mask above and below the broken portion defogger wire with cellophane tape.



3. Using a small brush, apply heavy coat of silver conductive paint extending about 1/8 in. on both sides of the break. Allow 30 minutes to dry.

NOTE: Thoroughly mix paint before use.





4. Check for proper operation with a voltmeter (approximately 6 V at the mid-point).
5. Apply a second coat of paint in the same manner. Dry 3 hours before removing tape.



Switch Test



1. Remove the switch from the instrument panel.
2. Check for continuity between the terminals according to the table.

Terminal Position	A	B	C	D	E
ON	○	○	○	○	○
OFF					



Relay Test

1. Remove the defogger relay from the dash fuse box.
2. There should be continuity between the A and B terminals when the battery is connected to the C and D terminals.
There should be no continuity when the battery is disconnected.




Headlight Adjuster (KG model only)

Circuit Diagram

Discription :

The motor-driven type headlight adjuster is mounted behind the headlight unit. When you operate the adjuster switch, the motor driving circuit senses the ground through each resistor and the headlight adjuster is actuated.



Wiring Diagrams

Index

Air Conditioner	14	Lighting System	3
ALB System	17	Locks, Power	8
Automatic Transmission		Mirrors, Power	7
Control System	18	Seat Heaters	9
Battery	1	Shift Lever Position	
Blower Controls	14	Indicator	16
Charging System	1	Starting System	1
Cigarette Lighter	6	Stereo Sound System	7
Clock	6	Sunroof	7
Cooling Fan System	2	Turn Signal/Hazard	
Defogger, Rear Window	7	Flasher System	6
Fuel-Injected System	12	Warning System	
Gauges	2	ALB/Rear Differential	
Headlight Adjuster System	16	Warning	17
Heater Controls	14	Brake Warning	2
Horns	6	Charge Warning	1
Ignition Switch	1	Check Engine Warning	12
Ignition System	1	Choke Warning	11
Integrated Control Unit	2	Oil Pressure Warning	2
Lights, Exterior		Seat Belt Reminder	2
Back-up Lights	6	Hatch-open Warning	2
Brake Lights	6	Washers	
Fog Lights, Rear	3	Headlight	10
Hazard Lights	6	Windshield	9
Headlights	3	Rear Window	9
License Plate Lights	3	Windows, Power	8
Marker Lights, Front	3	Wipers	
Taillights	3	Windshield	9
Turn Signal Lights	6	Rear Window	9
Lights, Interior			
Dashlight Brightness			
Control	3		
Dome Light	6		
Trunk Light	6		